

User Manual

1. Input voltage: AC 120V $\pm$ 20%
2. Output current: max AC6.3A(resistive load)
3. Terminals

- a. P1—120 VAC.
- b. P2— AC out , connected to the Motor

4. Operating

a. When it is connected to the AC power supply, the controller begins working with a green LED lighting.

b. Open the Apps on , set the phone wifi connection according to the instruction and let the controller be connected to the network. Then the green LED turns in flashing. At this time, the value of temperature and humidity on the Apps can be adjusted.

c. While automatic mode is selected, if the controller detects a value of temperature and humidity higher than the setting, the relay on the controller begins working, and output AC120V to drive the motor. A red LED turns on.

If the value becomes lower than the setting, the relay stops working. The motor will stop and the red LED turns off.

d. While manual mode is selected, changing the ON/OFF setting of Apps will start the motor at once.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.