

SYLVANIA


SPA151

SPEAKER

Operating Instructions


 Please carefully read the operating instruction before using our product
SYLVANIA is a registered trademark of OSRAM Sylvania Inc. used under license.

PANEL FUNCTION DECLARATION



1. : INTERCHANGE (MODE SWITCH)	2.USB/SD CARD/AUX
: REC	3.MICROPHONE INPUT
: REPEAT	4.LIGHT ON/OFF
: PREVIOUS SONG	5.POWER ON/OFF
: PLAY/PAUSE	6.ADJUST THE VOLUME OF MICROPHONE
: NEXT SONG	7.BASS
	8.TREBLE
	9.ADJUST THE VOLUME OF WHOLE UNIT
	10.LED / DC9V INPUT / CHAR/FULL

REC FUNCTION DECLARATION



HOW TO USE REC?

Step 1

Make sure the unit is working, put USB or SD card into the slot.

Step 2

Inserting the wired microphone, make sure it is working normally by speaking some words, e.g. 'hello'. If you can hear the voice which means wired microphone is ready to rec.

Step 3

Long press the button '●' then to start recording, you are freely to rec what you want. Short press the button '●' to play recording when you finish recording.

REMOTE FUNCTION DECLARATION



1. MUTE: Press this button to mute the unit.
2. Press this button to toggle between the various inputs(AUX,USB,SD,FM,BLUETOOTH), Long press this button to turn on/turn off the voice prompt.
3. Press this button to start recording.
4. Press this button to increase the master volume for the unit.
5. Press this button to pause or play the unit when it is on the mode of USB. When it is on the mode of FM,press this button to auto scan all channels. Long press to change language to Chinese/English for the voice prompt.
6. Press this button to select the previous song/channel.
7. Press this button to reduce the master volume for the unit.
8. Press this button to repeat one/repeat all.
9. Press this button to play the recording.
10. Press this button to select the next song/channel.
11. Press this button to the EQ mode of Normal,Jazz,Rock,Pop,Classical.
12. 0-9,Key number for selecting the certain songs in the USB/SD/TF Card.

BLUETOOTH FUNCTION DECLARATION

STEP 1

Press the mode button on front panel to launch the bluetooth application. Then you will see that 'bluetooth' logo show on the screen.

STEP 2

Slide the 'bluetooth' switch to 'on'. Your other devices with bluetooth function, like smart phone, computer or others, then it automatically begins scanning for nearby bluetooth devices.

STEP 3

When the "Sylvania SPA151" appears on your devices, tap to connect it. It will show "Connected" on your device after connected successfully.

Depending on which device you are trying to connect the speaker to, it may be necessary to enter a passcode. Enter passcode "0000" if prompted by the device.

STEP 4

Tap the entry for bluetooth accessory when it is detected by the smart phone or computer and displayed on the screen. Then it can use bluetooth to operate in conjunction with accessory.

CHARGING INDICATOR

Charging: the led light will be in red color

Full: when full-charging the led light will be in green color

Charging time : 6 to 7 hours

Working time : 3 to 4 hours

TECHNICAL SPECIFICATIONS

- Frequency range: 2.4-2.48Ghz
- Working distance: up to 15 meters in open space
- Supporting: USB/SD card play
- FM Radio: frequency 87.5 ~108MHz
- Remote Control: up to 5 meters in open Space LED
- light with on/of Switch
- Output power: 40W
- Distortion: ≤1.0%
- Frequency response: 180Hz – 20Khz Microphone
- sensitivity: -40dB
- Working time: Music time 3 to 4 hours
- Input jack: Aux input ,wired microphone input
- Charging input power: DC 9V (Adapter) Charging
- time: 6 to 7 hours

FCC STATEMENTS

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm

BACK PANNEL



FM RADIO ANTENNA

INSTRUCTION

1. THIS UNIT HAS RECHARGEABLE BATTERY, WHEN THE BATTERY POWER IS FINISH, KINDLY PLUG THE SWITCH TO ELECTRIC SOCKET ACCORDING TO INPUT VOLTAGE.
2. WHEN THE UNIT IS CHARGING PLEASE MAKE SURE AC/DC SWITCH SHOULD BE ON, ONCE CHANGED PLEASE UNPLUG THE SOCKET FROM ELECTRICITY SAFELY.

YOU HAVE TO CHARGE THE BATTERY FOR 10 TO 12 HOURS FOR THE FIRST USE, NEXT TIME ONWARD YOU HAVE TO RECHARGE THE BATTERY FOR 8 TO 10 HOURS.

BATTERY NORMAL WORKING TIME IS 3 TO 4 HOURS ACCORDING TO THE VOLUME OF SPEAKER.

ATTENTION

1. IN ORDER TO KEEP BATTERY LIFE LONGER, KINDLY CHARGE THE BATTERY EVERY TIME AFTER THE BATTERY POWER IS FINISH, OR IT WILL DAMAGE THE BATTERY IF YOU KEEP IT LONG TIME WITHOUT CHARGE OR NOT USING IT FOR LONG PERIOD OF TIME, SO KINDLY USE IT AFTER REGULAR INTERVAL OF TIME.
2. OUR COMPANY RESERVE RIGHT TO BRING CHANGES IN PRODUCT WITHOUT ANY NOTICE.
3. IF ANY ISSUE WITH THE PRODUCT KINDLY CONTACT THE PROFESSIONAL PERSON TO HANDLE AS THIS UNIT IS HIGH POWER , SO PLS DON'T OPEN THE UNIT.
4. KEEP IT AWAY FROM CHILDREN.

For service assistance and product information, please call: 1-800-968-9853.

Curtis International Ltd.

7045 BECKETT DRIVE, UNIT 15, MISSISSAUGA, ON, L5S 2A3

www.curtisint.com