









|  |   |  |   |  |
|--|---|--|---|--|
| <div>English</div> <div>F2 Tag Item Finder<br/>User Manual</div> <div>Model: F2 Tag</div> <div><div>Works with<br/>Apple Find My</div></div> | <div>Active 1-Year Warranty</div> <div>Please send your order number to our WhatsApp / Email <b>within 7 days</b> after receiving the product to activate the warranty. We will provide you 1 year after-sales service.<br/><b>(Support free replacement of damaged products. No need to return damaged products)</b></div> <div><div>Email: qxqvip@gmail.com</div><div>WhatsApp: +86 18038108503</div></div> | <div>Major Functions</div> <div>1. By using the <b>Apple Find My</b> app, you can find your F2 Tag from your iPhone, iPad, iPod touch, or Mac. Simply open the <b>Apple Find My</b> app, click on the corresponding item, and you will see the location of the Tag item finder. Use the map guide to find it.<br/>2. Even if it is left in a place far away from you, you can also enable the lost mode to lock the location of the item and use the map guide to find it since Apple device are widely used.<br/>3. In addition, if your F2 Tag item finder leaves the range of your Apple device, you will receive an alarm notification. This can help you timely discover the lost items and avoid further losses.</div> | <div>Turn On/Off</div> <div><div><div>1. <b>Turn On:</b><br/>Press and hold the button of F2 Tag item finder for 3 seconds, item finder makes a sound of "Di Di Di Di".</div><div>2. <b>Turn Off</b><br/>Press and hold the button of F2 Tag item finder for exactly 3 seconds, and it will play the confirmation sound "Di Di".</div><div>3. <b>Reset</b><br/>Click the button 5 times in a row, when the 5th time is pressed, don't release the button, and keep pressing the button for 3 seconds at least, a beeping "Di Dididididi" will be played by buzzer. Release the button after confirming the sound effect (the above operation needs to be completed within 5 seconds).</div><div>4. <b>Battery Replacement</b><br/>Click the button 5 times in a row, when the 5th time is pressed, don't release the button, and keep pressing the button for 3 seconds at least, a beeping "Di Dididididi" will be played by buzzer. Release the button after confirming the sound effect (the above operation needs to be completed within 5 seconds).</div></div><div></div></div> | <div>How to Connect</div> <div><div><div>① Turn on the item</div></div><div><div>② Open "Find My" App</div></div><div><div>③ Tap "Add Item"</div></div><div><div>④ Select "Other Supported Item"</div></div></div> |
|--|---|--|---|--|

备注：

1、说明书用105克双铜纸

2、彩色打印

3、双面打印。