



bestchoiceproducts

User Manual

Product Name:SPEAKER

Brand name:BCP

Model name: SKY4728

Manufacture: TONOUCH ELECTRONICS LIMITED

Safety Precautions


- Disassembly and installation of this speaker cabinet must be carried out by qualified personnel following the approved safety standards.
- Do not attempt to clean the plastic enclosure with solvents or petrochemical based cleaners.
- Do not place objects which are sources of heat on the speaker cabinet such as lighting equipment or smoke machines.
- Do not expose the speaker cabinet to direct rain or allow it to stand in water. Liquid getting into the box is hazardous and will risk a short circuit.
- Do not stack the speaker cabinet in a manner that could cause injury should it become dislodged.
- Before installation, ensure that the voltage and frequency of power outlet match the power requirements of the speaker.
- Disconnect from main power before making connections to the speaker.
- Make sure that the power cord is never crimped or damaged by sharp edges.

Attention

Before connecting or operating your speaker, study the accompanying instruction manual and be aware of the operating precautions and wiring procedure.

WARNING:

1. Do not mix alkaline, standard (carbon-zinc), and rechargeable (nickel hydride) batteries.
2. Do not mix old and new batteries.
3. Non-rechargeable batteries should not be charged.
4. Rechargeable batteries should be charged under adult supervision only.
5. Exhausted batteries should be removed.
6. The supply terminals should not be short-circuited.
7. Do not put batteries next to or in a heat source (fire, electronic heating device, etc.).
8. Do not hit batteries against hard objects.
9. Do not submerge batteries in water.
10. Batteries should be inserted with the correct polarity.



This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service, or the shop where you purchased the product.



WARNING:

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

E-MAIL US:

We're here 7 days a week to help you!

customerservice@bestchoiceproducts.com



Functions

1. Media Player

MODE	Toggle between USB / SD / BLUETOOTH
▶	Play/Pause
↺	Repeat
◀◀	Last
▶▶	Next

2. Volume1 : Control the Volume of Microphone input

3. 6.35 MM Jack input

4. XLR for Mic input

5. Wireless MIC volume control

6. Volume 2 : Control the Volume of line in

7. MP3 Volume: Control the volume of MP3

8. MASTER Volme:Control the master volume

9. AUX input

10. Equalizer : Control the tone level of high frequency at range -12dB to + 12dB.

11. Equalizer: Control the tone level of low frequency at range -12dB to + 12dB.

12. RCA connector to control Line input, RCA right channel input, and RCA left channel input

13. XLR connector to control Line input: Allows you to connect an external audio device (CD, radio ,DVD ,etc.), with an adaptor

14. XLR connector to control Line out: Connect other amplifier or even another powered speaker cabinet in cascade

15. Main supply inlet: Connects the main power cable

16. Power On/Off Switch

17. Speaker out: Connect with a passive speaker

Remote Control

- Use the remote control to operate the media player.
- The numbers are the remote control can be used to play corresponding numbered songs on the USB drive or SD card.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.