

120mm


180mm

Selfie Power Bank with Wireless Instruction Manual

Please read the following carefully before using the device to ensure safe and proper usage.

Package Content:

- 1 Power bank
- 1 USB-C to USB-C cable
- 1 User Manual



Specifications:

Capacity: 4500mAh/3.7V
Input (USB-C): 5V/3A, 9V/2A, 12V/1.5A
Output: total 22.5W max
USB-C: 5V/3.1A, 9V/2.22A, 12V/1.67A
Wireless: 15W max
USB-C+ Wireless: 5V/3A
Power and selfie button
Logo lights up when wireless charging

- 1 -

- 2 -

Charging Your Device Using Your power bank:

IMPORTANT: Before using your power bank for the first time, fully charge it (when powered on, all 4 status LEDs are illuminated).

Connect the supplied USB cable (or the cable that came with your device) to the power bank's USB port and to your device. Then begin charging.

During charging of your device, the four indicators will shut off one by one as your device receives power, when the power bank is low in power, the first LED indicator bar will flash and go out automatically until all the power is used up.

Checking Your Power bank Battery's Charging Status

Momentarily press the power button on your power bank and the status LEDs will indicate its charge level. Four LEDs means that the power bank battery is fully charged, while one LED means that it's almost empty. Know before you go!

1 LED	< 25%
2 LEDs	< 50%
3 LEDs	< 75%
4 LEDs	< 100%

If you see no LEDs or 1 flashing LED, the battery status is less than 10%. Please recharge the power bank.

Recharging your power bank:

To recharge your power bank, use the supplied USB cable to connect its USB-C port to a USB wall charging adapter. While recharging the power bank, the LEDs will light up. If there is one LED flashing, the charging is not completed. Once the power bank is fully charged, all LEDs are illuminated.

NOTE: For best results, do not connect the power bank to a computer's USB port. We recommend using a wall charging adapter that supports fast charging protocols such as QC or PD.

正面
(FRONT)

背面
(BACK)


说明书折法:

Instruction Manual

Please read the following carefully before using the device to ensure safe and proper usage.

Package Content:

- 1 Power bank
- 1 USB-C to USB-C cable
- 1 User Manual



Specifications:

Capacity: 4500mAh/3.7V
Input (USB-C): 5V/3A, 9V/2A, 12V/1.5A
Output: total 22.5W max
USB-C: 5V/3.1A, 9V/2.22A, 12V/1.67A
Wireless: 15W max
USB-C+ Wireless: 5V/3A
Power and selfie button
Logo lights up when wireless charging

- 1 -

- 2 -

Charging Your Device Using Your power bank:

IMPORTANT: Before using your power bank for the first time, fully charge it (when powered on, all 4 status LEDs are illuminated).

Connect the supplied USB cable (or the cable that came with your device) to the power bank's USB port and to your device. Then begin charging.

During charging of your device, the four indicators will shut off one by one as your device receives power, when the power bank is low in power, the first LED indicator bar will flash and go out automatically until all the power is used up.

Checking Your Power bank Battery's Charging Status

Momentarily press the power button on your power bank and the status LEDs will indicate its charge level. Four LEDs means that the power bank battery is fully charged, while one LED means that it's almost empty. Know before you go!

1 LED	< 25%
2 LEDs	< 50%
3 LEDs	< 75%
4 LEDs	< 100%

If you see no LEDs or 1 flashing LED, the battery status is less than 10%. Please recharge the power bank.

Recharging your power bank:

To recharge your power bank, use the supplied USB cable to connect its USB-C port to a USB wall charging adapter. While recharging the power bank, the LEDs will light up. If there is one LED flashing, the charging is not completed. Once the power bank is fully charged, all LEDs are illuminated.

NOTE: For best results, do not connect the power bank to a computer's USB port. We recommend using a wall charging adapter that supports fast charging protocols such as QC or PD.


中间对折

Instruction Manual

Please read the following carefully before using the device to ensure safe and proper usage.

Package Content:

- 1 Power bank
- 1 USB-C to USB-C cable
- 1 User Manual



Specifications:

Capacity: 4500mAh/3.7V
Input (USB-C): 5V/3A, 9V/2A, 12V/1.5A
Output: total 22.5W max
USB-C: 5V/3.1A, 9V/2.22A, 12V/1.67A
Wireless: 15W max
USB-C+ Wireless: 5V/3A
Power and selfie button
Logo lights up when wireless charging

- 1 -

- 2 -

Charging Your Device Using Your power bank:

IMPORTANT: Before using your power bank for the first time, fully charge it (when powered on, all 4 status LEDs are illuminated).

Connect the supplied USB cable (or the cable that came with your device) to the power bank's USB port and to your device. Then begin charging.

During charging of your device, the four indicators will shut off one by one as your device receives power, when the power bank is low in power, the first LED indicator bar will flash and go out automatically until all the power is used up.

Checking Your Power bank Battery's Charging Status

Momentarily press the power button on your power bank and the status LEDs will indicate its charge level. Four LEDs means that the power bank battery is fully charged, while one LED means that it's almost empty. Know before you go!

1 LED	< 25%
2 LEDs	< 50%
3 LEDs	< 75%
4 LEDs	< 100%

If you see no LEDs or 1 flashing LED, the battery status is less than 10%. Please recharge the power bank.

Recharging your power bank:

To recharge your power bank, use the supplied USB cable to connect its USB-C port to a USB wall charging adapter. While recharging the power bank, the LEDs will light up. If there is one LED flashing, the charging is not completed. Once the power bank is fully charged, all LEDs are illuminated.

NOTE: For best results, do not connect the power bank to a computer's USB port. We recommend using a wall charging adapter that supports fast charging protocols such as QC or PD.

180*120mm 70g 书写纸 双面印刷 对折1次

标准说明书

JMTek

图号

SFPB100-SMS-JMT001

版次

第1版

材料

颜色

单位

mm

型号

SFPB100

日期

240929

制图

Sam

审核

Steven

客户回签

料号

70431-0361-01

第三角度投影



第 1 张 共 1 张

折后正面

折后尺寸: 90 x 120mm

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.