

1 Annex C – EUT pictures internal

1.1 List of Pictures

Picture 1: EUT without handle housing – front view	2
Picture 2: EUT without handle housing – top view	2
Picture 3: EUT with battery and without handle housing – front view.....	3
Picture 4: EUT without cover – front view	3
Picture 5: EUT without cover and RF module– front view.....	4
Picture 6: RF module – top view.....	4
Picture 7: RF module – bottom view.....	5
Picture 8: EUT without border – front view.....	5
Picture 9: Disassembled EUT – top view.....	6
Picture 10: Left side of disassembled EUT – top view.....	6
Picture 11: Right side of disassembled EUT – top view	7
Picture 12: Right side of disassembled EUT without module– top view	7
Picture 13: Module of right side of disassembled EUT– top view	8
Picture 14: Module of right side of disassembled EUT– bottom view.....	8
Picture 15: Lock of EUT – top view.....	9



Picture 1: EUT without handle housing – front view



Picture 2: EUT without handle housing – top view




Picture 3: EUT with battery and without handle housing – front view




Picture 4: EUT without cover – front view



Picture 5: EUT without cover and RF module– front view




Picture 6: RF module – top view




Picture 7: RF module – bottom view




Picture 8: EUT without border – front view




Picture 9: Disassembled EUT – top view




Picture 10: Left side of disassembled EUT – top view




Picture 11: Right side of disassembled EUT – top view



Picture 12: Right side of disassembled EUT without module– top view



Picture 13: Module of right side of disassembled EUT– top view



Picture 14: Module of right side of disassembled EUT– bottom view



Picture 15: Lock of EUT – top view