



<p><b>Features of S6 upgraded wireless earbuds:</b></p> <p><b>One Step Pairing:</b> Both earbuds can be connected with cell phone separately the upgraded earbuds adopt wireless 5.0 version, it can be connected with your devices automatically, IPX7 waterproof, prevent sweat Music non-stop. Shower can use headphones.</p> <p><b>Longer Battery Duration:</b> Up to 4 hours playtime with each charge, and an extra 20 hours from the included storage and charging case. S6 upgraded wireless earbuds can last up to 26 hours for you enjoying your music and movies.</p> <p><b>True Wireless Design:</b> If you're tired of headphone's wire always entangled and messy, true wireless design is good news for you. Adopted true wireless technology, S6 wireless earbuds realize to free your ears from bondage of wire, and you won't need to tolerate tangled wires anymore.</p> <p><b>Functions:</b></p> <p><b>In terms of iOS devices</b></p> <p>It can be used to answer/reject/redial calling, play/pause/switch songs, activate Siri, and control the volume up and down by the earbuds.</p> <p>Click once: pause/play music (Listening music mode) Click once: answer/hang up (calling mode)</p> <p><b>In terms of Android devices</b></p> <p>It supports answer/reject/redial calling, play/pause/switch songs, control the volume up and down by the earbuds. Due to the limitation of Android system, some Android device may not support to adjust volume by the earbuds, you need to adjust the volume on your smart phone.</p> <p>Some Android device may not receive ringtone reminder through earbuds when someone is calling you.</p> <p>Click once: pause/play music (Listening music mode) Click once: answer/hang up (calling mode)</p> <p>Click twice on Left earbud: volume down Click twice on Right earbud: volume up</p> <p>Click three times on Left earbud: switch to previous song Click three times on Right earbud: switch to next song</p>	<p>Click twice on Left earbud: volume down Click twice on Right earbud: volume up</p> <p>Click three times on Left earbud: switch to previous song</p> <p>Click three times on Right earbud: switch to next song</p> <p>Press 2 seconds on Right earbud: redial the last dialed number Press 2 seconds on Left earbud: wake up Siri</p> <p><b>In terms of Android devices</b></p> <p>It supports answer/reject/redial calling, play/pause/switch songs, control the volume up and down by the earbuds. Due to the limitation of Android system, some Android device may not support to adjust volume by the earbuds, you need to adjust the volume on your smart phone.</p> <p>Some Android device may not receive ringtone reminder through earbuds when someone is calling you.</p> <p>Click once: pause/play music (Listening music mode) Click once: answer/hang up (calling mode)</p> <p>Click twice on Left earbud: volume down Click twice on Right earbud: volume up</p> <p>Click three times on Left earbud: switch to previous song Click three times on Right earbud: switch to next song</p>	<p>Press 2 seconds on Left earbud: redial the last dialed number</p> <p><b>Wireless earbuds charging:</b></p> <p>1.Put the left and right earbud charging contact point to the according elastic pin contact point of the rech-arge stand and connect. 2.The earbud indicator light is bright red when charging. 3.The earbud indicator is bright white when finished charging.</p> <p><b>Charging instruction of storage and charging box:</b></p> <p>1.Connect the USB cable with the Micro USB input, and the other part of USB cable connect with AC adapter. 2.When the box is charging, the earbuds will be under charging once the charging case is closed then the indicator light will show blue color flashing. After the charging complete, the LED indicator will show four blue light at the same time.</p> <p><b>Note:</b> The LED indicator turns blue when the earbuds are fully charged. The red indicator is flashing when charging the case. It turns to blue light when fully charged. After 2 minutes the light is off.</p>	<p><b>Package included:</b></p> <ul style="list-style-type: none"> <li>- 2* Bluetooth Earbud</li> <li>- 1* charge case</li> <li>- 1* User Manual</li> <li>- 1* USB Charging Cable</li> <li>- 2* Ear tips (2 pair)</li> </ul> <p><b>Parameters:</b></p> <ul style="list-style-type: none"> <li>wireless version: wireless 5.0 Share Technology</li> <li>Charging time: 1 hours</li> <li>Talking time: 5 hours</li> <li>Music time: 5 hours</li> <li>wireless range: 33 feet (10m)</li> </ul> <p><b>Safety precautions:</b></p> <p>The product contains a built-in lithium battery. Do not expose the product to strong sunlight, fire, or dispose it in fire, which may result in explosion. Deal with disposal of batteries in accordance with local regulations and do not treat them as house-hold waste. Do not allow the equipment to come into liquid because this will cause serious damage to the equipment. Do not place the equipment in an environment where the temperature is too high (above 45 degrees Celsius) or too low (below 0 degrees Celsius).</p>
4	5	6	7

#### FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.