

Luci Connect

User manual

MPOWERD

How to Use:

Physical buttons on Luci Connect:

- 1st Click: Soft True White at 75%, Bluetooth Turned On for Pairing
- 2nd Click: Pink
- 3rd Click: Purple
- 4th Click: Green
- 5th Click: Amber
- 6th Click: LEDs Off, Bluetooth Off (smartphone pairing will be lost)

After 1st click, launch the app on your smartphone and ensure your Bluetooth settings are ON, the app will:

- Find a new Luci Connect if the device has never been paired before and the device is powered on.
- Auto-pair if the device has been paired in the past.

Home Page of MPOWERD app:

- Menu located in Top Left.
- Right top has shortcut for On/Off for the currently selected Luci.
- While using the On/Off button, Bluetooth LE on device will remain on and connected until the smart device is out of range or the Luci is turned off by the physical button on the light.
- Name of the Unit/Group that is being controlled is in the middle. You may group a number of lights together and control (turn on/off) all at once. For example: if you have three Luci Connect units on your backyard patio you can connect to all three and when they are in the group you can then turn all on / off at once.
- 3 Navigation Buttons (large bubbles in center-bottom of app screen) in a slider field: Brightness, Mood, Timer. Swipe left or right to select the settings button you wish to change.

Brightness:

- This page features a slider to choose the intensity / brightness on True White or any color already selected.

- Select brightness and click on “<” on top left to go back.
- If brightness is at 0%, the light is not off. Bluetooth pairing is still in place.

Mood:

- This page features a color wheel and moods (color cycles) at the bottom. You can pick a color from the wheel, select a preset mood or create a custom mood of your choice.
- There is no way of going back to the True White LEDs on this page - yet. If you want to use the True White LEDs, you must turn the unit off through the physical power button (it will unpair the unit and smart device), and turn it back on at the first click.
- You can use the white in the middle of the color wheel, but this will be a white obtained using the RGB LEDs, not a true white that the first click provides through the set of white LEDs. The brightness of this white will be lower, and it will always be slightly red, green or blue.
- While using the color wheel, use the outermost perimeter to pick the colors for the best results.
- Preset moods:
 - Party: Pink, Orange, Purple, 2 seconds each, colors change without fading/transition
 - Candle: Yellow, Amber, Gray, 1 second on each
 - Sunrise: Amber, goes from full to zero brightness in every 3 seconds
 - You can select preset moods by clicking on them, it will activate the mood. User can move the circle in the color wheel to switch back to a solid color from the color wheel
- Custom Moods:
 - You can create custom moods. Swipe preset moods to the left and click on “+ Customer Mood”.
 - Custom moods will be placed to the left most under preset moods so the user doesn't have to scroll all the way to the right.
 - You can rename the Custom Moods at the top of the edit screen next to the pencil icon.
 - Add up to 6 colors
 - Select transition speed
 - Select brightness level
 - Click Save. If clicked on “<” on top left, progress will be lost.
 - If clicked on “Edit” colors can be removed.

- You can go back to editing the custom mood by clicking Edit on top right. ◦ Preset moods cannot be edit or deleted.

Timer:

- This page features a “Timer” on the top half to turn the light/group of lights off after a certain amount of relative time, eg. 25 min. You can select a certain amount of hours & minutes to turn the lights off, for example to use as a night light.
- To use the timer, select an hour and minute, click start the timer. Light/group will turn off after relative time is complete.
- “Schedule” feature to schedule the light/group of lights to turn on at an absolute time, for a wake timer for example.
- To use the schedule, slide the schedule to on position and click on the little arrow underneath. On the next page, select:
 - Start time
 - Stop time
 - Mood from a solid color, preset mood or custom mood that is previously saved
 - Brightness
 - And optional repeat days if desired
 - Click set to save

Left top Menu button will allow you to go directly to the following locations within the app:

- My Lights: to rename the lights that have already been paired before
- My Groups: to create groups of lights
- About
- Terms & Conditions
- Privacy Policy
- My Info: to submit name, email and zip to receive marketing emails
- FAQ

Product Information Guide

This Important Product Information Guide contains safety, handling, disposal, recycling, and regulatory information as well as the limited warranty for Luci. Read all safety information and operating instructions before using Luci to avoid injury or harm. For a downloadable version of the Luci User and Product Guides, visit www.mpowerd.com/user-manual.

IMPORTANT SAFETY AND HANDLING INFORMATION

Read the following warning before you or your child play with Luci. Failing to do so may cause injury.

CAUTION: To reduce the risk of damage or injury, do not attempt to remove Luci's shell; please refer all non-routine servicing questions to MPOWERD. No user-serviceable parts are contained inside.

General

- Read all safety and operating instructions before operating Luci.
- Retain the safety and operating instructions for future reference.
- Follow all operating and use instructions.
- Do not attempt to service Luci yourself. Refer all non-routine servicing to MPOWERD.

Keeping Luci Within Acceptable Temperatures

Operate and store Luci in a place where the temperature is between -10° and 50° C (15° to 122° F). Low or high-temperature conditions might temporarily shorten battery life or cause Luci to temporarily stop working properly. Avoid dramatic changes in temperature or humidity when using Luci, as condensation may form on or within Luci. Don't leave Luci on your car dashboard because temperatures on the dashboard can exceed this range. When you're using Luci or charging the battery, it is normal for Luci to get warm. The exterior of Luci functions as a cooling surface that transfers heat from inside the unit to the cooler air outside.

Use and Maintenance

Never:

- Use Luci as a flotation device, although Luci will float and is waterproof, it is not designed to support weight while in the water. This can damage the light and compromise its safe operation.
- Hang anything from the handles on Luci. The handles are designed to hold the weight of Luci only, not additional weighted items and will break under extreme pressure.
- Stare into the lights for extended periods of time, which can cause permanent damage to your eyes.

Always:

- Be aware of the structure that you hang Luci from to ensure a secure connection. Always make sure it is a safe, stable location that will hold Luci with variations in the weather.
- Ensure that you are close to the Luci when connecting and changing settings on Luci. The Bluetooth antenna will reach up to 30m (100 ft) but that can differ based on environmental elements like trees, weather, and buildings.
- Periodically examine Luci for potential hazards such as cracked, damaged or otherwise broken parts. In the event of such damage, do not use Luci until it can be replaced or repaired.

Battery Warning

- Lithium Polymer batteries are extremely hazardous and liable to cause serious injuries to persons or property. The user accepts liability for the use of a Lithium Polymer battery. As the manufacturer and the distributor cannot ensure the battery is used correctly (charging, discharging, storage, etc.), they cannot be held liable for damages caused to persons or property.
- In the event of battery leakage, avoid the liquid coming into contact with skin and eyes. In case of contact with the skin, wash copiously with soap and water. In case of contact with the eyes, rinse copiously with cold water and consult a doctor. If you notice a suspicious smell or noise or observe smoke around the charger, disconnect it immediately.
- Non-compliance with the instructions below could result in gas being given off, fire, electric shock or an explosion.

Charging

- Never charge a leaky battery or one that has been damaged.
- Do not charge other devices with the Luci near inflammable materials or on an inflammable surface (carpet, wooden flooring, wooden furniture, etc.) or conducting surface.
- Do not cover your product or its charger while the battery is charging. Recharge the battery at a temperature of between -10° and 50° C (15° to 122° F).

Use and storage

- Do not use Luci if its hard case around the battery and solar panel have been broken and the battery's plastic cover has been cracked or compromised in any way.
- Do not expose the battery to excessive physical shock.
- Do not expose Luci and its battery to heat or dispose of a fire.
- Do not put the battery in a microwave oven or in a pressurized container.
- Do not attempt to dismantle, pierce, distort or cut the battery and do not attempt to repair the battery. Do not place any heavy objects on Luci.
- Do not clean Luci with a solvent, denatured alcohol or other inflammable solvents.
- Avoid direct contact with the electrolyte contained within the battery. The electrolyte and electrolysis vapors are harmful to health.
- Do not subject Luci and its battery to large temperature variations. Do not place your Luci near a source of heat.

Battery disposal

Discarding Luci and its batteries in your general household waste can be harmful to the environment. Damaged or unusable batteries must be disposed of in a container specially reserved for this purpose. When disposing of the battery, follow appropriate local guidelines and regulations. For further information contact your local solid waste authority or electronic recycling facility.

Warranty

Limited Warranty to Original Purchaser

This Luci product, as supplied and distributed by MPOWERD, Inc., and delivered new, in the original carton to the original purchaser, is warranted by MPOWERD, Inc. against

manufacturing defects in materials and workmanship for a period of 1 year. MPOWERD will repair or replace this product, at our option and at no charge with new or reconditioned parts, if found to be defective during the limited warranty period specified above.

If a defect arises:

Please contact us at support@mpowerd.com to be provided with troubleshooting advice and steps to prevent return if necessary. Once defect is determined, appropriate steps for return and/or replacement will be provided by your customer service agent. Purchaser is responsible for all return shipping costs.

Software License

Use of Luci is subject to the Luci Software License Agreement found at: mpowerd.com

Exclusions and Limitations

This warranty covers the normal and intended use of Luci. It applies only to the hardware product "Luci" manufactured by or for MPOWERD, Inc. that can be identified by the "Luci" trademark, trade name or logo affixed to it. The Limited Warranty does not apply to any non-MPOWERD hardware product or any software, even if packaged or sold with the Luci hardware product. Refer to the software license agreement accompanying the software for details of your rights with respect to its use.

MPOWERD does not warrant that the operation of Luci will be uninterrupted or error-free. MPOWERD is not responsible for damage arising from failure to follow instructions relating to Luci's use. This warranty does not apply to:

1. Consumable parts, such as batteries, or protective coatings designed to diminish over time unless failure has occurred due to a defect in materials or workmanship;
2. Damage caused by use with non-Luci products;
3. Damage caused by accidents, misuse, abuse, neglect, misapplication, fire, water, lightning or other acts of nature; incorrect electrical line voltage, fluctuations or surges; damage caused by improper installation; product alteration or modification; improper or unauthorized repair; exterior finish or cosmetic damage;
4. Damage caused by operating Luci outside the intended uses described by MPOWERD;
5. Defects caused by normal wear and tear or otherwise due to the normal aging of the Luci product.

THERE ARE NO EXPRESS WARRANTIES OTHER THAN THOSE LISTED AND DESCRIBED ABOVE, AND NO WARRANTIES WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS, SHALL APPLY AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE, AND NO OTHER EXPRESS WARRANTY OR GUARANTEE GIVEN BY ANY PERSON, FIRM OR CORPORATION WITH RESPECT TO THIS PRODUCT SHALL BE BINDING ON MPOWERD. EXCEPT AS PROVIDED IN THIS WARRANTY AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, MPOWERD IS NOT RESPONSIBLE FOR LOSS OF REVENUE OR PROFITS, FAILURE TO REALIZE SAVINGS OR OTHER BENEFITS, LOSS OF OPPORTUNITY, LOSS OF GOODWILL, LOSS OF REPUTATION, LOSS OF, DAMAGE TO, COMPROMISE OR CORRUPTION OF DATA, OR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE, MISUSE OR INABILITY TO USE THIS PRODUCT, OR ANY BREACH OF ANY WARRANTY OR CONDITION REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF MPOWERD HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. NOR SHALL RECOVERY OF ANY KIND AGAINST MPOWERD BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF LUCI. WITHOUT LIMITING THE FOREGOING, PURCHASER ASSUMES ALL RISK AND LIABILITY FOR LOSS, DAMAGE OR INJURY TO PURCHASER AND PURCHASER'S PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF THE USE, MISUSE OR INABILITY TO USE THIS PRODUCT SOLD BY MPOWERD NOT CAUSED DIRECTLY BY THE GROSS NEGLIGENCE OF MPOWERD. THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT, IS NONTRANSFERABLE AND STATES YOUR EXCLUSIVE REMEDY.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Governing Law and Arbitration

This Limited Warranty shall be governed by the laws of the State of New York without giving effect to any conflict of laws principles that may provide the application of the law of another jurisdiction. Any claim or dispute in connection with this Limited Warranty shall

be resolved in a cost-effective manner through binding non-appearance-based arbitration. The arbitration shall be initiated through an established alternative dispute resolution provider mutually agreed upon by the parties. The alternative dispute resolution provider and the parties must comply with the following rules:

1. The arbitration shall be conducted by telephone, online and/or be solely based on written submissions, the specific manner shall be chosen by the party initiating the arbitration;
2. The arbitration shall not involve any personal appearance by the parties or witnesses unless otherwise mutually agreed by the parties; and
3. Any judgment on the award rendered by the arbitrator may be entered in any court of competent jurisdiction.

If the foregoing arbitration clause does not apply for any reason, you agree to submit to the personal jurisdiction of the state courts located within Kings County, New York and the federal courts in New York, New York for the purpose of litigating all such claims or disputes, which courts shall have exclusive jurisdiction of such claims or disputes. Notwithstanding the foregoing, MPOWERD may seek injunctive or other equitable relief to protect its intellectual property rights in any court of competent jurisdiction.

Changes to this Product Information Guide

The explanations and specifications in this guide are given for information only and may be modified at any time without prior notice. The latest version of this guide will be available from our website at www.mpowerd.com/user-manual. The explanations and specifications contained in this guide are correct at the time of printing. MPOWERD reserves the right to amend or improve the product design or user guide without any restrictions and without any obligation to notify users.

As part of our ongoing effort to upgrade and improve our products, the product that you have purchased may therefore differ slightly from the model described in this guide.

End of Life Product Disposal

At the end of this product's life, please do not dispose of this product in your general household waste. Instead, in order to prevent possible harm to the environment or human

health from uncontrolled waste disposal, please dispose of this product separately in accordance with your local laws and regulation. For more information on the separate collection systems for waste electrical and electronic equipment that are available for consumers, near your home, free of charge, please contact your local municipality authority. You can also contact the retailer from which you purchased your Luci – they might have put in place recycling services or he may be part of a specific recycling program.

This product will be then treated in an environmentally sound manner at a licensed recycling plant and its components will be recovered, recycled or reused in the most efficient manner, in compliance with the requirements of the Directive on Waste Electrical and Electronic Equipment (2002/96/EC) of 27 January 2003 (as subsequently amended or replaced).

IMPORTANT!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

Apple

Made for iPod,” “Made for iPhone,” and “Made for iPad” mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance. iPad, iPhone and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

Bluetooth

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by MPOWERD, Inc. is under license.

Android

AndroidTM is a trademark of Google Inc. Use of this trademark is subject to Google Permissions. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License. Not all devices compatible. Check www.mpowerd.com/compatibility.

Software

Your Luci product can connect with special MPOWERD, Inc. copyrighted software to control its operation. Parts of this software may contain copyrighted elements that are licensed under the GPL, MIT, and Creative Common licenses among others. Additionally your Luci product contains proprietary firmware developed and copyrighted by MPOWERD, Inc. On our web site, free source code of sample software is available for developers; please visit www.mpowerd.com for more information.

Copyright

Copyright © 2018 MPOWERD, Inc. All Rights Reserved.

The total or even partial reproduction, transmission or storage of this guide in any form or by any process whatsoever (electronic, mechanical, photocopy, recording or otherwise) is strictly prohibited without prior consent from MPOWERD.

Registered Trademarks

MPOWERD, the MPOWERD logo, Luci, and the Luci logo are registered trademarks of MPOWERD, Inc; All other trademarks mentioned in this guide are the property of their respective owners.

Patents

The following MPOWERD products are protected by patents in the U.S. and elsewhere. This website is provided to satisfy the virtual patent marking provisions of various jurisdictions including the virtual patent marking provisions of the America Invents Act and 35 U.S.C. § 287(a). Additional patents may be issued or pending in the U.S. and elsewhere, and MPOWERD products not listed may be protected by one or more patents.

Luci Original, Luci Outdoor 2.0, Luci Pro: Outdoor 2.0 + mobile charging, Luci Lux, Luci Pro: Lux + mobile charging, Luci Color Essence Mini Trio, and Luci EMRG: Protected by U.S. Patent Nos. 9,194,563 and 9,638,399.

Luci Color and Luci Color Essence: Protected by U.S. Patent Nos. 9,080,736; 9,194,563; 9,255,675; and 9,638,399.

MPOWERD, Inc
45 Main Street, Suite 522, Brooklyn, NY USA MPOWERD.com

