



 <h1>气传导无线耳机</h1> <h2>说 明 书</h2>	<h3>按键功能概述</h3>  <p>1.开机/关机/暂停/播放/接电话/挂电话/下一曲/语音助手 2.磁吸充电口 3.LED指示灯 4.通话麦克风 5.通话降噪麦克风</p>	<h3>控制说明</h3> <p>开机: 耳机处于关机状态, 长按多功能键, 保持3秒, LED蓝灯闪亮, 提示音: power on;</p> <p>关机: 耳机处于开机状态, 长按多功能键, 保持5秒, LED红灯闪一下关机, 提示音: poweroff;</p> <p>链接BT: 关机状态, 长按多功能键3秒, 进入配对状态, LED指示灯红蓝灯闪烁, 耳机提示音: Pairing; 设备(智能手机、平板电脑等)搜索到BH831, 点击连接;</p> <p>链接成功: 耳机成功连接至设备时, LED蓝灯5秒闪一下, 耳机提示音: Connected;</p> <p>暂停/播放: 蓝牙连接音乐播放状态下, 单击多功能按键为暂停, 再单击多功能按键为播放;</p> <p>接听/挂断: 来电状态下: 单击多功能按键为接听, 长按2秒多功能按键为拒接电话 通话状态下, 单击多功能按键为挂断</p> <p>下一曲: 长按多功能按键1秒.</p> <p>语音助手/Siri: 蓝牙连接状态, 双击多功能键进入语音模式/Siri, 再双击退出;</p> <p>插充电线: 插上充电线后, 耳机将会自动关机进入充电状态;</p> <p>清除配对信息: 关机状态长按多功能键不松手5秒清除</p>	<p>配对, 然后进入到配对模式, 红蓝灯同时闪烁1秒, 然后进入到配对模式,</p> <p>充电: 使用充电线时, 将耳机插入USB电源, 充电状态下, LED指示灯为红色, 充电完成时, 则为蓝色;</p>	<h3>重要说明</h3> <ul style="list-style-type: none"> 本款耳机扬声器的正确佩戴位置为耳朵前方的面颊骨处, 请勿将扬声器置于耳内; 长时间听大音量的音乐可能会带来不适感, 请尽可能使用中等左右的音量, 避免长时间使用大音量; 无论音量大小, 使用耳机都将影响您对周围环境声音的感知, 使用耳机时多加注意; 切勿抛扔、坐压耳机或将耳机浸入水中; 耳机应远离火、水和高压设备; 不适合三岁以下儿童使用, 包含小零件; 请勿将其归类为生活垃圾, 而将其送往当地相应的电器电子设备回收站; <p>若用户因违反以上警告内容造成的人身财产损失, 本公司不承担任何责任</p>
---	--	--	--	---

 <h1>Manual Instruction for Air Conduction Wireless Headphones</h1>	<h3>Overview of button functions</h3>  <p>1.Power On/ Power Off/ Pause/ Play/ Answer / Hang Up / Next/ Voice Assistant 2.Magnetic Charging Port 3.LED Indicator 4.Call Microphone 5.Call Noise-cancelling Microphone</p>	<h3>Instructions on Controls</h3> <p>Power on: When the headphone is off, press and hold multi-function button for 3 seconds with blue LED flickering, reminding tone: power on.</p> <p>Power off: When the headphone is on, press and hold multi-function button for 5 seconds with red LED flickering once, reminding tone: power off.</p> <p>Connect BT: When the headphone is off, press and hold multi-function button for 3 seconds to enter a pairing state, with red and blue LEDs flickering and reminding tone: pairing. After the device (smart phone, tablet computer, etc.) discovers BH831, click it to connect.</p> <p>Connected successfully: When the headphone is successfully connected to the device, blue LED will flicker once every 5 seconds, with reminding tone: Connected</p> <p>Pause/Play: In the Bluetooth music playback state, click the multi-function button to pause, and then click the multi-function button again to play;</p> <p>Answer/Hang up: when there is an incoming call: click the multi-function button to answer, press and hold the multi-function button for 2 seconds to reject the call. During the call, click the multi-function button to hang up</p> <p>Next: press and hold multi-function button for 1 second</p> <p>Voice assistant/Siri: In Bluetooth connection state, double click multi-function button to enter voice mode/Siri, and double click it again to exit;</p> <p>Plug in charging line: upon plugging in the charging line, the headphone will be shut off automatically and enter charging state;</p> <p>Clear pairing information: with headphone shut off, press and hold multi-function button for 5 seconds to</p>	<p>clear pairing and enter pairing mode, with red and blue LEDs flickering for 1 second simultaneously.</p> <p>Charging: In case of using charging line for charging, connect the headphone to the USB power. During charging, LED turns red. When charging is complete, the LED turns blue.</p>	<h3>How to wear</h3>  <p>Hang the headphone behind your neck with both speakers clinging to your cheekbones. After that, adjust it until you feel comfortable.</p> <h3>Attenions</h3> <ul style="list-style-type: none"> Please wear the bone-conduction speakers of the headphone at your cheekbones in front of your ears and do not put them in your ears. Listening to music for an excessive long time may make you feel uncomfortable, please try to use a medium volume instead of a big one. No matter how the volume is, please do not make it prevent you from hearing the surrounding sounds. Please take care when using the headphone. Do not throw, press the headphone or put it in the water. Keep the headphone away from fire, water and high voltage devices. It is not for children's use as it contains small parts. Please do not treat it as domestic waste. Instead, send it to the local electrical and electronic recycling station. If there is any injury or property loss due to violation of the above contents, we will not bear any responsibility. <h3>FCC Warning</h3> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>NOTE 1: The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio communications, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. <p>NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p>
---	--	--	---	--