

## Caution:

- This light panel is ideally used on smooth surfaces (e.g. glass, wood, etc); not suitable for uneven, bumpy or wet surfaces (e.g. brick, stucco, etc)
- Clean and ensure the surface is totally dry before sticking the light panel on.
- When installing the light panel, press its central point against the wall for more than 30s in order to maximize the adhesion.

## Safety Instructions

Read and follow all the safety instructions:

- The light panel is not waterproof. Avoid exposing it to splashing or dripping water.
- The operating temperature should be within -10° to 40°C (14° to 104°F).
- The light panel's internal light source cannot be replaced. If it breaks, you must replace it.
- Do not allow children to install the light panel alone.
- Avoid placing the light panel near heat sources.
- Do not install the light panel with a dimming driver.
- Avoid placing the light panel near potentially dangerous sources (e.g., candles, liquid-filled objects).


## Introduction

Thank you for choosing Govee Glide Triangle Light Panels! Let your creativity shine by designing beautiful patterns to decorate any wall in your home. Explore millions of flowing colors, dynamic scene modes, and effects that sync with your music. Govee Glide Triangle can bring you a brand-new visual experience.

## What You Get

Item	Quantity
Light Panel	10
Linking Cable	10
Control Box	1
Mounting Plate	10
Adhesive Tape	12
Adapter	1
Quick Start Guide	1
User Manual	1
Service Card	1

## At a Glance



Note: Ensure the mic is facing up during use.

## 01

What you need:

A Wi-Fi router supporting the 2.4GHz and 80.11b/g/n bands. 5GHz is not supported.

Pairing instructions

① Download the Govee Home app from the App Store (iOS devices) or Google Play (Android devices).

② Open the app, tap the "+" icon in the top right corner and search for "H6067".

③ Tap the device icon and follow the onscreen instructions to complete pairing.

## 02

## 03

## 04

## 05

## 06

## 07

## 08

## 09

## 10

## 11

## 12

## 13

## 14

## 15

## 16

## 17

## 18

## 19

## 20

## 21

## 22

## 23

## 24

## 25

## 26

## 27

## 28

## 29

## 30

## 31

## 32

## 33

## 34

## 35

## 36

## 37

## 38

## 39

## 40

## 41

## 42

## 43

## 44

## 45

## 46

## 47

## 48

## 49

## 50

## 51

## 52

## 53

## 54

## 55

## 56

## 57

## 58

## 59

## 60

## 61

## 62

## 63

## 64

## 65

## 66

## 67

## 68

## 69

## 70

## 71

## 72

## 73

## 74

## 75

## 76

## 77

## 78

## 79

## 80

## 81

## 82

## 83

## 84

## 85

## 86

## 87

## 88

## 89

## 90

## 91

## 92

## 93

## 94

## 95

## 96

## 97

## 98

## 99

## 100

## 101

## 102

## 103

## 104

## 105

## 106

## 107

## 108

## 109

## 110

## 111

## 112

## 113

## 114

## 115

## 116

## 117

## 118

## 119

## 120

## 121

## 122

## 123

## 124

## 125

## 126

## 127

## 128

## 129

## 130

## 131

## 132

## 133

## 134

## 135

## 136

## 137

## 138

## 139

## 140

## 141

## 142

## 143

## 144

## 145

## 146

## 147

## 148

## 149

## 150

## 151

## 152

## 153

## 154

## 155

## 156

## 157

## 158

## 159

## 160

## 161

## 162

## 163

## 164

## 165

## 166

## 167

## 168

## 169

## 170

## 171

## 172

## 173

## 174

## 175

## 176

## 177

## 178

## 179

## 180

## 181

## 182

## 183

## 184

## 185

## 186

## 187

## 188

## 189

## 190

## 191

## 192

## 193

## 194

## 195

## 196

## 197

## 198

## 199

## 200

</

## Troubleshooting

### ① Cannot connect to the Govee Home app.

- Check if the light panel is powered on.
- Check if Bluetooth on the smartphone is enabled, or try connecting with another smartphone.
- When connecting for the first time, ensure the smartphone is near the light panel.
- If the connection error still exists, please delete the connected light panel from "My Device" on the app. Reconnect to the Govee Home app by following the instructions provided previously.

### ② Wi-Fi disconnected or failed to connect.

- Check if the light panel is powered on.
- Do not skip the Wi-Fi connection steps during the light panel pairing process.
- Ensure your Wi-Fi router is 2.4GHz (5GHz is not supported).
- Ensure you entered the correct Wi-Fi password during the Wi-Fi set up process.
- Try connecting the light panel with a smartphone hotspot to check if your home network is working properly.
- Shorten the distance between the light panel and the Wi-Fi router to less than 1m, then reconnect.

### ③ Cannot connect to Alexa or Google Assistant.

- Ensure the Wi-Fi connection is stable and working properly.
- Go to "User Guide" on the app Settings page to pair the light panel again.

### ④ Can multiple users control one light panel.

- Each light panel can only be controlled by one account.
- If multiple users want to manage the same light panel, ensure they all use the same account.

## Customer Service

⌚ Warranty: 12-Month Limited Warranty

🔍 Support: Lifetime Technical Support

✉ Email: support@govee.com

🌐 Official Website: [www.govee.com](http://www.govee.com)

📺 @Govee

📷 @govee\_official

📠 @govee.official

🐦 @Goveeofficial

📠 @Govee.smarthome

## FCC and ISED Canada Statement

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil n'doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.



FOR INDOOR USE ONLY

POUR UNE UTILISATION EN INTÉRIEUR UNIQUEMENT

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.

2. Increase the separation between the equipment and receiver.

3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

4. Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-005.

Cet appareil numérique de la classe B est conforme à la norme NMB-005 du Canada.

## FCC and IC Radiation Exposure Statement

Govee

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

la distance entre l'utilisation et l'appareil ne doit pas être inférieure à 20 cm.

This device uses a non-replaceable light source. When the light source reaches the end of its life cycle, this device should be replaced. Not intended for illumination. Only use for creating ambience.

Responsible party :

Name: GOVEE MOMENTS(US) TRADING LIMITED

Address: 13013 WESTERN AVE STE 5 BLUE ISLAND IL 60462-448

Email: support@govee.com

Contact information: <https://www.govee.com/support>

## User Manual



Model: H6067

Govee G1617 Triangle Light Panels

H6067美版说明书

版本:1.0

料号:807-0003-00290

折叠尺寸:90×90 (mm)

展开尺寸:450×90 (mm)

材质:80G书页纸

工艺:单色印刷

折叠方式:风琴页

页数:10页