

正面

Smart Gateway

Mercü

GalaThings

© 2018 GalaThings Technology, Inc. All rights reserved.

Smart Gateway

- REQUIREMENTS:
Wi-Fi 802.11 a/b/g/n/ac 2.4/5GHz.
(WEP/WPA/WPA2 encryption supported)
- Dimensions:
2.5in x 2.5in x 2.4in Ring Base-2.2in x 2.2in x 0.32in
Weight: 120g Ring Base-34g
- AC Power adapter:
Input: 100-240V AC, 50/60HZ
Output: 5V DC, 2A



Mercu(SHC301)

What You'll Need:

- a. WiFi and broadband speed: 1Mbps upload at least
- b. A smartphone with iOS8 or later, or Android 4 or later
- c. Electrical outlet

Get Started

Power On Your Mercu

Step 1. Insert SD card into Mercu (smart gateway).

Step 2. Plug power adapter into electrical outlet

Step 3. LED color will turn blue when Mercu is ready to use.

Step 4. Download GalaThings App to manage your Mercu and account.

Download Mobile APP

Download GalaThings App from App Store or Google Play.



FCC ID: ZAQJEGC01



! Strangulation Hazard-Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3.ft(0.9m) away).

WARNING!!

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1) this device may not cause harmful interference, and

2) this device must accept any interference received, including interference that may cause undesired operation of the device.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body and this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

When using IEEE 802.11a wireless LAN, this product is restricted to indoor use, due to its operation in the 5.15 to 5.25GHz frequency range. The FCC requires this product to be used indoors for the frequency range of 5.15 to 5.25GHz to reduce the potential for harmful interference to co channel mobile satellite systems.

High-power radar is allocated as the primary user of the 5.25 to 5.35GHz and 5.65 to 5.85GHz bands. These radar stations can cause interference with and/or damage to this device.

背面

In the box

Mercu Orb

AC Adapter

Power Cable

Magnetic Ring Base

Wall Mount Holder

Quick Guide

Screws



wall screw x1 plastic anchor x1 holder screws x3

CAUTION

Be careful of sharp screws. Please keep the screws in the box before using. Handle with caution to avoid injury from sharp screw.

Get to know Mercu

Front

Camera

Smart color status LED

Magnetic Ring Base

Side

2W Speaker

Bottom

SD Card

Tripod Mount

! SD card must be installed in Mercu to activate the video recording.

Wall Mount Installation

Follow the steps


1 Use the plastic anchor and tighten the wall screw on the wall.

2 Install the Ring Base with the wall mount holder by holder screws.

3 Hook the wall mount holder with the screw.

4 Put Mercu on the Ring Base and adjust the view angle.

5 Change Mercu's direction without affecting its location.



More information at galathings.com/support

京寰科技 使用者說明書 銅版紙 90P