


F3-X Wireless Speaker User Manual

Congratulations on your purchase. Please read this manual carefully before using this speaker. Keep this manual for future reference.

What's in the box

Main unit
Micro USB cable
3.5mm audio cable.
User manual



1. Mode/Bluetooth Button

Press to switch between Bluetooth/Aux in Mode.
Press and hold to connect/disconnect Bluetooth device.

2. Back/Volume Down Button

Press: play the previous song
Press and Hold: Volume Down

3. Next/Volume Up Button

Press: play the next song
Press and Hold: Volume Up

4. Play/Pause/Phone Button

Press to pause playing, press again to resume.
Press to accept an incoming call.
Press and hold to decline an incoming call.

Charging the Speaker

When the battery runs low, the speaker will prompt a message "Low Battery". If it is not charged, it will power off automatically. Connect the USB cable between the charging socket on the speaker, and an USB socket on a computer, or a 5V output mobile phone charger.

Power On/Off

Push the "On/Off switch" to power On/Off the speaker.

Pairing with Bluetooth Device

Switch on the speaker, if it is used for the 1st time, the LED indicator will blink blue light fast and searching for Bluetooth devices. On your bluetooth device, enable Bluetooth and search for Bluetooth devices, when BTSPEAKER is found select it to start pairing and connection. The speaker will prompt a voice message "Bluetooth Paired Successfully" after paired.

For a paired Bluetooth device on which automatic re-connection is enabled, this speaker reconnects with it once it is detected.

To connect another Bluetooth device: Disable Bluetooth on the current device, the speaker will prompt a message "Bluetooth Disconnected" and search for other device, pair it with another device according to the steps show above.

Play from Bluetooth device

After connection, play audio on the Bluetooth

device. Audio streams from your Bluetooth device to the speaker.

Mode Switching

Bluetooth Mode

By default, the speaker will enter into this mode when power on, with a voice message "Bluetooth Mode".

Aux In Mode

When a 3.5mm audio plug is plugged in, the speaker will switch to Aux In mode automatically and prompt "Aux In" mode.

Press the Mode button to manually switch between Bluetooth Mode and Aux In Mode.

Receiving Call

If you get an incoming call when your smart phone is connected to the speaker, it will stop playing music, and playing a ring tone, press the Play/Phone button to receive the call, Press and hold to reject an incoming call. Press it again to hang-off the call. During a call press to end the current phone call.

Double press the Play/Phone button to call the last phone number

LED Indicator Light:

Blue light flashes slowly: working condition
Blue light flashes fast: Searching for Bluetooth devices or waiting for connection.

Red Light: Charging

Red light off: fully charged

Important Safety Instructions:

Read these instructions.

Do not use this apparatus near water.

Do not put this product in water or get wet, clean only with dry cloth.

Battery shall not be exposed to excessive heat, such as sunshine, fire or the like.

When the speaker is firstly used, or used for a long time, its battery may discharge gradually and automatically, so please recharge it before use or re-use.

Do not drop, beat, or shake this product strongly, otherwise it may damage the internal parts and the product.

Please keep this product and the accessories safely and avoid reaching by young children. The speaker may be slightly hot while it is under charging or playing.

Please avoid any metal items touching the speaker charging / audio sockets, so as to avoid damage to the speaker due to short circuits.

Unauthorized change and self-repair products may cause the speaker stop working.

Please use this product in accordance with local laws, regulations and restrictions. When under unauthorized situation, please stop using it and turn off your cell phone or other electronic equipment immediately e.g. the airplane takeoff/ landing or near a medical instrument.

FCC Statement:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.