

Test Setup photographs (PCB)

EUT Position: X-axis



EUT Position: Y-axis



EUT Position: Z-axis

