



<p>PRODA</p> <h2>WIRELESS EARPHONE</h2> <p>PD-BN200</p> <p>卡颈戴式无线运动耳机 说明书</p>	<p>安全事项</p> <p>为正确而安全地使用本耳机,请在使用前详细阅读本手册,并保存好。</p> <p>使用耳机时应注意下列事项:</p> <ol style="list-style-type: none"> 请合理使用耳机的音量和时间。 请勿在潜在危险环境中使用耳机,以确保安全。 尽量避免在驾驶途中使用耳机聆听音乐,拨打或接听电话,分散注意力造成危险。 请将耳机置于儿童无法接触到的地方,避免儿童使用不当造成危险。 在洗澡时应避免耳机进水,以免损害耳机音质或耳机。 应尽量避免持续高音量,导致你听不到周围的声音,如出现耳鸣或感觉音量过高,请调到合适音量。 如使用耳机时感到明显不适,有刺激感或其他不良反应,请立刻停止使用。 避免将耳机存储或使用于温度低于-10°C (14°F) 或高于50°C (122°F) 的环境,否则可能会缩短耳机或电池寿命。 	<p>技术规格</p> <p>蓝牙版本: V5.0 通信距离: 10米 接收灵敏度: -89dbm 工作频段: 2.4GHz 待机时间: (连接状态): 约60小时 通话时间: 约12小时 听歌时间: 约12小时</p> 	<p>耳机概况</p> <p>耳机说明 开机: 关机状态下;长按开关机键2秒 关机: 开机/配对连接状态;长按开关机键2-3秒 接听电话: 来电响铃中;单击开关机键1次 结束电话: 通话中;单击开关机键1次 重拨: 连接状态下;双击开关机键 通话时间: 来电响铃中;长按开关机键1.5秒松开 取消通话: 去电未接状态下;单击开关机键一次 播放音乐: 待机连接模式;单击开关机键 暂停音乐: 音乐播放中;单击开关机键 音量调节: 音乐播放中/通话中;单击音量加减键 切换上下曲: 音乐播放中;长按音量加减键1.5秒 (加: 上一曲; 减: 下一曲) 断开连接: 连接状态下;单击手机上对应配对名选择断开/长按开关机键3.5秒 回连: 关机状态下;长按开关机键1.5秒 (开机自动回连最后连接记录) 一拖二: (一耳机同时连两部手机): 已连接一部手机 关掉A手机蓝牙, 双击开关机键进入配对状态进行B手机连接, 再开启A手机的蓝牙功能自动连接 (部分手机需手动点击连接)</p>	<p>耳机概述</p> <p>断开耳机与手机蓝牙连接: 请采用以下任一方式。 关闭手机蓝牙功能。 长按耳机多功能键直到红灯亮1秒后熄灭, 耳机关机。 将耳机移到距离手机10米 (约30英尺) 或更远的位置。 将已配对的耳机重新连接至手机: 1.请将蓝牙耳机和手机 (或其他用作连接的设备) 的距离控制在1米范围内, 越近越好。 2.将耳机开机, 耳机进入回连模式, 此时白灯闪烁。 3.同时打开手机或其他所需连接的设备的蓝牙搜索功能, 蓝牙耳机会自动与上次连接的手机重新连接。 接听来电: 来电时, 当听到耳机提示音后, 短按一下多功能键, 接听来电; 或使用您的手机接听来电。 拒绝通话: 来电时, 当听到耳机提示音后, 双击多功能键, 通话便会被拒绝; 或使用您的手机进行拒接。 挂断电话: 正在通话时, 短按一下耳机的多功能键; 或使用手机挂断电话即可。</p>	<p>回拨电话: 待机状态下, 双击多功能键, 可自动回拨最近一次通话。 音乐播放/暂停: 短按一下多功能键可播放或暂停音乐。 音量调节及歌曲选择: 在音乐播放时, 短按音量 (+) / 音量 (-), 可调节音量大小; 长按音量 (+) 2秒, 切换下一曲 长按音量 (-) 2秒, 切换下一曲</p>	<p>常见问题</p> <p>1.PD-BN200不能与手机配对? 答: 请检查耳机是否处于配对或回连模式, 以及检查手机蓝牙搜索功能是否已打开; 并检查设备上的蓝牙菜单并删除其搜索名, 再说明将其重新连接。 2.PD-BN200耳机无法开机? 答: 请检查耳机的电量。 3.PD-BN200的耳机能否更换电池? 答: 不可以, 本耳机使用不可拆卸式锂聚合物电池。 4.开车时能否使用蓝牙耳机? 答: 出于安全考虑, 可在驾驶时使用通讯类耳机, 但不建议在驾驶途中使用头戴式耳机。 5.PD-BN200耳机与手机在10米断开连接? 答: 由于蓝牙是一种无线技术, 因此对耳机与已连接设备之间的物体很敏感。请检查在连接范围内是否有金属或其他影响连接的对象。 6.耳机连接计算机或手机后, 听不到声音? 答: 请检查计算机输出声道是否已设为蓝牙音频装置以及计算机的蓝牙是否支持A2DP协议, 并检查计算机/手机的音量。 7.蓝牙耳机与手机连接后, 可以用耳机控制手机上的应用程序吗? 答: 设备应用程序的软件设定或有所不同, 个别应用程序的功能不支持由耳机操控。</p>	
<p>PRODA</p> <h2>WIRELESS EARPHONE</h2> <p>PD-BN200</p> <p>KAMEN NECKBAND WIRELESS EARPHONE Instruction manual</p>	<p>Cautions</p> <p>To use the headphone properly, read this manual first. Keep this manual for future reference</p> <p>1. Do not listen to headphones for long hours. Listening at safe volume levels; 2. Do not use headphones in a potentially hazardous environment; 3. Do not use headphones to listen to music, make or receive calls while driving; 4. Keep the headphones out of the reach of children to avoid the danger caused by improper use of children; 5. Keep headphones away from water to avoid damaging the sound quality of the headphones; 6. It's dangerous that listening at high volume makes you not hear the sound around. If you have tinnitus or feel the volume is too high, adjust the volume to an appropriate level; 7. If you feel uncomfortable, irritation or any adverse reactions when using the headphones, stop using them immediately; 8. Avoid storing or using headphones at temperatures below -10°C (14°F) or above 50°C (122°F), which may shorten the headphone life or battery life;</p>	<p>7.Q: The PD-BN200 cannot be paired with a mobile phone? A: Since the software settings are different from device to device, the functions of some applications cannot be controlled by the headphone.</p> <p>Technical Specifications</p> <p>Bluetooth version: V5.0 Communication distance: 10 meters Receive sensitivity: -89dbm Working frequency band: 2.4GHz Standby time (link status): About 60 hours Talk time: about 12 hours Listening to song time: about 12 hours</p> 	<p>Introduction to Headphones</p> <p>Headphone instructions Power on: In the off state; long press the switch button for 2 seconds Shut down: Power on/matched connection status; long press the switch button for 2-3 seconds Answer the call: The caller rings; click the switch button once End the call: During the call; click the switch button once Redial: In the connected state; double-click the switch button Reject the call: The caller rings; press and hold the switch button for 1.5 seconds to release Cancel the call: When the power is off, click the switch button once. Play music: Standby connection mode; click on the switch button Pause music: During music playback; click on the switch button Volume adjustment: during music playback/calling; click volume plus or minus button Switch the top and bottom: Music playback; long press the volume plus or minus button for 1.5 seconds (plus: previous song; minus: next song) Disconnect: In the connected state; click the corresponding pairing name on the phone to select the disconnect/long press the switch button for 3.5 seconds. Back connection: In the off state; long press the switch button for 1.5 seconds (automatically return to the last connection record)</p>	<p>One for two (one headset with two phones at the same time): A mobile phone is connected Turn off the A mobile phone Bluetooth, double-click the switch button to enter the pairing state to connect the B phone, then turn on the A The Bluetooth function of the phone is automatically connected (some phones need to be manually clicked) Reconnect the paired headset to your phone: 1.Make the BT headphone as closer as possible to your phone (or other device used for connection) within 1 meter. 2.Turn on the headphone, and it enters reconnection mode. The white indicator flashes; 3.Turn on the BT function of your phone (or other device used for connection). The headphone will automatically reconnect with the previously connected phone; Answer call: When you hear a prompt tone, click MFB Button to answer the incoming call. Or answer it through your phone; Reject call: When you hear a prompt tone, double-click MFB Button to reject the incoming call. Or reject it through your phone; Hang up: Click MFB Button to hang up on the on-going call. Or hang up through your phone.</p>	<p>Headset overview</p> <p>To disconnect your phone from the headphone, try one of the following methods: Press and hold MFB Button until the red indicator is on for 1 second, and then the headphone is turned off; Keep the headphone at least 10 meters (approx. 30ft) away from your phone. Reconnect the paired headset to your phone: 1.Check the remaining battery. In standby mode, double-click MFB Button to redial the last called number. Play/pause: Click MFB Button to play or pause the music. Volume and song: When playing music, click Volume + Button / Volume - Button to adjust the volume. Press and hold Volume (+) Button for 2 seconds to go to the previous track. Press and hold Volume (-) Button for 2 seconds to go to the next track</p>	<p>Q & A</p> <p>1.Q: The PD-BN200 cannot be paired with a mobile phone? A: Please check if the headphone is in the pairing or connection mode. Check if the phone's BT function is turned on. Delete "PD-BN200" on the BT menu of your device and then follow the instructions to connect the headphone one more time. 2.Q: The PD-BN200 cannot be turned on? A: Check the remaining battery. 3.Q: Is the PD-BN200's battery replaceable? A: No. This headphone uses a non-removable lithium polymer battery. 4.Q: Can I use the BT headphone when I'm driving? A: Use a communication headphone while driving. It is not recommended to use an over-ear headphone or on-ear headphone. 5.Q: Is the PD-BN200 disconnected from the phone at 10 meters? A: Since BT is a wireless technology, it is sensitive when objects are between the headphone and the connected device. Check if there are metals or any other objects that affect the connection within the connection range. 6.Q: After the headphone is connected to the computer or mobile phone, I can't hear any sound? A: Check if the computer's output channel is set to BT audio device and whether the computer's BT supports A2DP protocol. Check the volume of the computer/phone.</p>	

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.