

国纸类别	产品说明书	物料编码	1.D001.0013		
产品型号	S67L	规格	60*120mm/P	设计	
版本	S67L-1	文件类型	受控文件	审核	
材质工艺	128g铜版纸, 4C, 双面印刷, 风琴折			批准	
备注	1、电池描述由: 4900mAh 改成: 4900mAh(5000mAh Typical) 2、SAR:at 10mm from the body改成: 5mm				

en

Thank you for choosing FOXOX. Please follow the provided instructions when using this product.

Product Safety Information

- Do not use while re-charging.
- Do not use hand-held while driving.
- This device may produce a bright or flash light.
- For body-worn operation, maintain separation of 5 mm.
- Do not dispose of the phone in a fire.
- Small parts may cause a choking hazard.
- Avoid contact with magnetic media.
- This device may produce a loud sound.
- To prevent possible hearing damage, do not listen at high volume levels for long periods.
- Avoid extreme temperatures.
- Keep away from pacemakers and other personal medical devices.
- Avoid any contact with liquid. Keep it dry.
- Switch off when instructed in hospitals and medical facilities.
- Do not attempt to disassemble your phone.
- Switch off when instructed in aircraft and airports.
- Do not rely on this device for emergency communications.
- Switch off in explosive environments.
- Only use approved accessories.

What's in the Box

The phone packaging box should contain the following items and accessories:

- Phone Charger, USB Type-C cable, Protective film (applied), SIM card tool, Phone case, and Quick Start Guide.

Notices on Using Your Phone

Your phone should be treated with care. The following suggestions can help you extend the life of your mobile phone.

- Place the mobile phone and its parts and components out of reach of young children.
- Keep the phone dry. Rain, humidity and all types of liquids which contain minerals will corrode electronic circuits.
- Don't touch the phone with wet hands when charging. It will cause an electric shock or damage the phone.
- Avoid placing the device in high temperature environments. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Avoid placing the device in a low temperature environment. When the temperature rises, the phone will produce water vapor that may damage electronic circuits.
- Avoid placing the phone in dusty, dirty places, otherwise parts may be damaged.
- Avoid placing the phone near a lit cigarette, open flame or any heat source.
- Do not drop, knock or shake the phone. Rough handling can damage internal circuit boards.
- Do not paint the phone. The paint may block headphones, microphones or other removable parts, and cause them not to work.
- Use a clean, soft, dry cloth to clean the camera, light sensor lenses. Prohibit the use of harmful chemicals and cleaning agents to clean the phone.
- Pacemaker manufacturers recommend that a minimum separation of 5mm be maintained between a mobile phone and a pacemaker to avoid a potential interference with the pacemaker (when the device is used in the USA, the separation distance can be maintained at 10mm between users' body and handset). To achieve this use the phone on the opposite side.

Getting to Know Your Phone

Before Getting Started

Installing SIM Cards

Insert a SIM tool into the small hole to eject the SIM tray.

Installing a microSD Card (Not Included)

Please insert the microSD card with the gold contact facing down on the SIM tray. Push the SIM tray back in until it clicks into place and is flush with the side of the device.

Display

- Brightness:** Adjust the screen brightness.
- Lock display:** Lock screen. Customize what is shown on the lock screen. Screen timeout. Adjust the time allowed before the screen goes to sleep after inactivity.
- Appearance:** Dark theme. Turn on/off the dark background. Font size. Set the font size of the system. Display size. Set the display size of the screen.
- Other display controls:** Auto-rotated screen. Swipe to turn on or off. Screen saver. Choose the screen saver and when to start.

System

- Languages and input:** 1. You can set up all the languages supported by the phone. 2. Keyboards. You can set on-screen keyboard or physical keyboard.
- Date and time:** 1. Set time automatically. Swipe right to use date and time provided by network. 2. Time zone. You can choose to use the time zone provided by the network or use your location to set the time zone. 3. Time format. You can choose to use the local default time format or to use the 24-hour format.

About phone

Here you can check out the basic information device name, phone number, legal information and device details, including SIM status, memory/storage information, operation system, IP address, up time, build number, etc.

Technical Specifications

- Network: 2G: B2/B3/B8; 3G: B2/B3/B8; 4G: B2/B3/B7/B25/B26/B28/B40/B46/B71; 5G: N25/N71/N25/B26/B46/B71/77/78
- Display: 6.7"
- Memory: 3GB RAM+32GB ROM
- Camera: 13MP+CA&MP
- PM/MP& MP& GPS/GPS sensor
- Battery Capacity: 4900mAh(5000mAh Typical) Li-ion

(Note: The storage capacity actually available in the units internal memory may be less due to the pre-installed operating system and/or other pre-installed or configured applications. Check the space actually available on your computer.)

FCC Warning

15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.10 Information to the user.

Note: This equipment has been tested and found to comply with the limits for Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference, which can be determined by turning the equipment off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device was tested for typical body-worn operations with the back of the device kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an appropriate separation distance between the user's body and the back of the device. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

Device types smartphone FCC ID: 24Q6M-S67L has also been tested against this SAR limit. The highest SAR value for this mobile phone tested is 1.04W/kg against the head and 1.18W/kg at 10mm from the body.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Manufacturer: Fox Development Inc.
3480 Preston Ridge Road, Suite 500, Alpharetta, GA 30005

Information for auxiliary equipment

Battery	
Model	BLG01
Capacity	18.96Wh
Manufacturer	SHEN ZHEN JIAJINYUAN TECHNOLOGY CO., LTD.
Address of Manufacturer	Building A3, Fuying Second Industrial Zone, Jiamen Road, Zhancheng, Fuhai, Baoan, Shenzhen, Guangdong, P.R.China

WEEE Recycling

This product should not be treated as household waste. Instead, it should be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

GPS/GLONASS

Operation Frequency	
Band 2	1559MHz-1610MHz
Band 11	1559MHz-1610MHz

Google is a trademark of Google LLC.

es

— Gracias por elegir el FOXOX. Siga las instrucciones cuando comience a usar este producto.

Información sobre la seguridad del producto

- No usar mientras está cargando.
- No use cuando está conduciendo sin sistema manos libres.
- Este dispositivo puede emitir una luz brillante o intermitente.
- Para el funcionamiento corporal, mantenga una aspiración de 5 mm.
- No tire el teléfono al fuego.
- Contiene piezas pequeñas que pueden suponer riesgo de asfixia.
- Evite el contacto con imanes.
- Este dispositivo puede crear un sonido alto.
- Para evitar posibles daños auditivos, no escuche a un nivel de volumen alto durante períodos prolongados.
- Evite las temperaturas extremas.
- Mantenga alejado de marcapasos y otros dispositivos médicos personales.
- Evite el contacto con líquidos. Manténelo seco y personal.
- Apague cuando se le indique en hospitales y instalaciones médicas.
- No intente desarmar su teléfono.
- Apague cuando se le indique en aeropuertos y aviones.
- No dependa de este dispositivo para las comunicaciones de emergencia.
- Apague cuando estas en ambientes explosivos.
- Use solamente accesorios aprobados.

Qué hay en la caja

La caja de embalaje del teléfono debe contener los siguientes artículos y accesorios:

- Teléfono, cargador, cable USB tipo C, película protectora (aplicada), herramienta de tarjeta SIM, funda del teléfono, y guía de inicio rápido.

Avisos sobre el uso de su teléfono

su teléfono debe tratarse con cuidado. Las siguientes sugerencias pueden ayudarlo a prolongar la vida útil de su teléfono móvil.

- Coloque el teléfono móvil y sus partes y componentes fuera del alcance de sus hijos pequeños.
- Mantenga el teléfono seco. La lluvia, la humedad y todo tipo de líquidos que contengan minerales corroerán los circuitos electrónicos.
- No toque el teléfono con las manos mojadas mientras lo carga. Causará una descarga eléctrica o dañará el teléfono.
- Evite colocar el teléfono en entornos de alta temperatura. Cuando la temperatura aumenta, el teléfono producirá vapor de agua que puede dañar los circuitos electrónicos.
- Evite colocar el teléfono en lugares poco ventilados y sucios.
- Evite colocar el teléfono cerca de un cigarrillo encendido, una llama abierta o cualquier fuente de calor.
- No deje caer, golpear ni agitar el teléfono. Un manejo brusco puede dañar las placas de circuito interno.
- No pinte el teléfono. La pintura puede bloquear los auriculares, micrófonos u otras piezas extraíbles y hacer que no funcionen.
- Utilice un paño limpio, suave y seco para limpiar la cámara y las lentes del sensor de luz. Prohíba el uso de productos químicos tóxicos y agentes de limpieza para limpiar el teléfono.
- Los fabricantes de marcapasos recomiendan que se mantenga una separación mínima de 5 mm entre el teléfono móvil y un marcapasos para evitar una posible interferencia con el marcapasos cuando el dispositivo se use en EE. UU. la distancia de separación se puede mantener en 10 mm entre el cuerpo del usuario y el teléfono).

Conozca su teléfono

Antes de empezar

Instalación de tarjetas SIM

Inserte una herramienta SIM en el pequeño orificio para expulsar la bandeja SIM.

Instalación de la tarjeta microSD (no incluida)

Empuje la bandeja SIM hacia adentro hasta que encaje en su lugar y quede al ras con el costado del dispositivo.

Monitor

- Nivel de brillo:** Ajuste el brillo de la pantalla.
- Pantalla de bloqueo:** Pantalla de bloqueo. Se ha personalizado lo que se muestra en la pantalla de bloqueo. Tiempo de espera de la pantalla. Ajuste el tiempo permitido antes de que la pantalla entre en reposo después de estar inactiva.
- Apariencia:** Tema oscuro. Desactiva el fondo oscuro. Tamaño de fuente. Establezca el tamaño de fuente del sistema. Tamaño de pantalla. Establezca el tamaño de visualización de la pantalla.
- Otros controles de pantalla:** Girar automáticamente la pantalla. Desliza el dedo para activarla o desactivarla. Protector de pantalla. Elija el protector de pantalla y cuándo colocarlo.

Sistema

- Idiomas y entradas:** 1. Puede configurar todos los idiomas admitidos por el teléfono. 2. Teclado. Puede configurar el teclado en pantalla o el teclado físico.

15.21 Información al usuario.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.10 Información al usuario.

Note: Este equipo ha sido probado y cumple con los límites para un dispositivo digital de Clase B, de conformidad con la parte 15 de las Reglas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias dañinas en una instalación residencial. Este equipo genera uso y puede irradiar energía de radiofrecuencia, y si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencias dañinas en las comunicaciones por radio. Sin embargo, no hay garantía de que no se produzcan interferencias en una instalación en particular. Si este equipo causa interferencias dañinas en la recepción de radio o televisión, lo cual se puede determinar apagando y encendiendo el equipo, se recomienda al usuario que intente corregir la interferencia mediante una o más de las siguientes medidas:

- Reorientar o reducir la antena receptora.
- Aumentar la separación entre el equipo y el receptor.
- Conectar el equipo a una toma de corriente en un circuito diferente al que está conectado el receptor.
- Consulte al distribuidor o a un técnico experimentado en radio/TV para obtener ayuda.

Advertencia de la FCC

Este dispositivo cumple con la parte 15 de las Reglas de la FCC. El funcionamiento está sujeto a las dos condiciones siguientes: (1) Este dispositivo no puede causar interferencias dañinas y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluidas las interferencias que pueden causar un funcionamiento no deseado.

15.19 Requisitos de etiquetado.

Este dispositivo cumple con la parte 15 de las Reglas de la FCC. El funcionamiento está sujeto a las dos condiciones siguientes: (1) Este dispositivo no puede causar interferencias dañinas y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluidas las interferencias que pueden causar un funcionamiento no deseado.

Precaución: Riesgo de explosión si la batería se reemplaza por un tipo incorrecto. Deshée las baterías usadas DE ACUERDO CON LAS INSTRUCCIONES.

Manufacturer: Fox Development Inc.
3480 Preston Ridge Road, Suite 500, Alpharetta, GA 30005

Información para equipos auxiliares

Batería	
Model	BLG01
Capacidad	18.96Wh
Potencia nominal	SHEN ZHEN JIAJINYUAN TECHNOLOGY CO., LTD.
Dirección del fabricante	Edificio A3, Zona Industrial Fuying Segunda Calle Jiamen, Zhancheng, Fuhai, Baoan, Shenzhen, Guangdong, P.R.China

Reciclage de RAEE

Este producto no debe tratarse como residuo doméstico. En su lugar, debe entregarse en el punto de recogida correspondiente para el reciclaje de aparatos eléctricos y electrónicos.

WCDMA

Frecuencia de funcionamiento	
Band 2	1559MHz-1610MHz
Band 4	1559MHz-1610MHz
Band 5	1559MHz-1610MHz
Band 8	1559MHz-1610MHz

LTE

Frecuencia de funcionamiento	
Band 2	1559MHz-1610MHz
Band 4	1559MHz-1610MHz
Band 5	1559MHz-1610MHz
Band 8	1559MHz-1610MHz

5G

Frecuencia de funcionamiento	
Band 2	1559MHz-1610MHz
Band 4	1559MHz-1610MHz
Band 5	1559MHz-1610MHz
Band 8	1559MHz-1610MHz

FM

Frecuencia de funcionamiento	
Band 2	1559MHz-1610MHz
Band 4	1559MHz-1610MHz
Band 5	1559MHz-1610MHz
Band 8	1559MHz-1610MHz

Google es una marca de Google LLC.