


**GUIDE DE
DÉMARRAGE
RAPIDE**



**QUICK
START
GUIDE**

Welcome!

Bienvenue!



1 **Get started**

- Download the **Globe Suite™** app from the App Store or Google Play to your mobile device.
- Launch the **Globe Suite™** app.
- To register, enter your email address. Create a password, then login to the app.

OR

- Login if you already have an account.



Pour commencer

- Téléchargez l'application **Globe Suite™** sur un appareil mobile à partir de l'App Store ou de Google Play.
- Lancez l'application **Globe Suite™**.
- Entrez votre adresse courriel pour s'inscrire. Créez un mot de passe et se connecter à l'application.
- ou
- Se connecter à l'application avec un compte existant.




2 **Verify your network**

- Verify your network and ensure your mobile device is connected to a 2.4 GHz Wi-Fi channel.
- Consult your router documentation for detailed instructions on how to change wireless settings.
- Once your devices have been successfully paired, you can switch back to mixed mode or use a cellular data network to control your smart products.

- Vérifier le réseau Wifi et s'assurer que l'appareil mobile est connecté à un canal sur la bande 2,4 GHz.
- Consulter la documentation qui accompagne le routeur pour des instructions détaillées sur la façon de modifier les paramètres sans fil.
- Une fois que vos appareils ont bien été couplés, vous pouvez revenir en mode mixte ou utiliser un réseau de données cellulaires pour contrôler vos appareils intelligents.

2 **Vérification du réseau**



3a *Ajoutez un appareil*

- Allumez votre appareil.
- Sélectionnez le symbole « + » dans le coin supérieur droit.
- Choisissez votre type de produit et suivez les instructions dans l'appli.
- Si la connexion ne marche pas, essayer mode AP.

3b *mode AP*

- Sur la page de «Ajoutez un appareil» sélectionnez mode AP en haut à droite et suivez les instructions dans l'appli.
- Vous êtes prêts à commencer!

3c *mode Balayage*

- Sélectionnez le symbole "+" dans le coin supérieur droit
- Sélectionnez « Balayage ».
- Suivez les instructions dans l'application.
- Vous êtes prêt à commencer!

3a *Add a device*

- Power on your device.
- Select the "+" symbol on the top right hand corner.
- Select your product type and follow the instructions within the app.
- If the connection fails, try using AP mode.

3b *AP mode*

- On the "add a device" page select AP mode on the top right-hand corner and follow the instructions within the app.
- If the connection fails, try using Scan mode.


3c *Scan mode*

- Select the "+" symbol on the top right hand corner.
- Select "Scan".
- Follow instructions within the app.
- You're good to go!



Configurez votre assistant vocal

- Les instructions dans l'application **Globe Suite^{MC}** : Sélectionnez « Profil », sélectionnez « Intégration », choisissez votre assistant vocal et suivez les instructions.



4 Setup voice assistance

- Instructions in the **Globe SuiteTM** app:
Select "Profile", select "Integration", choose your voice assistant, and follow instructions.

Le saviez-vous?

La plupart des routeurs modernes sont **bibandes**, ce qui signifie qu'ils peuvent diffuser à la fois aux fréquences 2,4 GHz et 5 GHz.

Voici les options de réseau sans fil les plus courantes:

- **Mixtes** : Le routeur diffuse simultanément aux fréquences 2,4 GHz et 5 GHz sous le même

identifiant SSID. L'appareil choisit la fréquence à utiliser en fonction de diverses variables (encombrement du réseau, distance du routeur, etc.).

- **2,4 GHz** : Le routeur diffuse uniquement à cette fréquence.

- **5 GHz** : Le routeur diffuse uniquement à cette fréquence.

- **Bandes 2,4 et 5 GHz pour des SSIDs séparés** :

Le routeur diffuse aux deux fréquences et l'utilisateur décide manuellement de la fréquence à utiliser.

Did you know?

Most modern routers are dual band meaning they support both 2.4 GHz and 5 GHz channels.

The most common wireless options are:

- **Mixed:** The router will broadcast both 2.4 GHz and 5 GHz simultaneously under the same SSID. The device will choose which to connect to based on multiple variables (congestion, distance to router etc.).

- **2.4 GHz:** Broadcast only on this channel.

- **5 GHz:** Broadcast only on this channel.

- **Dual 2.4 and 5 GHz using Separate SSIDs:**

Router will broadcast both channels and the user manually decides which to connect to.

***Have a question?
We can help!***



www.globe-electric.com/smart



smartsupport@globe-electric.com



Visit the FAQ page in the app



Check us out on YouTube



scan me

Globe Electric Company 34921*_QSG 10-093-20

***Des questions?
Nous pouvons vous aider!***



www.globe-electric.com/smart



smartsupport@globe-electric.com



Consultez la FAQ dans l'application.



Suivez-nous sur YouTube.



Balayer-moi

Compagnie Globe Electrique