

# Caltta Z9 U(1)

## Quick Start Guide Digital Handheld Terminal

## LEGAL INFORMATION

### Copyright© CALTTA TECHNOLOGIES CO.,LTD.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of CALTTA TECHNOLOGIES CO.,LTD.



### Violators Will Be Prosecuted.

CALTTA TECHNOLOGIES CO.,LTD. reserves the right to make modifications on typographical errors or update specifications in this guide without prior notice.

The figures in this manual are for reference only. For the product structure and specifications of the battery and charger, refer to the actual product. The accessories provided with the product may vary with product models and functions.

## Get to Know Your Z9 U(1)

### Components



### Programmable Keys

To facilitate operations, your Z9 U(1) provides three programmable keys (Side key 1, Side key 2, and the Top key), and each programmable key can be assigned with one of the following functions by the product distributor through programming.

| No. | Function             | Description  |
|-----|----------------------|--|
| 1   | Call release         | Releases an ongoing call or stops establishing a call. |
| 2   | Keypad lock          | Locks or unlocks the keypad immediately.               |
| 3   | Power level          | Adjusts the transmit power level quickly.              |
| 4   | Private call contact | Opens the private call contact list directly.          |
| 5   | Group call contact   | Opens the contact list of a contact group directly.    |
| 6   | Call logs            | Opens the Call Logs menu directly.                     |
| 7   | Work mode            | Opens the Work Mode menu directly.                     |
| 8   | Hunt                 | Opens the Hunt menu directly.                          |
| 9   | Manual Hunt          | Restarts scanning and registration                     |
| 10  | BKG Hunt             | Enables or disables BKG Hunt.                          |

### LED indicator

The LED indicator indicates the operating status of the Z9 U(1).

| Indicator       | Z9 U(1)  |
|-----------------|--|
| Lit green       | Your Z9 U(1) is receiving voice signals.   |
| Lit red         | Your Z9 U(1) is transmitting voice signals.  |
| Flashing orange | Your Z9 U(1) is in Hunt status.  |
| Lit orange      | After a call is established, there is no voice transmitted or received in the service channel. You can press the PTT key to initiate a call. |

### NOTE:

The functions of a programmable key may vary with the operation (press or press and hold). For details, contact the local distributor.

## Status Indication

### LCD icons

The following icons may be displayed on the LCD.

| Name            | Icon         | Status   |
|-----------------|--------------|--|
| Signal strength | 1 bar        | No signal  |
|                 | 4 bars       | The more the signal bars are, the stronger the signals are.              |
| Message         | Message icon | SMS message unread   |
|                 | Message icon | The message box is full.   |
| Hunt            | Circle icon  | Your Z9 is in Hunt status. This icon is not displayed in BKG Hunt.       |
|                 | Circle icon  | Your Z9 is in roaming status.  |
| Transmit power  | L icon       | The current channel transmits signals in low power.                      |
|                 | H icon       | The current channel transmits signals in high power.                     |
| Battery level   | 2/4 bars     | The longer the battery progress bar is, the higher the battery level is. |
| Speaker         | Speaker icon | The speaker is on.   |

### LED indicator

The LED indicator indicates the operating status of the Z9 U(1).

| Indicator       | Z9 U(1)  |
|-----------------|--|
| Lit green       | Your Z9 U(1) is receiving voice signals.   |
| Lit red         | Your Z9 U(1) is transmitting voice signals.  |
| Flashing orange | Your Z9 U(1) is in Hunt status.  |
| Lit orange      | After a call is established, there is no voice transmitted or received in the service channel. You can press the PTT key to initiate a call. |

### NOTE:

After your Z9 U(1) is powered on and registered, you can select a group contact through one of the following three ways:

## Basic Operations

### Power On/Off Your Z9 U(1)

To power on your Z9 U(1), turn the **Power/Volume knob** clockwise until a click is heard.

To power off your Z9 U(1), turn the **Power/Volume knob** counterclockwise until a click is heard.

### Turn Up/Down the Volume

After powering on your Z9 turn the **Power/Volume knob** clockwise to turn up the volume, and turning the **Power/Volume knob** counterclockwise to turn down the volume.

### Select a Group

You can add contacts in one group to manage the contacts efficiently. Your Z9 U(1) supports up to 32 groups. One group contains up to 32 contacts.

You can select a group through one of the following ways:

#### • Menu

Press the **OK/Menu** key, select **Subgroup** from the displayed menu, press the **Up** or **Down** key to select a group as required. After entering the group, select **Set Default**, and press the **OK/Menu** key.

#### • Shortcut key

When the homescreen is displayed, press the **Group call management** key to open the **Subgroup** menu, and then repeat the above operations.

#### • NOTE:

By default, your Z9 U(1) has one group list in which you can add 32 group contacts.

### Select a Group Contact

The functions of a programmable key may vary with the operation (press or press and hold). For details, contact the local distributor.

### NOTE:

If there is no **Keypad lock** in the **Radio Setting** menu, you can ask your distributor to set the automatic keypad lock function.

| No. | Name                    | No. | Name          |
|-----|-------------------------|-----|---------------|
| 1   | Group call /Volume knob | 13  | Down key      |
| 2   | Microphone              | 14  | BATT CLIP     |
| 3   | LCD                     | 15  | LED indicator |
| 4   | OK/Menu key             | 16  | PTT key       |
| 5   | Call/Answer key         | 17  | Side key 1    |
| 6   | Digit keypad            | 18  | Side key 2    |
| 7   | Back Speaker            | 19  | Top Speaker   |
| 8   | Antenna                 | 20  | Top key       |
| 9   | Accessory interface     | 21  | Push button   |

# Call

To ensure that the called party can hear you the best, keep the microphone 2.5 cm to 5 cm away from your mouth.

## Private Call

### Initiate a private call

You can initiate a private call through one of the following ways. Your Z9 U(1) plays a prompt tone before the called party answers the call.

- Initiate the call through **Contacts** or **Call Logs**

1. Press the **OK/Menu** key to enter the home menu.

2. Select **Contacts > Private Contact**, or select **Call Logs** to display **Outgoing** calls, **Incoming** calls, or **Missed** calls.

3. Press the **Up** or **Down** key to select the contact that you want to call.

4. Press the **PTT** key to initiate the private call.

- Dial the number that you want to call

1. When the home screen is displayed, enter the private number that you want to call.

2. Press the **Call/Answer** key, **PTT** key, or the **#** key to initiate the call.

- Initiate a call in **Missed calls**

In the **Missed** calls menu, select a missed call, and press the **Call** key or **PTT** key to initiate the call.



If your Z9 U(1) is not registered or fails in registration, no call can be initiated.

### Answer a private call

After receiving a private call, your Z9 U(1) plays a prompt tone. If you press the **Call/Answer** key or **PTT** key within the preconfigured duration, the call is answered. Your Z9 U(1) emits

an announcement. If the call is not answered, the icon is displayed on the LCD to notify you that you missed a call.

### End a private call

To end a private call, press the **Hook** key.



A private call can be ended by the calling or called party.

## Group Call

### Initiate a group call

You can initiate a group call through one of the following ways:

- Initiate a group call to a preset group contact

When the home screen is displayed, press the **PTT** key to initiate a group call to the group contact preset for the **Group call selection knob**.

- Through the address book in groups

1. On the home screen, press the **OK/Menu** key and select **Subgroup**, or press the **Group call management** key to enter the **Subgroup** menu.

2. Select **Members**, and press the **Up** or **Down** key to select the contact that you want to call.

3. Press the **Call/Answer** key or **PTT** key to initiate the group call.

- Dial the number that you want to call

1. On the home screen, enter the group call number that you want to call.

2. Press the **Call/Answer** key, **PTT** key, or **#** key to initiate the group call.

### Answer a group call

The Z9 U(1) answers a group call automatically. When a group call is answered, your Z9 emits an announcement.

### Answer a call in delay

After a group call is established, a member who did not answer the call immediately can join in the group call during the call.

## End a group call

Press the **Hook** key to end the group call.



Only the calling party can end a group call.

## GPS:

Press the **OK/Menu** key, select **Accessories** from the menu, and press the **Up** or **Down** key to select **Positioning**.

## BT:

Press the **OK/Menu** key, select **Accessories** from the menu, and press the **Up** or **Down** key to select **Bluetooth**.

Your CALTTA TECHNOLOGIES CO.,LTD. 2-way radio complies with the following RF energy exposure standards and guidelines:

- United States Federal Communications Commission, Code of Federal Regulations; 47 CFR §§ 1.1307, 1.1310, 2.1091 and 2.1093.

• American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95.1-1992.

• Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition.

Operation is subject to the following two conditions: 1. This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation.

Note: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Compliance with RF Exposure Standards

Your CALTTA TECHNOLOGIES CO.,LTD. 2-way radio is designed and tested to comply with a number of national and international standards and guidelines (listed below) for human exposure to radio frequency electromagnetic energy. This radio complies with the IEEE and ICNIRP exposure limits for occupational/controlled RF exposure environment at operating duty factors of up to 50 % transmitting and is authorized by the FCC for occupational use only. In terms of measuring RF energy for compliance with the FCC exposure guidelines, your radio radiates measurable RF energy only while it is transmitting (during talking), not when it is receiving (listening) or in standby mode. Note: The approved batteries supplied with this radio are rated for a 5-5-90 duty factor (5% talk-5% listen 90% standby), even though this radio complies with the FCC occupational RF exposure limits and may operate at duty factors of up to 50 % talk.

- Hold the radio in a vertical position in front of face with the microphone (and the other parts of the radio, including the antenna) at least one inch (2.5 cm) away from the nose. Keeping the radio at the proper distance is important because RF exposures decrease with distance from the antenna. Antenna should be kept away from eyes.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct:

- When worn on the body, always place the radio in a CALTTA TECHNOLOGIES CO.,LTD. approved clip, holder, holster, case, or body harness for this product. Using approved body-worn accessories is important because the use of CALTTA TECHNOLOGIES CO.,LTD. or other manufacturer's non-approved accessories may result in exposure levels, which exceed the FCC's occupational/controlled environment RF exposure limits.

• Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions: 1. This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation.

Note: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Operating Instructions:

### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct:

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions: 1. This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation.

Note: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.