


Product Instruction

1. Inventory :

x1
USB cable x1
Adaptor x1
Specification x1
product instruction x1

2. Key Interface Description :



1. Power port (Micro USB)

2. Power switch

3. Cashbox interface (RJ12)

Note: the money box must be equipped with a micro switch, and the micro switch is normally closed. Special note: the money box must be equipped with a micro switch, and the micro switch is normally closed.

4. Communication mode select key

WIFI/Bluetooth

5. Configuration key


Only WIFI mode is effective.

6. Power Light

- Bright : Starting up
- Not bright : Shutdown
- 7. Money box indicator light
 - Bright : The box open
 - Not bright : The box cloth
- 8. Communication light
 - WIFI mode Bright : connected; Glitter : ununited ; fast blink : Configuration state
 - BT mode Bright : onnected ; Glitter : ununited

3. Operating Instructions :

1. Connection method : Panel computer-TPT-200-cashbox



2. Open the APP on the tablet and select the same communication mode as the target TPT200 (WIFI mode requires the TPT200 and the tablet to be on the same network segment), click Search, the device list displays all the TPT200 products found, select the target device, and establish a connection. Press the unlock button and the cash box opens.
3. WIFI configuration: The communication mode selection button is switched to the WIFI gear position, press the configuration button to enter the configuration state. At this time, the indicator light flashes rapidly, the tablet APP selects the WIFI mode, enters the configuration page, fills in the WIFI user name and password, and sends the indicator light. It is always on and the configuration is successful.

4. FCC Compliance

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The distance between user and products should be no less than 20cm.