


封面



封面的下一页




目录1

Table of Contents	
目录/目次/Onnanew/목차	
Pairing Tutorial.....01	配对教程.....01
Check Battery Status.....02	电量查看.....02
Volume Sync (Important).....03	音量同步 (重要).....03
Dual Device Connection.....04	双设备连接.....04
Wearing Instructions.....05	佩戴说明.....05
Operation Instructions.....06	操作说明.....06
Important Notes.....07	重要事项.....07
Battery Warning.....08	电池警告.....08

目录2

1. 配对教程.....01	2. 电量查看.....02	3. 音量同步 (重要).....03	4. 双设备连接.....04	5. 佩戴说明.....05	6. 操作说明.....06	7. 重要事项.....07	8. 电池警告.....08
----------------	----------------	---------------------	-----------------	----------------	----------------	----------------	----------------
























































封底的上一页



封底



物料编码: LKP01026A		表面工艺: ①单黑印刷, ②骑马钉(双钉68p), ③啤,	
物料名称: LinkLike Ringstar air耳机(线下说明书)		印刷颜色: K	
结构部分	材 质:	银米样合100克白双胶纸	单 位: mm
	成型尺寸:	75*75mm	刀 线:
	结构设计:		压 线: - - - - -
	结构修改:		针刀线: - - - - -
	日 期:		刀线相交: - - - - -
备 注: 特别注意事项		坑 坑:	备 注:
特别说明: 所有物料需要符合蓝禾《有害物质限用管理程序》LH-WI-0004 (环保要求)			



LINKLIKE

User Manual




Table of Contents

目录/目錄/目次/Оглавление/목차

EN

Pairing Tutorial	01
Check Battery Status	01
Volume Sync (Important)	02
Dual Device Connection	03
Wearing Instructions	04
Operation Instructions	05
Earbuds Indicator Light Instructions	07
Charging Case Indicator Light Instructions	08
Important Notes	09
Battery Warning	09

CN

连接教程	13
电量查看	13
音量同步(重要)	14
双设备连接	15
佩戴说明	16
操作说明	17
耳机指示灯说明	19
充电仓指示灯说明	20
重要说明	21
电池警告	22
产品中有害物质的名称及含量	23

TC

連接教學	24
電量查看	24
音量同步 (重要)	25
雙設備連接	26
佩戴說明	27
操作說明	28
耳機指示燈說明	30
充電盒指示燈說明	31
重要說明	32
電池警告	32

RU

Инструкция подключения	43
Проверка уровня заряда батареи	43
Синхронизация громкости (Важно)	44
Подключение двух устройств	45
Инструкция по ношению	46
Управление	47
Индикаторы на наушниках	49
Индикаторы зарядного кейса	50
Важные указания	51
Предупреждение о батарее	52

JP

接続手順	34
バッテリー残量の確認	34
ボリューム同期 (重要)	35
デュアルデバイス接続	36
装着方法	37
操作方法	38
イヤホンのLEDインジケーター	40
充電ケースのLEDインジケーター	41
重要事項	42
バッテリー警告	42

KR

연결 가이드	53
배터리 확인	53
볼륨 동기화 (중요)	54
듀얼 장치 연결	55
착용 방법	56
사용 방법	57
이어폰 LED 표시등 안내	59
충전 케이스 LED 표시등 안내	60
중요 안내사항	61
배터리 경고	61

Pairing Tutorial


EN

1. Navigate to phone settings > Bluetooth
2. Locate "LINKLIKE RingStar Air" in Bluetooth devices and tap to connect
3. Enable call & media permissions



Check Battery Status

Depending on the operating system, you can check the battery status on the negative one screen interface or in the top notification bar of your phone.




Volume Sync (Important)

Sync function locations vary across systems. Here's how to find the sync toggle:

iOS: Automatic system synchronization (no manual setup required)

Android: Settings > Bluetooth > Headphone Settings > Enable Volume Sync


Legacy Android: Settings > Search bar (type "Volume Sync") > Toggle ON



Pro tip: For optimal volume control and enhanced audio quality, activate volume sync before using your earphones.

Dual Device Connection

1. Open the charging case and enable Bluetooth on devices A and B. Select the earbuds in the Bluetooth settings to connect. (Fast connection available within 15 seconds.)
2. Remove the earbuds from the charging case and connect them to Device A. Tap both earbuds' touch panels five times to enter pairing mode again, then connect to Device B. If two devices are already connected, the earbuds will maintain connection with the last two paired devices.



(Note: Bluetooth implementations vary across systems. If auto-reconnect fails, manually connect via device Bluetooth settings or toggle Bluetooth off/on.)


Wearing Instructions

Front



Audio Output Port

Back




Touch Control Panel



1. Insert the earbuds into the ear canal and slide down to a secure and comfortable position.
2. Adjust the angle so the audio output port aligns vertically with the ear canal for optimal fit.
3. Improper wearing may negatively impact call quality and sound performance.
4. Wipe dry promptly if wet to avoid affecting earphone performance.


Operation Instructions



Left Earbud Controls

Music mode	● Single click: Play/pause
	●● Double click: Previous track
	▬ Long press: Volume down
	●●● Triple click: Enter/exit game mode
Call mode	●● Double click: Answer call
	▬ Long press: Hang up/reject call
Normal mode (Non-music, non-call mode)	▬ Long press 3s/6s: Power on/off


Right Earbud
Touch controls
(Single-finger tap)




Right Earbud Controls

Music mode	● Single click: Play/pause
	●● Double click: Next track
	▬ Long press: Volume up
	●●● Triple click: Enter/exit voice assistant
Call mode	●● Double click: Answer call
	▬ Long press : Hang up/reject call
Normal mode (Non-music, non-call mode)	▬ Long press 3s/6s: Power on/off

Remove earbuds from the charging case, then press and hold both touch panels for 3 seconds.




Earbuds Indicator Light Instructions



Function Description	Light Status
Power on/off	White/red light stays on for 3 seconds
Pairing mode	White light breathing flash
Pairing successful	White light stays on for 3 seconds
Factory reset	White/red alternating flash for 3 seconds
Fully charged	White light stays on for 10 seconds
Dual-device pairing	White/red alternating flash 3 seconds

Charging Case Indicator Light Instructions



Function Description	Light Status
Case open/close	Battery level displayed for 3s
Charging case battery level (Display when case opened)	White: 80%→100%
	Green: 50%→80%
	Orange: 20%→50%
	Red: 0%→20%
Fully charged	White light on for 10s
NTC thermal protection	Red light flashes for 10s
Earbud detection (in/out)	Battery indicator light flashes twice quickly

Tip: Keeping battery level above 30% during storage extends battery lifespan.

Important Notes

1. Do not use corrosive cleaners to clean this product.
2. Avoid using the product in high-temperature or humid environments. Never expose to heat sources, open flames, or fire to prevent explosion.
3. This product contains no user-serviceable parts. Do not disassemble or modify.
4. Do not charge below 0°C to prevent battery damage.
5. Avoid use during thunderstorms as it may cause malfunction and electric shock risks.
6. Maintain moderate volume levels. Prolonged loud volumes may cause hearing damage.
7. Refrain from use in situations requiring full attention (e.g., traffic or skilled work).
8. Use only certified chargers meeting standard requirements.
9. For optimal performance, use USB-C adapters compliant with national standards.
10. Keep accessories and packaging components away from children and pets to prevent accidents/choking hazards.
11. For long-term storage, keep earbuds in charging case in dry conditions. Charge case at least monthly.

Battery Warning

This product contains a built-in battery. Please note the following:

1. Charge promptly when the battery is low. If unused for extended periods, power on the device every 3 months until the battery is depleted, then fully recharge it to prevent damage. Use and store the product within recommended temperature ranges.

2. Do not disassemble, impact, crush, or expose to fire. Discontinue use if severe swelling occurs. Avoid high-temperature environments. If battery life significantly shortens, cease use and consult professionals.
3. Improper battery replacement may cause explosion. Use only identical/equivalent battery types. Replacement must be performed by qualified technicians.
4. Battery packs or battery arrays must not be exposed to excessive heat sources, including sunlight or open flames.
5. For products containing built-in batteries: When disposing, separate from household waste. Deliver designated e-waste collection points for proper recycling. Never discard casually.



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IC Warning

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

1. This device may not cause interference;
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

3. l'appareil ne doit pas produire de brouillage, et
4. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The information listed above provides the user with information needed to make him or her aware of a RF exposure, and what to do to assure that this radio operates within the FCC exposure limits of this radio.

The device complies with RF specifications when the device used at 5mm from the body. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.



All products bearing this symbol are waste electrical and electronic equipment which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.



Linklike (Shenzhen) Technology Co., Ltd. hereby declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU and all other applicable EU directive requirements. The full text of the EU declaration of conformity is available at the following internet address: www.linklikeaudio.com