

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WIRELESS SPEAKER BARR  USER MANUAL for use with  Bluetooth enabled devices	© Quest USA Corp. GoJoy & Joy are registered trademarks of Quest USA Corp. All other trademarks and trade names are property of their respective owners. Designed by gojoy & joy in New York, Made in China, All rights reserved. QUEST USA CORP, Brooklyn, NY, Limited lifetime warranty. To activate your product warranty go to our website www.gojoy.com & register this product.	•DEVICE FUNCTIONS + Next Song/Long Press volume + ☎ Phone Function ⏮ Play/Pause/long press for mode change ⏭ Last song/long press volume -  Speaker specification: 57 mm*2 Charging time: 2.5 hours Bluetooth version: 4.2 Transmission distance: 10 meters Frequency range: 50Hz-20kHz Signal to noise ratio: > 63DB Product size: 38*90mm	•INSTRUCTIONS Power ON/OFF To turn the speaker ON, push the (POWER) button to ON position. To turn the speaker OFF, push the (POWER) button to OFF position. Adjusting Volume Long Press the + button to increase volume. A tone will be heard if you attempt to increase the volume past maximum level. Long press the - button to decrease volume. Playing/Pausing Media To enjoy music on your device, make sure you are paired to a Bluetooth-enabled device. Once paired, you can control media playback and volume adjustment with the controls on your paired device or with the speaker. Skipping Tracks To skip to the next track, quick press the + button. To skip to the previous track, quick press the - button.
•YOUR LJOY PRODUCT Thank you for purchasing and using the "UJOY BARR" wireless bluetooth speaker. This product can provide high quality listening and enjoyment for mobile phone, computer and multimedia. Before using this product, carefully read this manual to correctly manipulate and play its best performance. Please ask your local dealer or call us if you have any questions. PACKAGE CONTENTS UJOY BARR Bluetooth Speaker X1 Charging Cable X 1 User Manual X 1 •PAIRING YOUR PRODUCT 1. Place device within 30 ft. of bluetooth enabled device. 2. Turn on the speaker. You will hear a "beep" sound. The LED Display will turn on to indicate it is ready to pair. 3. Follow the instructions of your device to search for the device. 4. The device is called "UJOY BARR". If a pin is required, enter "0000". 5. Then the device will have a different "beep" sound when pairing is complete.	•BATTERY CAUTION The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal. Never disassemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic substance. Always confirm that the temperature is 5 degrees Celsius before you change the battery. Never expose the battery to any liquid. Never expose the battery to excessive heat such as direct sunlight or fire. Never use the battery pack in an unventilated vehicle where excessive internal temperatures may be encountered. Always keep the battery out of reach of infants and small children. •BATTERY DISPOSAL Please do not attempt to change the battery yourself. If the battery has died and you do not want us to replace your battery, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics with ordinary solid wastes. Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.	•OTHER IMPORTANT SAFETY INFORMATION To avoid danger of suffocation, keep plastic bag away from babies and children. Do not use this bag in cribs, beds, carriages or playpens. This bag is not a toy. Disposal of old electrical & electronic equipment. (Applicable in the European Union and other European Countries with separate collection systems.) The trash can symbol (seen on bottom right) on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for recycling of electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item. 	•LIMITED LIFETIME WARRANTY Our product is warranted for a limited lifetime warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 24 months does not apply to decrease in accumulators effective capacity cause by on its use or age. Effective capacity gradually decreases depending on the method of use of the accumulator. WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS. For more information please visit: www.gojoy.com Tip: You must use the formal manufacturer certified charger, output voltage of 5v. If the product is not in use for a long time, please charge it.