

## N1315

### Instruction Manual 快速操作指南

### Bluetooth Headphones 蓝牙无线耳机

#### 包装内容 Package Contents

1. 耳机 Headphone
2. USB 充电线 USB charging cable
3. 音频线 Aux-input cable

#### 外观 At a Glance

1. 降噪开关 ANC button
2. 音量 + 按键 volume +bottom
3. 音量 - 按键 volume - bottom
4. 多功能按键 Multifunction button
5. USB 接口 USB charging port
6. LED 指示灯 LED indicator
7. Microphone
8. 3.5mm Aux-input

#### 使用方法 Instructions

##### 开/关机 Turn ON/OFF

##### 开机 Turn ON

长按多功能键 2 秒

红蓝色指示灯常亮 1 秒语音提示 “ON”

Press and hold the multifunction button for 2 seconds

The red and blue lights are on for 1 second and the voice prompts "ON"

##### 关机 Turn OFF

long press multi-function button for about 2.5 seconds off red and blue light is always on for 1 second

Voice prompt "OFF"

##### 连接设备 Pair with your device

在配对之前，请把您的蓝牙设备移近与 N1315 耳机 3 米范围以内进行配对和连接。确保您的耳机电池有足够的电量

Before pairing, please pair and connect your Bluetooth device within 3 meters of the N1315 headphone. Make sure your headphone battery has enough power.

##### Pairing

Turn on your N1315 headset and press and hold the multifunction button for about 5 seconds.

The red and blue lights flash alternately

##### 配对

打开您的 N1315 耳机，按住多功能键约 5 秒。红蓝指示灯快速交替闪烁表示

N1315 进入到配对模式和准备配对连接到您的蓝牙设备。语音提示 “配对”

Turn on N1315 headphone and press and hold the multifunction button for about 5 seconds. The red and blue lights flash alternately

The N1315 enters pairing mode and is ready to pair to connect to your Bluetooth device. Voice prompt "pairing"

连接成功

蓝牙设备搜索 N1315 并连接，蓝色指示灯快速闪烁。语音提示“连接成功”。

Connected to a device

The Bluetooth device searches for the N1315 and connects, and the blue LED flashes quickly.

Voice prompt "Connection is successful".

配对超时

红蓝指示灯快速交替闪烁，5 分钟后自动关机。语音提示“嘟”。

Pairing timeout

The red and blue lights flash alternately quickly and turn off automatically after 5 minutes. Voice prompt "beep."

连接断开

设备端人为把蓝牙断开连接，红色指示灯快速闪烁 5 分钟后关机。

设备和 N1315 的连接超出有效范围

（10 米）蓝色指示灯前 5 分钟每 15 秒语言提示“嘟嘟”，5 分钟后关机。

Disconnected

The device end manually disconnects the Bluetooth, and the red indicator flashes quickly after 5 minutes.

Device and N1315 connection is out of valid range

(10 meters) The blue light indicates “beep” every 15 seconds for the first 5 minutes and turns off after 5 minutes.

同时连接两部手机

成功配对到第一台手机后关闭 N1315 重新开机进入到配对状态，然后连接上第二台手机后耳机再次关机，然后开机自动连接到第二台手机，在手机上手动点连接第一台手机。蓝色指示灯

1 秒闪烁 3 次。语音提示“嘟”

Connect two mobile phones at the same time

After successfully pairing to the first phone, close N1315 and reboot to enter the pairing state. After connecting the second phone, turn off the headphone again. Then the connection will be automatically connected to the second phone, manually connect the first mobile phone on the phone. The blue light flashes 3 times for 1 second.

清除配对列表

长按 VOL+键，VOL-键 5 秒钟。（注：清除记录成功后耳机开机自动进入配对状态）红蓝色指示灯快速闪烁 1 次，语言提示长“嘟嘟”。

Clear pairing list

Long press the VOL+ button and the VOL- button for 5 seconds. (Note: The headphone will automatically enter the pairing status after the clear recording is successful.) The red and blue indicators flash once, and the language prompts “beep”.

待机 Standby

配对、连接成功后自动进入联机待机状态，蓝色指示灯 1 秒闪烁 3 次

Automatically enters online standby after pairing and connection is successful. The blue light

flashes 3 times for 1 second.

In your wireless Bluetooth device: iPhone, iPad, iPod and Android smartphone or tablet

- Open the "Settings" function on your Bluetooth device.
- Make sure the "Bluetooth" option on your Bluetooth device is turned on. Click the "Search" function.
- Wait for the N1315's Bluetooth name to appear in the Available Devices' Bluetooth list.
- Select the N1315 Bluetooth name to start pairing and connecting with your Bluetooth device.
- The blue light on your N1315 wireless Bluetooth headphone flashes quickly, indicating that your wireless Bluetooth headphone is paired successfully and you can start playing and listening to your favorite music.

#### 播放控制

##### Play control

- Push the button to turn on noise reduction

The green indicator light is ON, noise reduction begins to work, and the noise reduction peak can reach -22dB.

Press down button turn off the noise reduction

- Press Volume+  
hold for 1 second   play next
- Press Volume-  
hold for 1 second   play previous
- Press Multifunction button  
Play/Pause

#### 电话控制

##### Phone control

- Press   Volume up
- Press   Volume down
- Press the multi-function button to answer the call
- Press and hold the multifunction button for about 2 seconds to reject the call
- Short press the multifunction button to end call
- In the standby mode, double-click the multi-function button to redial

#### 音频线连接

##### Connect via AUX

Insert one end of the audio cable into the 3.5mm AUX-input of the Bluetooth device and the other end into the N1315

In the 3.5mm AUX-input, open the music player on your device and you can start playing and listening to your favorite music.

#### 耳机充电

##### Charge your N1315

The battery of your N1315 wireless Bluetooth headphone is only partially charged at the factory. We suggest that you fully charge it before use . This will allow you to play for the longest time possible.

Steady red   charging

Steady blue full charged

Low power

When the battery power less than 15%,Voice prompt "Beep" (every ten minutes to remind) and the red light will flash twice every second.

Gently insert the Micro USB cable into the Micro USB charging port of the headphone, and gently insert the other end of the Micro USB cable into the USB port of the charger or the computer's USB port to charge the headphone. It takes 2 hours to fully charge the battery.

Note: When plugging in the USB cable to charge the headphones, in order to protect the battery life, long press the multi-function button on the headphone can not turn OFF, you need to pull out the USB cable, long press the multi-function button to make the headphone turn ON.

#### 规格参数 Specifications

- Battery: 500mAh
- Input voltage: 5V/0.5A
- Charging time: 2hours
- Standby time: 480hours
- Playing time:  $\geq 20$ hours
- Bluetooth connection distance:  $\geq 10$ m
- Operation, storage and charging temperature: 0° C-40° C

#### 注意事项

- For safety, do not use headphones when riding a bicycle, motorcycle, or driving. It is dangerous to open the volume too loud to hear outside sounds; pay attention to the careful driving of the surrounding vehicles.
- Don't disassemble, avoid dropping
- Avoid extreme temperature
- Do not place this product in a hot, humid environment.
- Do not submerge in water, fire or any corrosive cleaner
- Do not place this product on flammable substances when charging.
- Do not remove or replace the built-in battery by yourself, there is a risk of explosion.
- Avoid excessive volume or wear headphones for a long time to avoid hearing loss.
- The noise reduction function is effective in the low frequency range, such as in airplane, train, or office (around the air conditioner, etc.), but the effect on higher frequencies is not obvious, such as vocals

#### 常见问题 common problem

If N1315 wireless Bluetooth headphone does not turn on?

- Check the battery of your N1315 wireless Bluetooth headphone has enough power.
- If your computer's own battery is exhausted, your computer's USB port will not be able to charge the N1315's battery. Try charging the N1315's battery with a 5V (1A or 2A) USB charger. Charging time should be at least 2-3 hours.

If there is no sound in the headphones when you play music?

- Check whether the device and the Bluetooth headphone establish a valid connection. If the audio device fails to connect properly, reconnect it and adjust the volume of the phone and Bluetooth headphone to an appropriate volume level.

If the phone can't search the Bluetooth headphone?

● Please confirm whether the Bluetooth of the mobile phone is in the “Device Visible Mode”. If the pairing is not performed for a long time, the Bluetooth pairing function will be automatically closed. Please turn Bluetooth on again to “Device Visible Mode”. If the phone program error, please restart the phone; if headphone bluetooth goes wrong, please restart the Bluetooth .

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.