
ADYSS-A19 说明书260*120mm



欢迎使用补光自拍杆,使用前请给自拍杆充电半小时! 连接操作步骤:

● 长按开机键 " □ " 两秒钟开启设备 ② 待蓝灯亮起闪烁

♠ 打开王机设置 搜索连接设备

▲ 点击 "ADYSS" 连接设备等待5秒,蓝灯长亭配对成功

产品参数·

最大承重能力 : 500a 工作电流 : 3.5mA 主要材料 : ABS塑料 工作电压 : 3.6~4.2V 产品净重 : 187a 丁作温度 · -10°~ +40°

产品频率 : 2.4G 电池容量 : 补光灯/80mAh ; 遥控器/55mAh

充电时间: 0.5小时 充电电压: DC 5V 补光时间 : 1小时 待机时间 : 半年

支持手机型号:

★ 苹果系列机型 (iOS 5.0以上系统)

● 安卓系列机型 (Android 4.2.2以上系统) 请按时更新手机系统,避免版本过低无法兼容使用

- 使用自拍杆前请确保手机完好的固定在夹头上,智能机脱落等产生的损伤
- 使用前请确认使用地域和设施限制的场所,禁止违反公共秩序的行为。
- 使用期间将电源线强力拉、旋转等导致断线
- 高出跌落导致外壳损伤不良
- 使用超出产品负荷电源,导致产品发热及电路板烧坏


一年有限保修摘要

ADYSS保证所附带的硬件产品,从原先零售购入的日期一年内在材料和工艺 方面无瑕疵,均可受理售后问题。ADYSS对正常使用磨损不做担保,对于事故或滥用造成的损坏也不做担保。若要获取服务可访问ADYSS拥有的零售店或 ADYSS授权服务商,即可为你的产品酌情进行修理、更换你享有的保修权益 是附加在本地消费者法律所提供的权利以外的。当您根据本保修政策提出索 赔时,可能需要提供购买证明的详细信息

产品操作光骤:








补光灯开关按键 三挡灯光切换 长按螺闪




遥控器跟手机连接,遥控有效距离10米



长按"👩"三秒蓝灯闪烁,手机设置 搜索: "ADYSS" 点击连接.蓝灯长亮完成配对




支架模式,支架位于手柄处凹槽



将锁紧装置"Ⅲ"向左一推,至状态" / 1







支架收起前 需要将锁紧装置" / 【 " 向右→推 至状态" Ⅲ "方可收起





遥控器、补光灯为 Micro USB充电接口充电时间:0.5小时 使用常规DC 5V USB充电器充电

Welcome to use the fill-light selfie stick Please charge the selfie stick for 0.5 hours before use!

- 2 Wait until the blue light is on
- 3 Open phone settings, search for link devices
- 4 Click "ADYSS" to connect the device and wait for 5 seconds. The blue light is brightly paired successfully.

Parameter

Working current: 3.5mA Working voltage : 3.5~4.2V Charging voltage : DC 5V Operating temperature : -10°~40° Standby time : half a year Main material : ABS plastic

Net Weight: 187g Operating frequency : 2.4GHZ Charging time : 0.5/h Max load capacity : 500g Battery capacity : Fill light / 80mAh

Supported mobile phone model:

- Apple series models (iOS 5.0 and above)
- Android series models (Android 4.2.2 and above) being too low to be compatible for using.
- ⚠ Matters need attention (not involved in the warranty)
- Before using the selfie stick, please make sure that the phone is properly
- fixed on the collet, and the damage caused by the smart phone falling of Please confirm the place of using region and facility restrictions before using, and prohibit the behavior of public property violations.
- Pulling and rotating the power cord during using period which causes
- Falling from a high place that causes damage to the outer casing. Using a power supply that exceeds the product load that causes the product heating up and the circuit board burning out.

One Year Limited Warranty Summary

ADYSS guarantees that the attached hardware products can accept the after-sales problems in terms of materials and processes within one year from the original retail purchase date. ADYSS does not guarantee the normal use of wear and tear, nor does guarantee the damage caused by accident or abuse. If you want to obtain service, you can visit the retail store or ADYSS Authorized Service Providers to repair and replace your products as appropriate. The warranty interest you possess is in addition to the rights provided by local consumer law. When you claim for compensation under this warranty policy, you may need to provide the detailed information of the purchase certificate


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particula installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- -Connect the equipment into an outlet on a circuit different from that to
- -Consult the dealer or an experienced radio/TV technician for help

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to



Do not throw the product into the fire and keep away from the fire.

Warning: Contains small parts.
Not suitable for children 3 years old and below.

Executive standard: Q/QTP:002-2016 FCC ID: 2ARFLADYSS-A19

RoHS (F F 🕏 🛟 👸 🗵 Made in China

Product operating steps:





Loosen the twist head and adjust the angle up and down. After the angle adjustment is completed, lock the twist.





phone, and the remote control effective distance














Remote control, fill light for Micro USB charging interface Charging time: 0.5 hours Charge using a regular DC 5V USB charger

