

Innway tracker USER GUIDE



Step 1:

please download App "Innway tracker" from App store or Google Play.Or scan the QR code to download.



Compatible devices:

For IOS: iPhone 4S and later

For Android: android TM 4.4 and above.

Step 2:

Turn on Bluetooth.

Make sure your phone Bluetooth is on.

Step 3:

Sign up for New user.

Start "innway tracker" App and tap the "sign up".

Step 4:

Pair the innway device to your phone.

- 1). Make sure to turn on your phone's Bluetooth.
- 2). Hold the innway device close to your phone.
- 3). Hold the button on the innway until you hear a beep and the led starts flashing.

Attach:

Innway card to anything you don't want to lose. Connect it to the Innway app.

Ring:

When the device and phone are connected. you can use the device to find your phone, or use your phone to find the device.

Motion History:

Your missing items. The app remembers when and where you last had them.

Camera Remote:

The botton on the card also as a camera remote. Never be left out of a group picture again.

Rechargeble battary:

Batteay life up to 2 Months and the batterypercent also display in APP and could rechargeable.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.