

Noise Cancelling Wireless Sport Headphones 无线运动降噪耳机

SR-BH5

User Manual 用户手册

### **FCC Caution:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **IMPORTANT NOTE:**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

# **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

### Statement

#### Thank you for purchasing Saramonic!


Please read this manual carefully before using and strictly operate and store it in accordance with the instructions. Please save manual for your future reference. If you need further assistance than the user manual, please consult with your retailer for help or email us: info@saramonic.com

# **Packaging List**



Warranty Card

# **Product Overview**



- ① Microphone
- 2 Active Noise Cancellation (ANC) Switch
- ③ Type-C Charging Port
- 4 Indicator
  - (5) Volume +/ Previous Song
- 6 Volume -/ Next Song
- (7) Multi-function button

# **LED Indicator Status**

Equipment Status	Indicator Light		Voice Prompts
Power on	Blue indicator flashing 1s	•	Power on
Power off	Red indicator flashing 1s and then turn off	•	Power off
Playing	Blue indicator flashing 1 time / 3s	•	/
Charging	Indicator solid red	•	/
Fully charged	Indicator solid blue	•	/
Battery low	When connected, the red indicator flashing 1 time / 10s	•	Battery low
Pairing	Red and blue indicators flashing alternately	•	/
Connected	Blue indicator flashing 1 time / 3s	•	Your headset is connected

# Specifications

Model	SR-BH5
Bluetooth Version	5.0
Driver Specifications	12mm Graphene
Impedance	32Ω
Frequency Response	20Hz~20kHz
Music Play time	Approx 15 hrs (ANC off, BT on) Approx 9 hrs (ANC on, BT on)
Supported Audio Formats	APTX, APTX-HD, AAC, SBC
Operating Distance	10m
Noise Cancellation Depth	22dB
Battery Capacity	182mAh
Charging Time	Approx 2 hrs
Dimensions	160*130*35mm
Weight	37g

Note: BT=bluetooth, ANC=active noise cancelling

### **Button Operation**


#### 1) Active Noise Cancellation (ANC) switch

Turn on the ANC mode: Flick down the ANC switch Turn off ANC mode:

Swipe up the ANC switch (red dot indicates)

Note: Slide the ANC on / off switch to turn on or turn off the ANC mode.





#### (2) Volume +/Previous Track

Volume up: Short press the Volume + button (Maximum volume will be reminded) Previous song: Long press the Volume + button

#### (3) Volume-/Next Track

Volume down: Short press the Volume-button (Minimum volume will be reminded) Next song: Long press the Volume-button

#### (4) Multi-function button

Equipment Status	Instructions
Turn on/ off	Long Press for 5s
Play/ Pause	Click once
Voice assistant	Double-click
Reset the device	After power off, long press for 8s
Answer/ hand up	Double click
Reject Calls	Long press for 1s
Headphones / mobile phone hands-free switch	Long press for 1s



#### TIPS

Please turn off the ANC function when stop using this headphone to avoid battery consumption. Please use high-quality playback sources to experience the best sound quality.

### Instructions for Use

#### 1. Pairing

- ① Long press the multi-function button for 5s, the headphone will automatically start pairing;
- 2 The red and blue lights flash alternately;
- 3 Select the Bluetooth name "Saramonic BH5" on your device:
- (4) Once successful, the voice prompts "Your Headset is Connected".

After the connection is successful, you can check the battery level on the phone.



#### Note:

The headphone will automatically turn off if there's no connection after 5 mins.



 Unfold and put on the headphone, adjust it into a comfortable position in the direction shown.

#### 3. Charging

Use the Type-C cable to charge the headphones.



Equipment Status	Voice Prompts	Indicator Light
Battery low	Battery low	When connected, the red indicator flashes 1 time / 10s
Battery low and turn off automatically	Power off	Red indicators flashes 1s and then turn off

### Multi-Device Connection (Wireless)



- Connect the headphone with the first device.
- Turn off Bluetooth on the first device, the headphone will enter pairing mode automatically again.
- Search the Saramonic BH5 on the bluetooth list of the second device, select it and connect the headphone.
- Go back to first device, select Saramonic
  BH5 and connect.
- Now the headphone is connecting with two devices simultaneously.

### After-sales and Supports

#### Warranty Service:



(F) 2 years Quality Warranty

Life time Technical Service Support

According to the relevant laws and regulations of consumer electronic products and the actual the situation of the industry, the following after-sales service regulations are formulated to provide consumers with satisfactory after-sales services:

- 1. Warranty certificate mainly includes: warranty card and sales certificate.
- 2. After-sales service scope:
  - During the warranty period of the product, the company will be responsible for providing free maintenance for any failure caused by the quality problem of the product itself under normal use without disassembly and repair:
  - For products beyond the warranty period, the warranty certificate shall be issued and the maintenance fee shall be paid. If any spare parts are needed for repair cost for the spare parts would be born by the purchaser; please avoid repair and replace when the product is not tested by Saramonic after-sales department:
  - Once the warranty certificate is altered, the warranty will become invalid immediately:
  - The warranty certificate of the product shall be properly kept by the consumer and shall not be supplemented if lost.

#### 3. Warranty Period:

- · Within two years after purchasing this product, there are quality problems in normal use (non-human damage) without disassembly and repair;
- Consumers who have quality problems in normal use (non-human damage) within 7 days from the date of purchase, without repair, can enjoy the replacement service; 1-year warranty (including all accessories) from the date of issuing the sales certificate;
- 4. Regulations on invalidation of the warranty during the warranty period:
- 4.1 In the following cases, the warranty is invalid, but the maintenance service is provided, the labor fee and parts fee are charged:
  - (1) any damage to accessories caused by improper use, maintenance and storage of consumers;
  - (2) damage caused by force majeure, such as natural disasters.
- 4.2 In the following cases, the company will refuse to provide maintenance services or provide charged maintenance services:
  - (1) fail to provide holograms on product packaging box;
  - (2) the contents of the holograms are altered or illegible;
  - (3) It is unable to provide the product warranty card or the content recorded in the warranty card is inconsistent with the product, or the content is altered or illegible; (4) headphones that have been removed by any unauthorized person of Shenzhen
  - Jiayz Photo Industrial., Ltd. (such as changing wires, removing voice coils, etc.);
  - (5) there is no sales voucher or the content of the sales voucher is inconsistent with the product.
- 5. We will not provide warranty service in the following cases after our inquiry: if we find that your repair products are not our products, we will refuse to provide warranty service, or double the maintenance fee, Please attach the warranty certificate when you send the headphones to our company for repair. If you don't have any certificate, our company will handle it as parallel imports.

### Safety Instructions

#### Please read the following precautions carefully before using.

- Please do not put the headphones close to flammable materials to avoid fire accidents when charging.
- Please keep the plastic bag away from babies and children to avoid suffocation.
- Please keep the headphones and all accessories away from children and pets, to avoid swallowing as it may cause asphyxia and other dangers.
- 4. Please do not use the headphones in situation which need concentration, such as driving, cycling and etc. Please abide by the local laws and regulations for using headphone when driving.
- Please avoid using indicator light of the device near children or animals eyes.
- Please do not use the headphones too long at high volume as it may damage your hearing, it is recommended to use an appropriate volume when listening to calls and music.
- Please do not rinse or immerse the headphones in water to avoid damage.
- Please do not disassemble the headphones and accessories by yourself to avoid damage and invalidation of the warranty.
- Please do not subject the headphones to a strong shock or vibration to avoid damage.
- 10. Please do not use chemical solvents or detergents to clean the headset.
- 11. If this headset will not be used for a long time, it should be power off after fully charged. Please unplug the charging cable after charging and use the charger provided by the official manufacturer or for charging.

### O&A

#### Q: The headphone cannot connect to the device?

A: Please make sure your headphone is in pairing mode. Delete the pairing record on the Bluetooth device and reconnect the headphone.

#### Q: The headphone cannot be turned on?

A: Please check if the headphone has power.

#### Q: Can the battery in the headphone be replaced?

A: No. This headphone uses a built-in non-removable lithium polymer battery that cannot be replaced.

#### Q: Can I use headphone while driving?

A: For your safety, we strongly recommend that do not use the headphone while driving to avoid danger.

#### Q: Why the headphone is disconnected within 10 meters?

A: As the Bluetooth signal connection may be interfered when it encounters WiFi routers, 4G signals, high-power electrical appliances and other devices etc. You can change the environment or try again.

#### Q: Why is there no sound on the computer or mobile phone?

A: Please check whether the output channel of the computer supports A2DP. Also check the volume setting on the headphone and computer/phone.

#### Q: Why can't I control the volume of the tracks playing on my phone?


A: As the headphone may not be fully compatible with some apps, due to the different configurations of various APP.

# 声明


#### 感谢您选择Saramonic!

请在使用前仔细阅读本手册,并严格按照说明进行操作和存储。 请妥善保存好说明书以供将来参考。如果用户手册不能帮助您解决某些问题, 请向零售商寻求帮助或给我们发送电子邮件: info@Saramonic.com

# 包装清单



# 产品结构



- ① 麦克风
- ② 主动降噪开关
- ③ Type-C充电口
- ④ 状态/电量指示灯
- ⑤ 音量+/上一曲
- ⑥ 音量-/下一曲
- ⑦ 多功能键

# LED 指示灯显示状态

设备状态	指示灯	图示	语音提示
开机	蓝灯亮一秒	•	Power on
关机	红灯亮一秒后熄灭	•	Power off
播放中	蓝灯3秒/次	•	/
充电中	红灯长亮	•	/
充电完成	蓝灯长亮	•	/
低电量提醒	已连接状态下,红灯闪烁10秒/次	•	Battery low
配对中	红蓝灯交替闪烁	•	/
蓝牙已连接	蓝灯闪烁3秒/次	•	Your headset is connected

### 参数

型号	SR-BH5
蓝牙版本	5.0
喇叭规格	12mm石墨烯
阻抗	32Ω
频率范围	20Hz~20kHz
播放时长	约15小时(降噪关,蓝牙连接开) 约9小时(降噪开,蓝牙连接开)
支持协议	aptX, aptX-HD, AAC, SBC
操作距离	10米
降噪值	22dB
电池容量	182mAh
充电时长	约2小时
尺寸	160x130x35mm
重量	37克


# 按键操作说明

#### ① 主动降噪开关

往下拨动, 开启主动降噪;

往上拨动,关闭主动降噪(有红点示意)

注意: ANC 可独立开启或关闭。





#### ② 音量+

短按, 音量加大; (最大音有提示音)

长按,切换至上一曲。

### ③ 3 音量 -

短按, 音量减小; (最小音有提示音)

长按,切换至下一曲。

#### ④ 多功能键

设备状态	操作说明
开机/关机	长按多功能键5秒
暂停/播放	单击多功能键
开启语音助手	双击多功能键(蓝牙已连接状态下)
重置	长按多功能键8秒(关机状态下)
接听/挂断	双击
拒接	长按1秒(来电状态下)
耳机/手机免提切换	长按1秒(通话状态下)



注意:

停止使用本产品时请关闭 ANC 开关, 避免持续消耗电池!

# 使用说明

### 1. 配对

- ① 长按多功能按键5秒、设备自动讲入配对模式:
- ② 红蓝灯交替闪烁:
- ③ 在设备上选择蓝牙名称 "Saramonic BH5";
- ④ 连接成功、语音提示 "Your headset is connected"。
  - \* 连接成功后可在手机状态栏杳看电量



#### 注意:

配对模式持续5分钟內,还未 与任何设备进行蓝牙连接,将 自动关机。



2. 展开并戴上耳机,将耳机按下图 所示方向调整至舒适位置。

### 3. 充电

使用Type-C充电线给耳机充电。



设备状态	语音提示	指示灯
低电量	Battery low	红灯闪烁, 10 秒 /次
电量过低, 自动关机	Power off	红灯常亮 1 秒熄灭

注意: 在充电状态下, 请关闭主动降噪 开关, 否则会延长充电时间。

# 多设备连接(无线连接)



- 1. 按配对步骤,将耳机连接到第一台设备;
- 2. 在第一台设备上断开蓝牙连接, 耳机重新进入配对状态;
- 3. 将耳机与第二台设备配对并连接;
- 4. 回到第一台设备端,在蓝牙列表选择Saramonic BH5耳机进行连接;
- 5. 此时耳机已成功同时连接两台设备。

# 售后服务

#### 保修:

🖭 2 年质量保修

#### ● 终身技术服务支持

根据消费类电子产品的有关法规以及行业的实际情况,为消费者提供满意的售后服务。 特制定以下售后服务条例:

1. 保修凭证主要包括:

保修卡及销售凭证。

- 2. 售后服务范围:
- 在产品保修期内,凡属于正常使用情况下,由于产品本身质量问题引起的故障,未经拆修,本公司将负责给予免费维修;
- 超出保修期产品,需出具保修凭证并支付维修费。如需订配件,需支付配件费;订购其他的配件则需把维修的产品寄到我司;经我司专业维修人员检测后维修并更换配件:
- 保修凭证一经涂改、保修即时失效。
- 产品的保修凭证,请消费者妥善保存,遗失不补。
- 3. 保修期:
- 自开具销售凭证之日起计算,购买本产品一年内,在正常使用情况下 (非人为损坏或拆修)出现质量问题,可享受保修服务(包括所有配件);
- 消费者由购买之日起7天内,在正常使用情况下(非人为损坏)出现质量问题。未经拆修。可享受包换服务:
- 包换服务, 仅限于同型号、同颜色的产品。
- 4. 保修期内保修失效条例:
  - 以下情况保修失效, 但提供维修服务, 收取人工费, 配件费:
    - (1) 消费者因使用、维护、保管不当造成任何配件的损坏;
    - (2)由不可抗力因素所引致的损坏,如天灾等。
  - 在下列情况,本公司将拒绝提供维修服务或提供收费维修服务:
    - (1)不能提供产品保修卡或保修卡所记载的内容与产品不符,或内容经涂改,或模糊不清无法辨认;
    - (2)由任何未经深圳市长丰影像器材有限公司授权人士拆动过的耳机(如:换线,拆卸音圈等);
    - (3) 无销售凭证或销售凭证内容与产品不符。
- 5. 如下情况我司将不提供保修服务:

经我司查询,如发现您的送修产品不属我司生产品,我司将拒绝提供 保修服务,或是加倍收取维修费。 请您在把需要维修的耳机寄到我司 时,附上保修凭证,如无任何凭证,我司则作水货处理。

# 注意事项

- 1.请勿在耳机充电时靠近易燃物品,以免发生火灾事故。
- 2.请保持耳机的塑料配件远离婴幼儿或孩子, 避免意外发生窒息。
- 请让耳机和所有配件远离儿童和宠物,避免吞咽,因为这可能会导致窒息或 其他危险。
- 4.请不要在需要集中注意力的情况下使用耳机,例如开车,骑自行车等。请遵守当地法律和驾驶时使用耳机的规定。
- 5.请避免在儿童或动物的眼睛附近使用设备的指示灯。
- 6.请勿在高音量下长时间使用耳机,在听电话和音乐时建议使用适当的音量以 免损害您的听力。
- 7.请不要用水冲洗或浸泡耳机,以免造成损坏。
- 8.请不要自行拆卸耳机和配件,以避免损坏和保修失效。
- 9.请勿使耳机受到强烈撞击或震动,以免损坏耳机。
- 10.请不要使用化学溶剂或清洁剂清洁耳机。
- 11.如果长时间不使用此耳机,请充满电后将其关机。充电或使用耳机时请拔 出充电线。请使用由官方制造商提供或适用于充电的充电器。

# 常见问题

- 问: 耳机无法连接设备?
- 答: 请确保您的耳机处于配对模式。删除蓝牙设备上配对记录并重新连接耳机。
- 问: 耳机无法开机?
- 答: 请检查耳机是否有电量。
- 问:可以更换耳机中的电池吗?
- 答:不可以。本耳机使用内置的不可拆卸锂聚合物电池,无法替换。
- 问: 可以在开车时使用耳机吗?
- 答: 为了安全起见, 我们强烈建议您不要在开车时使用耳机, 避免分心驾驶。
- 问: 为什么有时连接会在 10 米内断开?
- 答: 耳机遇到 WiFi 路由器, 4G 信号, 大功率电器等设备时, 蓝牙信号连接 可能会受到干扰, 可通过更改环境或重新连接来解决。
- 问: 为什么电脑或手机没有声音?
- 答:请检查电脑的输出通道是否支持 A2DP。同时检查耳机和电脑 / 手机上 的音量设置。
- 问: 为什么我无法控制手机上播放的曲目的音量应用?
- 答:由于各种应用软件的配置不同,耳机可能与某些 APP 不完全兼容。






Scan the QR code and follow us! 扫描微信关注枫笛公众号!

Shenzhen Jiayz Photo Industrial., Ltd 深圳市长丰影像器材有限公司

A16 Building, Intelligent Terminal Industrial Park of Silicon Valley Power, Guanlan, Longhua District, Shenzhen, China 深圳市龙华区观澜街道大富工业区硅谷动力智能终端产业园A16栋







修改名称	版本	变更内容	变更日期	变更担当

# .

SR-BH5 IRFR#5

杨帆/2021.04.08 正負公差

产品/零件名称

工程图号

物料编号

制图人/日期

AIL	YZ:	长丰	深圳市日	<b>三三三</b> 三三三三三三三三三三三三三三三三三三三三三三三三三三三三三三三三三	象器材	有限

JIAYZ	【长丰   深	圳市长	丰影像語	器材有	R
品/零件名称	SR-BH5 说明书	比例	1:1	版本	Т

٧.	YZ:	长主	深圳市·	长丰影信	象器材料	有限

物料描述

尺寸/用量

85×130mm

1:1	版本	V00
157克铜版纸过油 压痕折页 正反面印刷		
95 v 120mm		