NATURALISE®

Instruction manual

PRODUCT SPEC.

• Product: NATURALISE LOUVENIR

• Size: 110 x 110 x 190mmH

• Model: KISSIN

• Power input: 1.5W

• Input voltage: DC 5V/1A


• Bluetooth: 4.2v

Frequence range: 2402~2480MHz
Battery: Li-polymer 3.7V 1100mAh

• Operating system: Android 4.4 / IOS 8.0 above

• Weight: 200g

COMPONENT



Product, USB cable, Instruction manual

HOW TO USE SMART APP

- 1. Go to the App stire or google play Store and search for the naturalse. Install the App on your smart adevices.
- 2. Touch the " " button for about 3 seconds, When the light on the back lights up, NATURALISE is switched on and bluetooth is active.
- 3. Ativate the Smart App.
- 4. Register your NATURALISE by touching the "+" button.

FUCTIONS

NATURALISE can be controlled directly on the button by touching. At the stand you can choose form 15 colors 75 different color combination, or at smart App you can choose from 25 colors 125 different color



combination. Colors close to nature and the beautiful shades of light create a special atmosphere of living space.

Please release the Power Lock by touching " $\circlearrowleft + \circlearrowleft + \circlearrowleft$ button about 3 seconds at the same time. If the product is not in use, Lock it up in the same way.

- U POWER / 30 minute OFF
- ON/OFF Power, Touch about 3 seconds and turn off after 30 minutes.
 - • COLOR / PANORAMA

15 Colors mode, Touch about 3 seconds and color changes automatically.

- BRIGHTNESS / BLUETOOTH POWER
 5 Step, Touch about 3 seconds and bluetooth turn on/off.
- 💆 TIMER

The wake-up(sleep) fuction automatically turns on(off) the light at the set time.

- FUN
 - he light-color changes by shaking the smart devices.
- *** PARTY

25 colors change irregularly.

ATTENTION

- 1. Make sure that the voltage is correct for this product before use. Using unsuitable voltages may damage the product or cause safety issues.
- 2. Be sure to use it indoors.
- 3. Do not disassemble the product.
- 4. Do not use or store in environments with liquids and moisture.
- 5. The radio facility may be confused with radio waves during operation.
- 6. Use only standard USB. Using other USB cables may damage the product and pose a safety risk.

PRODUCT WARRANTY

- 1. Product warrenty period is 6 month.
- 2. If the initial defect is confirmed within 14 days of the purchase, the product can be exchanged or refunded. In case of product breakage caused by non-initial customer carelessness, it cannot be exchanged or refunded.
- 3. Please contact your place of purchase within 14 days from the date of purchase for product issue.



FCC Statement

FCC Part 15.19 Statements:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21 statement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Part 15.105 statement (Class B)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure

The antenna (or antennas) must be installed so as to maintain at all times a distance minimum of at least 20 cm between the radiation source (antenna) and any individual. This device may not be installed or used in conjunction with any other antenna or transmitter.

