

ARWORK
INFORMATION
PANEL

ARTWORK TITLE: Finger Dance Machine Manual

ARTWORK TYPE: ☐ PACKAGING ☒ MANUAL ☐ STICKER

MATERIAL: 80 gsm

FINISH:

CUTTER GUIDE SIZE: W 105mm x H 142 mm

PRODUCT CODE: OR-FINGDNCE

BARCODE: TYPE: EAN 13, 80%

CMYK

SPECIFIC PANTONE COLOURS

FOLDING GUIDE

CUTTER GUIDE

Font Listing Table

NOTES:

VERSION DATE: DATE: 18/08/2020 DESIGNER: AIDEN MURPHY

APPROVAL:	STAGE	DATE	SIGNATURE	CHECK AND TICK
DESIGNER		___/___/___	___	☐
COPY		___/___/___	___	☐
MANAGER		___/___/___	___	☐
DIRECTOR		___/___/___	___	☐

PLEASE MAKE SURE ALL FONTS HAVE BEEN OUTLINED, AND ALL IMAGES EMBEDDED.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

Head Office - Magnum Brands Group (UK) Ltd., Unit 1, Brainree Industrial Estate, Ruislip, Middlesex, HA4 6EJ, UK. T: 0845 466 8880. info@magnumbrands.com, www.magnumbrands.com

EU - Magnum Brands (EU) Ltd, Herbert House, 19-22 Pembroke road, Dún Laoghaire, Dublin 24, Ireland. T: 01-808 0715. info@magnumbrands.com, www.magnumbrands.com

USA - Magnum Brands Group USA, Unit 1, Brainree Industrial Estate, Ruislip, Middlesex, HA4 6EJ, UK. T: 0845 466 8880. info@magnumbrands.com, www.magnumbrands.com

CE, RoHS, WEEE, REACH, EN 60950-1, EN 60950-2, EN 60950-3, EN 60950-4, EN 60950-5, EN 60950-6, EN 60950-7, EN 60950-8, EN 60950-9, EN 60950-10, EN 60950-11, EN 60950-12, EN 60950-13, EN 60950-14, EN 60950-15, EN 60950-16, EN 60950-17, EN 60950-18, EN 60950-19, EN 60950-20, EN 60950-21, EN 60950-22, EN 60950-23, EN 60950-24, EN 60950-25, EN 60950-26, EN 60950-27, EN 60950-28, EN 60950-29, EN 60950-30, EN 60950-31, EN 60950-32, EN 60950-33, EN 60950-34, EN 60950-35, EN 60950-36, EN 60950-37, EN 60950-38, EN 60950-39, EN 60950-40, EN 60950-41, EN 60950-42, EN 60950-43, EN 60950-44, EN 60950-45, EN 60950-46, EN 60950-47, EN 60950-48, EN 60950-49, EN 60950-50, EN 60950-51, EN 60950-52, EN 60950-53, EN 60950-54, EN 60950-55, EN 60950-56, EN 60950-57, EN 60950-58, EN 60950-59, EN 60950-60, EN 60950-61, EN 60950-62, EN 60950-63, EN 60950-64, EN 60950-65, EN 60950-66, EN 60950-67, EN 60950-68, EN 60950-69, EN 60950-70, EN 60950-71, EN 60950-72, EN 60950-73, EN 60950-74, EN 60950-75, EN 60950-76, EN 60950-77, EN 60950-78, EN 60950-79, EN 60950-80, EN 60950-81, EN 60950-82, EN 60950-83, EN 60950-84, EN 60950-85, EN 60950-86, EN 60950-87, EN 60950-88, EN 60950-89, EN 60950-90, EN 60950-91, EN 60950-92, EN 60950-93, EN 60950-94, EN 60950-95, EN 60950-96, EN 60950-97, EN 60950-98, EN 60950-99, EN 60950-100

M:G MAGNUM BRANDS GROUP

1800 images and buttons may differ from actual product.

MADE IN CHINA / FABRIQUÉ EN CHINE

OR-FINGDNCE FCC ID - 2ARXKORFINGDNCE

FR

SEIGNAL LUMINEUX DANS FIL

SUPPORT DE TELEPHONE PORTABLE

SELECTION

REVENIR

PIVET DE CONTROLE

TOURNEVEIS REQUIS POUR L'INSTALLATION DES PILES (NON INCLUSES)

PILES 3 AA (NON INCLUSES)

PORT D'ENTREE 5 V

ACTIVE / DESACTIVE

Veuillez lire l'ensemble des instructions de ce guide avant d'utiliser le produit.

Signal lumineux sans fil

Support de téléphone portable

Pivé de contrôle

Sélectionner et revenir

Marche/Arrêt

Port d'entrée 5 V

Piles: 4 x AA

Installation de l'application

Association

Battery Information:

Supporto per cellulare

Padi di comando

Selezione e ritorno

On/Off

Porta di ingresso 5 V

Batterie: 4 x AA

Installazione dell'applicazione

Pairing

ES

SEÑAL LUMINOSA SIN FIL

SOPORTE PARA TELEFONO MOVIL

SELECCIONAR

REVERSO

PILAS 3 AA (NO INCLUIDAS)

PUERTO DE ENTRADA DE 5 V

SE NECESITA DESTORNILLADOR PARA INSTALAR LAS PILAS (NO INCLUIDO)

Lee y observa atentamente esta guía del usuario antes de utilizar el dispositivo.

Señal luminosa de inalámbrico

Soporte para teléfono móvil

Panel del mando a distancia

Seleccionar e regreso

On/Off

Puerto de entrada de 5 V

Pilas: 4 x AA

Instalación de la aplicación

Emparejamiento

Información sobre las pilas:

Handyhalter

Controlle-Pad

Auswahl und rückkehr

Aus/Ein

5-Volt-Eingang

Batterie: 4 x AA

App-Installation

Koppeln

orb

MINI FINGER DANCE MACHINE

Instructions

EN

WIRELESS LIGHT SIGNAL

Mobile Phone Holder

SELECT

RETURN

CONTROL PAD

BATTERIES 4 X AA (NOT INCLUDED)

5V IN PORT

ON/OFF

Please read and follow this user guide thoroughly before use.

Wireless Light Signal

Mobile Phone Holder

Controlle-Pad

On/Off

5V In port

Battery: 4 x AA

App Installation

Pairing

Battery Information:

Supporto per cellulare

Padi di comando

Selezione e ritorno

On/Off

Porta di ingresso 5 V

Batterie: 4 x AA

Installazione dell'applicazione

Pairing

IT

SPA SENZA FILI

SUPPORTO PER CELLULARE

SELEZIONE (selezione)

RETURN (ritorno)

PAD DI COMANDO

BATTERIE 4 X AA (NON INCLUSE)

PORTA DI INGRESSO 5 V

ON/OFF

PRIMA DELL'USO, LEGGERE E ATTENERSI ALLE ISTRUZIONI DI QUESTA GUIDA UTENTE.

Spis senza filii

Supporto per cellulare

Padi di comando

Selezione e ritorno

On/Off

Porta di ingresso 5 V

Batterie: 4 x AA

Installazione dell'applicazione

Pairing

Informazioni sulle batterie

Supporto per cellulare

Padi di comando

Selezione e ritorno

On/Off

Porta di ingresso 5 V

Batterie: 4 x AA

Installazione dell'applicazione

Pairing

DE

KABELLOS-LICHTSIGNAL

HANDYHALTER

AUSWAHL

RÜCKKEHR

CONTROLLEN-PAD

BATTERIEN 4 X AA (NICHT BELEGEND)

5-VOLT-EINGANG

EIN/AUS

Bitte lesen Sie diese Anleitung vor der Verwendung sorgfältig durch und befolgen Sie sie.

Kabellos-Lichtsignal

Handyhalter

Controlle-Pad

Auswahl und rückkehr

Aus/Ein

5-Volt-Eingang

Batterie: 4 x AA

App-Installation

Koppeln

Batteriehinweise:

Handyhalter

Controlle-Pad

Auswahl und rückkehr

Aus/Ein

5-Volt-Eingang

Batterie: 4 x AA

App-Installation

Koppeln