

## **1. Using this manual**

Thank you for choosing Wolki mobile WS055.

This device will provide you with high-quality mobile communication and entertainment based on exceptional technology and high standards.

This manual has been specially designed to guide you through the functions of your device.

### **1.1 Read me first**

- Before using your device , read the entire manual to ensure safe and proper use.
- The descriptions in this manual are based on the default settings of your device.
- The contents of this manual may differ from the product, or from software provided by service providers or carriers, and are subject to change without prior notice.
- Available features and additional services may vary by device, software, or service provider.
- Formatting and delivery of this manual is based on smartphone operating system .

### **2.0 Insert the SIM card**

Insert the SIM when you need a cellular service. Do not insert a memory card into the SIM slot.

### **2.1 Charge the battery**

Before using the device for the first time or when the battery has been unused for an extended period, you must fully charge the battery.

- Use only our approved chargers and cables. Unapproved chargers or cables may cause batteries to explode or damage your device.



## **2.2 Insert a memory card**

Your device accepts Memory cards with maximum capacities of 32GB.

## **3. Getting started**

### **3.1 Turn on or off your device**

Press and hold the Turn on/off key.

### **3.2 Use the touch screen**

Your device's touch screen lets you easily select items or perform functions. Learn basic actions for using the touch screen.

### **3.3 Lock or unlock the touch screen and the keys**

Your device will go in standby mode when you do not use it for a specified period. To turn on the screen, press the Turn on/off key.

●to set standby time, select Settings →Display →Sleep.

### **3.4 Get to know the Home screen**

From the Home screen, you can view your device's status and access applications.

The Home screen has multiple panels. Scroll left or right to view the panels on the Home screen.

#### **Move an item on the Home screen**

Tap and hold an item, and then drag it to a new location.

**Remove an item from the Home screen** Tap and hold an item, and then remove it.



### 3.5 Access applications

Launch applications and take full advantage of features on your device. You can reorganize the application list to match your preferences, or download applications from the Internet to enhance your device's functionality.

### 3.6 Launch multiple applications


Your device allows you to multitask by running multiple applications at the same time. To launch multiple applications, select another application to launch from the Home screen.

## 4. Communication

### 4.1 Calling



Make a call

1 In the application list, select Phone →Keypad, and then enter an area code and a phone number.

2 Select  to make a voice call.

3 Select  to end the call.

#### Answer a call

1 During an incoming call, Select  drag your finger to outside of the large circle then select 

To mute the ringtone, press the side key.


---

2 Select  to end the call.


#### 4.2 Messages

Learn to create and send text (SMS) or multimedia (MMS) messages, and view or manage messages that you have sent or received.

##### Send a text message

1 In the application list, select Messages → 

2 Add recipients:

- Enter phone numbers manually and separate them with a semicolon or a comma.
- Select phone numbers from your call, message, or contact lists by selecting .


3 Select the text field and enter your message text.

#### 5. Entertainment

##### 5.1 Camera

Learn how to take and view photos and videos. You can take photos and record videos.

##### Take a photo

1 In the application list, select Camera. 2 Select  to take a photo.

The photo is saved automatically.

---

## **5.2 Music player**

Learn to listen to your favorite music .

### **Add music files to your device**

- Download from the Internet.
- Download from a computer.
- Receive via BT.
- Copy to your memory card.

### **Play music**

1 In the application list, select Music.

2 Select a music category → a music file.

## **6. Tools**

### **6.1 Calculator**

Learn to perform calculations with your device.

#### **Perform a calculation**

1 In the application list, select Calculator.

2 Use the keys on the screen to perform basic calculations.

### **6.2 other tools : Clock, Calendar.**



**FCC Warning:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

Communications However, there is no guarantee that interference will not occur in a particular



installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Specific Absorption Rate (SAR) information:**

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Before a new



model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body)as required by the FCC. Device types: Smart Phone (FCC ID: 2ARO3-WS055) has also been tested against this SAR limit. SAR information on this and other pad can be viewed on-line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.0 cm from the body. Noncompliance with the above restrictions may result in violation of RF exposure guidelines. To maintain compliance with FCC RF exposure requirements, use accessories should maintain a separation distance between the user's bodies mentioned above, the use of belt clips,





holsters and similar accessories should not contain metallic components in its assembly, the use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

