



User manual




FCC ID: 2ARPHTS-T3

How to wear

Choose suitable earmuffs




Can adjust to comfortable angle



How to take out

Open the Charging Case approximately 90 degrees, then get the earbuds vertically




Multi-function button(MFB)


LED indicator

Microphone


Earmuff



Charging box power indicator light




Contact charging port



Charging box charging port

Charging box charging indicator light



How to pair

Support Bluetooth V2.1+EDR or above version devices connection

Use both the left and right earbuds at the same time

Auto Pairing

- 1.Open the Charging Case (The earbuds is in the case)
- 2.Turn on the phone bluetooth function and search for "V80", the click to connect " V80", after pairing successfully, then you can get the earbuds out to use

Use single earbud

- 1.Take only one earbud,(left one or right one), then close the charging case
- 2.The blue light on earbud will light up, then you can triple-clicks the function button until the earbuds light become the mode of "red light and blue light alternately flashes", then it starts to pair
- 3.Turn on the phone bluetooth function and search for "V80", the click to connect " V80", you can pair single earbud at this time.

Subsequent Use

After first using, the earbuds (The earbuds is in the charging case) will pair to your phone automatically as long as you open the charging case for later use(please make sure that you turn on the phone's bluetooth function)

Earbuds Pairing



- When you fail to pair the earbuds the first time, please take the left and right earbuds out of the charging case at the same time, click the function button twice until one of the earbud show " red light and blue light alternately flashes ", which means that the earbuds pair successfully, then turn the phone's bluetooth function and search for "V80", click to connect "V80", both the earbuds will work.

Function Button

Working Status:


- Press the function button for 5 seconds, you will hear the voice " turn off"
- Answer the phone by short time pressing while calling, as well as end up the calling by short time pressing
- Press the function button for 2 seconds until " DO DO" voice, you can refuse to answer the calling
- Click the function button 3 times until " DO DO" Voice, you can turn on " Siri"function.
- While listening the music, press to Pause/Play music
- Double-Click the multi-function button, you can recall the latest phone call while in standby mode

- Next song : Press the right earbud multi-function button for 2 seconds
- Increase volume : Twice-click the right earphone button



R

- Previous song: Press the left earbud multi-function button for 2 seconds
- Reduce Volume : Twice-click the left earphone button



L

- ★When you turn off one earbud while both two working, the left one can still work without interrupting.
- ★Support Turn on/Turn off the earphone, press the multi-function button for 3 seconds to turn on, press the multi-function button for 5 seconds to turn off.

Earbuds Charging

Both the earbuds and charging case own built-in Battery, please don't disassemble.Please make sure the earbuds are fully charged while first using

Charging Case Charging:

- Charge the Case: Use the Type C cable to charge the case. Plug the cable to USB 5V Output. All the 4 power indicator light alternately flashes while charging
- Full Charge Status: When all the 4 lights are lightening at the same time, it indicates that the case is fully charged, please unplug the cable from the power outlet.
- Power insufficient status: If the case power is insufficient, the The left-most light of the 4 lights is flashing.

Earbud Charging:

- Charge the earbuds : Put both the left and right earbud into the charging case, both the left and right indicator lights show red light, which means they are under charged status (The charging case indicator lights is always on work)
- Full Charge Status:When the left and right earbud are fully charged, both the indicator light will go out , and the charging case will automatically power off.
- Power insufficient Status : When the earbuds power is insufficient, it will send a sound interval "Your battery is running low, please get item charged ", and the indicator red light alternately flashes. If they are powered off while calling, the phone call will automatically transferred to your phone.

Package Lists

- A set of V80 Earbuds
- A User Manuel
- A Type C USB Charging Cable
- A Storage bag
- 2 Pair of Earbuds Caps (Size Large & Small)

Common Troubles and solutions

Problems	Causes	Solutions
Can't start up	Earbuds power is insufficient	Charge the earbuds
No indicator light while charging	Earbuds power is insufficient	Charge the earbuds
The earbud red light flashes	The earbuds didn't put in right place	Please adjust to the right Place
Automatically turn off	Earbuds power is insufficient	Charge the earbuds
Hear Noises	The outside interruption or too far away from your phone	Please go to another place without interruption or get close to your phone
Interrupted Signal	The outside interruption or too far away from your phone	Please go to another place without interruption or get close to your phone
Can't hear via single Earbud	Didn't pair successfully	Please refer to " Earbuds Pairing "steps

warning:

- 1.Please don't put the item where the temperature is too high or too low. the extremes temperature will make the item out of shape and reduce the battery capacity, resulting to shortening lifetime of the item.
- 2.Please don't use the item in rainstorm days, Thunderstorm may breakdown the item and increase the risk of electric shock.
- 3.Please don't dissemble or refit the earbuds for any reasons, which may lead to the item breakdown or burning down, please send the item to the sales agency to repair.
- 4.Only charge with the Type C USB cable within our approval. Cable unapproved or nonstandard may damage the earbuds, even to explosion in extreme case, and the item warranty will be invalid.
- 5.Repeated charging and discharging of the will make the built-in battery performance degraded over time, which is normal to all the rechargeable batteries.
- 6.Please put the item & accessories to the place where the kids or pets an't engage in order to avoid accidents.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.