



(5) ASSY PLAYER CAMERA (DL3-0600)




| ITEM NO. | PART NO.             | DESCRIPTION                                                      | NOTE |
|----------|----------------------|------------------------------------------------------------------|------|
| 1        | DL3-0601             | CAMERA BRKT TYPE P                                               |      |
| 2        | DL3-0602             | CAMERA SUPPORT TYPE P                                            |      |
| 3        | DL3-0603             | CAMERA ACRYLIC TYPE P                                            |      |
| 4        | DL3-0604             | CABLE TAG P.CAMERA                                               |      |
| 101      | KBCR-S03MU-DW9305CM  | USB CAMERA S03MU-DW9305CM                                        |      |
| 102      | DSL01-016900-10      | SPACER BRASS                                                     |      |
| 103      | DSL01-017000-12      | SPACER POM                                                       |      |
| 104      | MV00003800440        | USB CABLE CAMERA                                                 |      |
| 201      | M SCR PH M2X4 BLK    | PAN HEAD MACHINE SCREW M2X4MM. TRIVALENT BLACK                   |      |
| 202      | M SCR PH M3X6 P3 BLK | PAN HEAD MACHINE SCREW M3X6MM P3 FS WITH WASHER. TRIVALENT BLACK |      |

## (6) ASSY TARGET CAMERA (DL3-0700)




| ITEM NO. | PART NO.             | DESCRIPTION                                                      | NOTE |
|----------|----------------------|------------------------------------------------------------------|------|
| 1        | DL3-0701             | CAMERA BRKT TYPE T                                               |      |
| 2        | DL3-0702             | CAMERA SUPPORT TYPE T                                            |      |
| 3        | DL3-0703             | CAMERA HOLDER                                                    |      |
| 4        | DL3-0704             | CABLE TAG T.CAMERA                                               |      |
| 101      | KBCR-S03MU-HPB1007   | USB CAMERA S03MU-HPB1007                                         |      |
| 102      | DSL01-017000-12      | SPACER POM                                                       |      |
| 103      | MV00003800440        | USB CABLE CAMERA                                                 |      |
| 201      | M SCR PH M2X4 BLK    | PAN HEAD MACHINE SCREW M2X4MM. TRIVALENT BLACK                   |      |
| 202      | M SCR PH M3X6 P3 BLK | PAN HEAD MACHINE SCREW M3X6MM P3 FS WITH WASHER. TRIVALENT BLACK |      |

## (7) ASSY SIDE LED L (DL3-1050)



| ITEM NO. | PART NO.          | DESCRIPTION                                      | NOTE |
|----------|-------------------|--------------------------------------------------|------|
| 1        | DL3-1051          | SIDE ACRYLIC SUPPORT L                           |      |
| 2        | DL3-1052WE        | SIDE ACRYLIC L WE                                |      |
| 3        | DL3-1053          | SILICONE TUBE                                    |      |
| 4        | DL3-1065          | TAPE LED L=1000 W WH                             |      |
| 5        | DL3-1056          | STICKER SIDE ACRYLIC                             |      |
| 103      | J2527             | VINYL TAPE No. 21 (L=15MM)                       |      |
| 104      |                   | CORD KEEP                                        |      |
| 201      | M SCR TH M4X6 BLK | TRUSS HEAD MACHINE SCREW M4X6MM. TRIVALENT BLACK |      |


(8) ASSY SIDE LED R (DL3-1080)



| ITEM NO. | PART NO.          | DESCRIPTION                                      | NOTE |
|----------|-------------------|--------------------------------------------------|------|
| 1        | DL3-1081          | SIDE ACRYLIC SUPPORT R                           |      |
| 2        | DL3-1082WE        | SIDE ACRYLIC R WE                                |      |
| 3        | DL3-1053          | SILICONE TUBE                                    |      |
| 4        | DL3-1065          | TAPE LED L=1000 W WH                             |      |
| 5        | DL3-1056          | STICKER SIDE ACRYLIC                             |      |
| 103      | J2527             | VINYL TAPE No. 21 (L=15MM)                       |      |
| 104      |                   | CORD KEEP                                        |      |
| 201      | M SCR TH M4X6 BLK | TRUSS HEAD MACHINE SCREW M4X6MM. TRIVALENT BLACK |      |

(9) ASSY TARGET DOOR (DL3-1150)

(D-1/3)




**(9) ASSY TARGET DOOR (DL3-1150)****(D-2/3)**

| ITEM NO. | PART NO.             | DESCRIPTION                                     | NOTE |
|----------|----------------------|-------------------------------------------------|------|
| 1        | DL3-1200             | ASSY TARGET                                     |      |
| 2        | DL3-1151WE           | TARGET DOOR BOARD WE                            |      |
| 3        | DL3-1103             | DOOR LOCK PLATE                                 |      |
| 4        | DL3-1104             | LOCK LINK                                       |      |
| 5        | DL3-1105             | TARGET KEY TNG                                  |      |
| 6        | DL3-1106             | TARGET KEY SUB TNG                              |      |
| 7        | DL3-1107             | DOPPLER SENS BRKT                               |      |
| 8        | DL3-1108             | STANDING NAVI BOX 1                             |      |
| 9        | DL3-1109             | STANDING NAVI BOX 2                             |      |
| 10       | DL3-1110             | PLATE LOCK RETAINER FLAT                        |      |
| 11       | DL3-1111             | OUT BOARD SEGMENT                               |      |
| 12       | DL3-1112             | OUT BOARD LENS                                  |      |
| 13       | DL3-1113             | SENSOR COVER                                    |      |
| 14       | DL3-1114             | SENSOR COVER CYLINDER                           |      |
| 15       | DL3-1115             | NUMBER STICKER                                  |      |
| 16       | DL3-1124             | TARGET NUT M8X50 BLACK                          |      |
| 17       | DL3-1117             | DIFFUSION SHEET                                 |      |
| 18       | DL2-1057             | TARGET LED BD COVER                             |      |
| 19       | DL2-1054             | BOLT PLATE                                      |      |
| 20       | DL3-5007             | LED BD FOR OUT BOARD                            |      |
| 21       | DL3-5005             | LED BD FOR STANDING NAVI                        |      |
| 22       | DL3-1152             | TARGET DOOR BOARD PLATE                         |      |
| 23       | DL3-1153EG           | STICKER CAUTION TARGET ENG                      |      |
| 24       | DL3-1154             | TARGET DOOR BOARD BRKT                          |      |
| 101      | 220-5793-1-A001      | CLY LOCK MASTER W/O KEY A001                    |      |
| 102      | KPEG110W08528A       | SHOCK SENSOR                                    |      |
| 103      | GZV-D01              | SPEED SENSOR                                    |      |
| 104      | XT-DQ500A            | FULL BIT SENSOR                                 |      |
| 105      | TM-182-816-16        | URETHANE ROLL STOCK                             |      |
| 106      | DSL01-016900-10      | SPACER BRASS                                    |      |
| 107      | BS-2010BE            | SPACER POM                                      |      |
| 108      | DSL01-016400-10      | WASHER POM                                      |      |
| 109      | PDV-170BK            | RELEASABLE PUSH MOUNT TIES                      |      |
| 110      |                      | CORD KEEP                                       |      |
| 111      | CC-1005              | CORD CLIP 1005                                  |      |
| 112      | DSL01-017900-10      | GROMMET                                         |      |
| 113      | No. 500-10           | DOUBLE SIDED TAPE (L=30MM)                      |      |
| 201      | M SCR PH M2X4 BLK    | PAN HEAD MACHINE SCREW M2X4MM. TRIVALENT BLACK  |      |
| 202      | M SCR PH M3X8 P3     | PAN HEAD MACHINE SCREW M3X8MM P3 FS             |      |
| 203      | M SCR PH M3X6 P4     | PAN HEAD MACHINE SCREW M3X6MM P4 FS             |      |
| 204      | M SCR PH M4X12 P3    | PAN HEAD MACHINE SCREW M4X12MM P3 FS            |      |
| 205      | M SCR PH M4X20 P3    | PAN HEAD MACHINE SCREW M4X20MM P3 FS            |      |
| 206      | WOOD SCR PH 2X10     | Φ 2X10MM ROUND WOOD SCREW. TRIVALEN WHITE       |      |
| 207      | WOOD SCR PH 3X8      | Φ 3X8MM ROUND WOOD SCREW. TRIVALEN WHITE        |      |
| 208      | WOOD SCR TH 4X10 BLK | Φ 4X10MM TRUSS HEAD WOOD SCREW. TRIVALENT BLACK |      |
| 209      | FLG NUT M4           | FLANGE NUT M4                                   |      |
| 210      | FLT WASHER 16-4-1.6  | FLAT WASHER 16-4.0-1.6                          |      |

**(9) ASSY TARGET DOOR (DL3-1150)****(D-3/3)**


| ITEM NO. | PART NO.                | DESCRIPTION                                            | NOTE |
|----------|-------------------------|--------------------------------------------------------|------|
| 211      | PITACK M SCR PH M4X8 P3 | PITACK PAN HEAD MACHINE SCREW M4X8MM P3 FS WITH WASHER |      |
| 212      | M SCR PH M4X8 P3        | PAN HEAD MACHINE SCREW M4X8MM P3 FS                    |      |
| 213      | FLT WASHER M3           | FLAT WASHER M3                                         |      |
| 214      | CAP NUT M4              | CAP NUT M4                                             |      |
| 301      | DL3-6004                | WH NUMBER LED                                          |      |
| 302      | DL3-6005                | WH NUMBER LED JP                                       |      |
| 303      | DL3-6006                | WH OUTBOARD SENSOR                                     |      |
| 304      | DL3-6027                | WH NUMBER LED JP W TUBE                                |      |



**(10) ASSY TARGET (DL3-1200)****(D-2/2)**


| ITEM NO. | PART NO.                | DESCRIPTION                                                      | NOTE |
|----------|-------------------------|------------------------------------------------------------------|------|
| 1        | DLT-1201XT-3BK          | SPIDER BLACK                                                     |      |
| 2        | DLT-1252-3BK            | DOUBLE BULL SEGMENT BLACK                                        |      |
| 3        | DLT-1253                | SINGLE BULL SEGMENT                                              |      |
| 4        | DLT-1254                | SINGLE PIE SEGMENT                                               |      |
| 5        | DLT-1255                | TRIPLE SEGMENT                                                   |      |
| 6        | DLT-1256                | SINGLE BLOCK SEGMENT                                             |      |
| 7        | DLT-1257                | DOUBLE SEGMENT                                                   |      |
| 8        | DL3-1210                | TARGET LED REFLECT SPIDER FOR DL3                                |      |
| 9        | DLT-1212                | MENBRANE SPACER SHEET                                            |      |
| 10       | DL3-1213                | TARGET BASE PLATE                                                |      |
| 11       | DL2-1214                | LED BASE BRKT                                                    |      |
| 12       | DL3-1215WE              | SPIDER WALL WE                                                   |      |
| 13       | DL3-1216                | SPIDER WALL BULL                                                 |      |
| 14       | DLT-1261                | MENBRANE PROTECT SHEET                                           |      |
| 15       | DLT-0002                | STICKER POSITIONING CABI                                         |      |
| 101      | DL3-5003                | TARGET LED BOARD                                                 |      |
| 102      | 509-6204                | MENBRANE SW S-SGA-1789                                           |      |
| 103      | DSL01-011200-10         | FLANGE BUSH                                                      |      |
| 201      | M SCR PH M4X8 P3 BLK    | PAN HEAD MACHINE SCREW M4X8MM P3 FS WITH WASHER. TRIVALENT BLACK |      |
| 202      | M SCR PH M4X12 P2 BLK   | PAN HEAD MACHINE SCREW M4X12MM P2 S WITH WASHER. TRIVALENT BLACK |      |
| 203      | FLT WASHER 16-4-1.6 BLK | FLAT WASHER 16-4-1.6. TRIVALENT BLACK                            |      |

(11) ASSY SPEAKER (DL3-1300)



| ITEM NO. | PART NO.          | DESCRIPTION                          | NOTE |
|----------|-------------------|--------------------------------------|------|
| 1        | DL3-1301          | SPEAKER BOX                          |      |
| 2        | DL3-1302          | SPEAKER SUPPORT                      |      |
| 101      | F05008H0          | SPEAKER                              |      |
| 102      |                   | CORD CLIP 1005                       |      |
| 201      | M SCR PH M4X16 P3 | PAN HEAD MACHINE SCREW M4X16MM P3 FS |      |
| 202      | WOOD SCR TH 4X10  | Φ 4X10MM TRUSS HEAD WOOD SCREW       |      |
| 301      | DL3-6007          | WH SPEAKER                           |      |


(12) ASSY TOUCH PANEL DISPLAY (DL3-1410)



| ITEM NO. | PART NO.          | DESCRIPTION                          | NOTE |
|----------|-------------------|--------------------------------------|------|
| 1        | DL3-1406          | LOWER LCD BASE TOVIS                 |      |
| 2        | DL3-1402          | AC ADP BRKT                          |      |
| 3        | DL3-1403          | CUSHON FOR AC ADP                    |      |
| 101      | L24G7LTMDL        | TOVIS 23.8inch TOUCH PANEL DISPLAY   |      |
| 102      |                   | CLAMP                                |      |
| 103      | KL7K T 48X30X15-C | FERRITE CORE                         |      |
| 104      | HAS060243-K1      | POWER ADAPTOR 24V WEIHAI             |      |
| 201      | M SCR PH M4X10 P3 | PAN HEAD MACHINE SCREW M4X10MM P3 FS |      |
| 202      | FLG NUT M4        | FLANGE NUT M4                        |      |

# (13) ASSY LOWER CABI (DL3-1500)

(D-1/3)



**(13) ASSY LOWER CABI (DL3-1500)****(D-2/3)**


| ITEM NO. | PART NO.              | DESCRIPTION                  | NOTE |
|----------|-----------------------|------------------------------|------|
| 1        | DL3-1600              | ASSY CONTROL PANEL           |      |
| 2        | DL3-1700              | ASSY COIN SELECTOR           |      |
| 3        | DL3-1760              | ASSY COUNTER                 |      |
| 4        | DL3-1800              | ASSY LOWER DOOR L            |      |
| 5        | DL3-1850              | ASSY LOWER DOOR R            |      |
| 6        | DL3-1900              | ASSY WOOFER                  |      |
| 7        | DL3-2050              | ASSY AC PANEL                |      |
| 8        | DL3-2100              | ASSY CASH BOX                |      |
| 9        | DL3-2250              | ASSY CENTER RIB              |      |
| 10       | ICS-60B1-1A/GTX1650   | ASSY PCB ENNOCONN            |      |
| 11       | DL3-4100              | ASSY MAIN IO BD              |      |
| 12       | DL3-1501              | LOWER CABI                   |      |
| 13       | DL3-1504              | STOPPER BRKT L               |      |
| 14       | DL3-1505              | STOPPER BRKT R               |      |
| 15       | DL3-1506              | LOCK BAR GUIDE               |      |
| 16       | DL3-1507              | STEP COVER                   |      |
| 17       | DL3-1508              | RUBBER SHEET                 |      |
| 18       | DL3-1509              | COIN CHUTE                   |      |
| 19       | DL3-1510              | EXTENSION LID                |      |
| 20       | DL3-1013              | KEY LOCK PLATE               |      |
| 21       | DL3-2004              | AC UNIT COVER                |      |
| 22       | DL3-2003              | AC UNIT SUPPORT              |      |
| 23       | DL3-1511              | STICKER PL                   |      |
| 24       | DL3-1513              | CABLE TAG STEREO             |      |
| 25       | DL3-1514              | CABLE TAG MAIN I/O           |      |
| 26       | DL3-1816              | STICKER CONN POS             |      |
| 27       | DL3-1515EG            | STICKER URL BARCORD EG       |      |
| 28       | DL3-1516              | EM ABSORPTION SHEET          |      |
| 101      | MR-65N                | CASTER D65 H82 FIX           |      |
| 102      | MG-65N                | CASTER D65 H82 FREE          |      |
| 103      | PGBAA-034800-10       | LEG ADJUSTER W/O NUT         |      |
| 104      | DSL01-020700-10       | ONETOUCH BUSH                |      |
| 105      | DSL01-020600-10       | ONETOUCH BUSH                |      |
| 106      | DSL01-016400-10       | WASHER POM                   |      |
| 107      |                       | CLAMP                        |      |
| 108      |                       | CLAMP                        |      |
| 109      |                       | CLAMP                        |      |
| 110      |                       | CORD KEEP                    |      |
| 111      | MV00003800370         | AC CABLE 3P PLUG-SOCKET      |      |
| 112      | MV00003800760         | STEREO 3.5 CABLE L=1500MM    |      |
| 113      | MV00003800410         | USB2.0 CABLE A-B TYPE 1800MM |      |
| 114      | AC-F01FB01            | AC OUTLET                    |      |
| 116      | S6B UH 16X28X9(0930A) | FERRITE CORE                 |      |
| 117      |                       | CABLE TIE                    |      |

**(13) ASSY LOWER CABI (DL3-1500)****(D-3/3)**

| ITEM NO. | PART NO.                | DESCRIPTION                                                      | NOTE |
|----------|-------------------------|------------------------------------------------------------------|------|
| 201      | M SCR PH M4X8 P3 BLK    | PAN HEAD MACHINE SCREW M4X8MM P3 FS WITH WASHER. TRIVALENT BLACK |      |
| 202      | M SCR PH M4X10 P3       | PAN HEAD MACHINE SCREW M4X10MM P3 FS                             |      |
| 203      | M SCR PH M4X16 P3       | PAN HEAD MACHINE SCREW M4X16MM P3 FS                             |      |
| 204      | M SCR PH M4X25 P3       | PAN HEAD MACHINE SCREW M4X25MM P3 FS                             |      |
| 205      | M SCR TH M4X10 BLK      | TRUSS HEAD MACHINE SCREW M4X10MM. TRIVALENT BLACK                |      |
| 206      | FLT WASHER 16-4.4-1.6   | FLAT WASHER 16-4.4-1.6                                           |      |
| 207      | PITACK M SCR PH M4X8 P3 | PITACK PAN HEAD MACHINE SCREW M4X8MM P3 FS WITH WASHER           |      |
| 208      | UPSET BOLT M6X20 P3     | CROSS RECESSED UPSET BOLT<br>M6X20MM P3 FS WITH WASHER           |      |
| 301      | DL3-6200                | ASSY WH LOWER CABINET                                            |      |
| 302      | DL3-6017                | WH AC OUTLET                                                     |      |
| 303      | DL3-6022                | WH EARTH OUTLET                                                  |      |
| 304      | DL3-6023                | WH WITHOUT TRANCE EXT                                            |      |

(14) ASSY CONTROL PANEL (DL3-1600)

(D-1/2)




**(14) ASSY CONTROL PANEL (DL3-1630)****(D-2/2)**

| ITEM NO. | PART NO.                | DESCRIPTION                                               | NOTE |
|----------|-------------------------|-----------------------------------------------------------|------|
| 1        | DL3-1601                | CONTROL PNL                                               |      |
| 2        | DL3-1602                | RFID ANT HOLDER COVER                                     |      |
| 3        | DL3-1650                | ASSY DL CREDIT                                            |      |
| 4        | DL3-1604                | LIVE CREDIT PNL R                                         |      |
| 5        | (DL3-1605)              | (COIN ENTRY)                                              |      |
| 6        | (DL3-1606)              | (CANSEL ROD)                                              |      |
| 7        | DL3-1607                | CARD GUIDE A                                              |      |
| 8        | DL3-1608                | CARD GUIDE B                                              |      |
| 9        | DL3-1609                | CARD GUIDE C                                              |      |
| 10       | DL3-1610                | CARD LED ACRYLIC                                          |      |
| 11       | DL3-1611                | CONPANE BRKT                                              |      |
| 12       | DL3-1612                | CONPANE HOOK L                                            |      |
| 13       | DL3-1613                | CONPANE HOOK R                                            |      |
| 14       | DL3-1614 (HK)           | COIN CHUTE BRKT 1 (HK)                                    |      |
| 15       | DL3-1615 (HK)           | COIN CHUTE BRKT 2 (HK)                                    |      |
| 16       | DL3-1616 (HK)           | COIN CHUTE OUT A (HK)                                     |      |
| 17       | DL3-1617 (HK)           | COIN CHUTE OUT B (HK)                                     |      |
| 18       | DL3-1618                | CARD LED BRKT                                             |      |
| 19       | DL3-1619                | PACKING RUBBER FOR CONPANE                                |      |
| 20       | DL3-1620                | PACKING RUBBER S FOR CARD LED                             |      |
| 21       | DL3-1621                | PACKING RUBBER L FOR CARD LED                             |      |
| 22       | (DL3-1624)              | (SPRING FOR COIN CANSEL)                                  |      |
| 23       | (DL3-1623)              | (STICKER DENOMINATION)                                    |      |
| 24       | (DL3-1651)              | (DL CREDIT CARD READER COVER L)                           |      |
| 25       | (DL3-1652)              | (STICKER COVER L)                                         |      |
| 26       | (DL3-1632)              | (COIN ENTRY CAP L)                                        |      |
| 101      | ME-MR23M4-C-SG          | RFID CARD RW BD W/ANT X4 233C                             |      |
| 102      | DL3-5008                | LED BD DL                                                 |      |
| 103      |                         | CLAMP                                                     |      |
| 104      |                         | CORD KEEP                                                 |      |
| 105      |                         | CABLE TIE                                                 |      |
| 201      | M SCR PH M3X10 P3       | PAN HEAD MACHINE SCREW M3X10MM P3 FS                      |      |
| 202      | M SCR PH M3X16 P3       | PAN HEAD MACHINE SCREW M3X16MM P3 FS                      |      |
| 203      | TAP SCR PH 3X8          | TAPPING SCREW 3X8MM                                       |      |
| 204      | TAP SCR PH 4X8          | TAPPING SCREW 4X8MM                                       |      |
| 205      | E RING 5MM              | E RING 5MM                                                |      |
| 206      | HEX SKT ELH M4X8 BLK    | LOW HEAD HEXAGON SOCKET CAP SCREW M4X8MM. TRIVALENT BLACK |      |
| 207      | PITACK M SCR PH M4X8 P3 | PITACK PAN HEAD MACHINE SCREW M4X8MM P3 FS WITH WASHER    |      |
| 301      | DL3-6008                | WH RFID CARD RW BD POW                                    |      |
| 302      | DL3-6009                | WH CARD HOLDER                                            |      |
| 303      | DL3-6029                | WH DSUB RW                                                |      |
| 304      | DL3-6026                | WH EARTH COIN CHUTE                                       |      |


## (15) ASSY COIN SELECTOR (DL3-1700 / 1710)

"(There are some units such as those for China, which were manufactured on specification without coin selector.)"



| ITEM NO. | PART NO.           | DESCRIPTION                          | NOTE |
|----------|--------------------|--------------------------------------|------|
| 1        | DL3-1701           | COIN SELECTOR BRKT A                 |      |
| 2        | DL3-1702           | COIN SELECTOR BRKT B                 |      |
| 3        | DL3-1703           | COIN SELECTOR BRKT C                 |      |
| 4        | DL3-1704           | REJECT PLATE                         |      |
| 5        | DL3-1705           | SPRING FOR SELECTOR                  |      |
| 6        | DL3-1706           | TORSION SPRING FOR SELECTOR          |      |
| 101      | (DP2- ~ _D3D CS ~) | (COIN SELECTOR_DP2- ~ D3D CS)        |      |
| 102      | DSL01-015200-10    | SPACER POM                           |      |
| 103      | DSL01-009700-10    | SPACER POM                           |      |
| 201      | M SCR PH M3X6 P3   | PAN HEAD MACHINE SCREW M3X6MM P3 FS  |      |
| 202      | M SCR PH M3X10 P3  | PAN HEAD MACHINE SCREW M3X10MM P3 FS |      |
| 203      | FLT WASHER M6      | FLAT WASHER M6 t=1.0                 |      |
| 301      | DL3-6011           | WH COIN                              |      |

(16) ASSY COUNTER (DL3-1760)



| ITEM NO. | PART NO.       | DESCRIPTION        | NOTE |
|----------|----------------|--------------------|------|
| 1        | DL3-1761       | COUNTER BRKT       |      |
| 2        | DL3-1752       | STICKER TEST       |      |
| 3        | DL3-1753       | STICKER SERVICE    |      |
| 101      | 502B-2R        | PUSH BUTTON SWITCH |      |
| 102      | OA-126CL DC12V | COUNTER            |      |
| 103      |                | CLAMP              |      |
| 301      | DL3-6012       | WH TEST SERVICE    |      |

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13

10

11

12

13

8

**(17) ASSY LOWER DOOR L (DL3-1800)****(D-2/2)**

| ITEM NO. | PART NO.                | DESCRIPTION                                                      | NOTE |
|----------|-------------------------|------------------------------------------------------------------|------|
| 201      | M SCR PH M3X6 P3        | PAN HEAD MACHINE SCREW M3X6MM P3 FS                              |      |
| 202      | M SCR TH M4X6 BLK       | PAN HEAD MACHINE SCREW M4X6MM P3 FS WITH WASHER. TRIVALENT BLACK |      |
| 203      | FLG NUT M4              | FLANGE NUT M4                                                    |      |
| 204      | E RING 5MM              | E RING 5MM                                                       |      |
| 205      | PITACK M SCR PH M4X8 P3 | PITACK PAN HEAD MACHINE SCREW M4X8MM P3 FS WITH WASHER           |      |
| 206      | FLT WASHER M6           | FLAT WASHER M6                                                   |      |
| 301      | DL3-6020                | WH EARTH DOOR                                                    |      |

1

2

3

4

5

6

7

8

9

10


11

12

13

## (18) ASSY LOWER DOOR R (DL3-1850)

(D-1/2)



| ITEM NO. | PART NO.        | DESCRIPTION                  | NOTE |
|----------|-----------------|------------------------------|------|
| 1        | DL3-1851        | DOOR BASE FRAME R            |      |
| 2        | DL3-1852        | DOOR ACRYLIC SUPPORT R       |      |
| 3        | DL3-1853        | DOOR LINK R                  |      |
| 4        | DL3-1804        | DOOR KEY TANG                |      |
| 5        | DL3-1805        | DOOR LOCK BAR                |      |
| 6        | DL3-1806        | DOOR RIB                     |      |
| 7        | DL3-1854WE      | DOOR HINGE R WE              |      |
| 8        | DL3-1855        | HINGE BRKT R                 |      |
| 9        | DL3-1856WE      | DOOR ACRYLIC R WE            |      |
| 10       | DL3-1857        | DOOR BASE CAP R              |      |
| 11       | DL3-1811        | SPRING FOR DOOR              |      |
| 12       | DL3-1503        | DOOR STOPPER LINK R          |      |
| 13       | DL3-1820        | TAPE LED L=700 W WH          |      |
| 101      | 220-5793-1-A002 | CLY LOCK MASTER W/O KEY A002 |      |
| 102      |                 | CORD KEEP                    |      |
| 103      | DSL01-016400-10 | WASHER POM                   |      |

**(18) ASSY LOWER DOOR R (DL3-1850)****(D-2/2)**

| ITEM NO. | PART NO.                | DESCRIPTION                                                      | NOTE |
|----------|-------------------------|------------------------------------------------------------------|------|
| 201      | M SCR PH M3X6 P3        | PAN HEAD MACHINE SCREW M3X6MM P3 FS                              |      |
| 202      | M SCR TH M4X6 BLK       | PAN HEAD MACHINE SCREW M4X6MM P3 FS WITH WASHER. TRIVALENT BLACK |      |
| 203      | FLG NUT M4              | FLANGE NUT M4                                                    |      |
| 204      | E RING 5MM              | E RING 5MM                                                       |      |
| 205      | PITACK M SCR PH M4X8 P3 | PITACK PAN HEAD MACHINE SCREW M4X8MM P3 FS WITH WASHER           |      |
| 206      | FLT WASHER M6           | FLAT WASHER M6                                                   |      |
| 301      | DL3-6020                | WH EARTH DOOR                                                    |      |

1

2

3

4

5

6

7

8

9


10

11

12


13

(19) ASSY WOOFER (DL3-1900)




| ITEM NO. | PART NO.              | DESCRIPTION                                | NOTE |
|----------|-----------------------|--------------------------------------------|------|
| 1        | DL3-1901              | WOOFER BOX                                 |      |
| 2        | DL3-1902              | WOOFER BOX TOP BOARD                       |      |
| 3        | DL3-1903              | WOOFER BOX BRKT                            |      |
| 4        | DL3-1904              | PC BASE HOOK                               |      |
| 101      | W00712D1              | WOOFER                                     |      |
| 102      |                       | CLAMP                                      |      |
| 201      | M SCR PH M4X16 P3     | PAN HEAD MACHINE SCREW M4X16MM P3 FS       |      |
| 202      | M SCR PH M4X20 P3     | PAN HEAD MACHINE SCREW M4X20MM P3 FS       |      |
| 203      | WOOD SCR TH 4X20      | Φ 4X20MM TRUSS HEAD WOOD SCREW             |      |
| 204      | FLT WASHER 16-4.4-1.6 | FLAT WASHER 16-4.4-1.6                     |      |
| 205      | WOOD SCR FH 3X12      | Φ 3X12MM COUNTERSUNK SCRW. TRIVALENT WHITE |      |
| 301      | DL3-6014              | WH WOOFER SPEAKER                          |      |

## (20) ASSY AC PANEL (DL3-2050)




| ITEM NO. | PART NO.             | DESCRIPTION                                                     | NOTE |
|----------|----------------------|-----------------------------------------------------------------|------|
| 1        | DL3-2001             | AC UNIT BRKT                                                    |      |
| 2        | DL3-2053             | STICKER C.P                                                     |      |
| 3        | DL3-2052             | STICKER EARTH                                                   |      |
| 4        | DL3-1020             | CABLE TAG NETWORK                                               |      |
| 101      | AC6AMF-PL1000        | PANELMOUNT LAN CABLE                                            |      |
| 102      | CF-LA-2KZ2-5C        | POWER SW                                                        |      |
| 103      | YB06A1-B             | AC INLET                                                        |      |
| 104      | T9-611P-5.0A         | CIRCUIT PROTECTOR 5A                                            |      |
| 105      |                      | CABLE TIE                                                       |      |
| 201      | M SCR PH M3X8 BLK P3 | PAN HEAD MACHINE SCREW M3X8MM TRIVALENT BLACK P3 FS WITH WASHER |      |
| 202      | M SCR FH M3X8 BLK    | FLAT HEAD MACHINE SCREW M3X8MM TRIVALENT BLACK                  |      |
| 203      | FLG NUT M4           | FLANGE NUT M4                                                   |      |
| 301      | DL3-6015             | WH INLET L                                                      |      |
| 302      | DL3-6016             | WH J8 CONN                                                      |      |
| 303      | DL3-6018             | WH EARTH AC                                                     |      |
| 304      | DL3-6021             | WH EARTH OUTLET EXT                                             |      |

(21) ASSY CASH BOX (DL3-2100)




| ITEM NO. | PART NO. | DESCRIPTION     | NOTE |
|----------|----------|-----------------|------|
| 1        | DL3-2101 | CASH BOX        |      |
| 2        | DL3-2102 | CASH KEY TANG   |      |
| 101      | 220-5794 | CLY LOCK W/KEYS |      |

## (22) ASSY CENTER RIB (DL3-2250)




| ITEM NO. | PART NO.         | DESCRIPTION                         | NOTE |
|----------|------------------|-------------------------------------|------|
| 1        | DL3-2251         | CENTER RIB                          |      |
| 2        | DL3-2252         | REJECT FLAP HOLDER L                |      |
| 3        | DL3-2253         | REJECT FLAP HOLDER R                |      |
| 4        | (DL3-2204)       | (REJECT CAP PLATE)                  |      |
| 101      | PGBKK-011100-10  | REJECT FLAP                         |      |
| 101      | PGBKK-011200-10  | REJECT FLAP ROLLER                  |      |
| 101      | PGBKK-011300-10  | REJECT FLAP PIN                     |      |
| 102      |                  | CLAMP                               |      |
| 201      | M SCR PH M3X6 P3 | PAN HEAD MACHINE SCREW M3X6MM P3 FS |      |
| 202      | FLG NUT M4       | FLANGE NUT M4                       |      |

(23) ASSY MAIN IO BD (DL3-4100)



| ITEM NO. | PART NO.           | DESCRIPTION                                | NOTE |
|----------|--------------------|--------------------------------------------|------|
| 1        | DL3-4101           | IO BD BASE WOODEN                          |      |
| 2        | DL3-4102           | PWB PROTECTOR                              |      |
| 3        | DL3-4110           | MAIN IO BD                                 |      |
| 101      | 14-1466AR          | 2.1CH EQ AMP BD                            |      |
| 102      | CBH01-042200-10    | L-LOCK                                     |      |
| 103      |                    | CLAMP                                      |      |
| 201      | M SCR PH M3X6 P4   | PAN HEAD MACHINE SCREW M3X6MM P4 FS        |      |
| 202      | WOOD SCR TH 3.5X16 | Φ 3.5X16MM TRUSS HEAD WOOD SCREW           |      |
| 203      | WOOD SCR FH 3X10   | Φ 3X10MM COUNTERSUNK SCRW. TRIVALENT WHITE |      |
| 204      | WOOD SCR FH 3X12   | Φ 3X12MM COUNTERSUNK SCRW. TRIVALENT WHITE |      |

(25) ASSY DL CREDIT (DL3-1650)



| ITEM NO. | PART NO.              | DESCRIPTION                                                  | NOTE |
|----------|-----------------------|--------------------------------------------------------------|------|
| 1        | DL3-1653              | DL CREDIT CARD READER BRKT                                   |      |
| 2        | DL3-1654              | CABLE TAG DLCR                                               |      |
| 3        | DL3-0009              | STICKER FCC DL CR                                            |      |
| 101      | DLI-00524-B           | DARTSLIVE Credit Card Reader for DL3 JSC330V52-UL (LED Back) |      |
| 102      | F580410 (DLI-00526-B) | USB 2.0 AM TO HOUSING 1.0M BLACK                             |      |
| 103      |                       | CORD KEEP 103G                                               |      |
| 201      | M SCR PH M2X8         | PAN HEAD MACHINE SCREW M2X8                                  |      |

## 12 Wire Color Correspondence Table


The wire colors used in the comprehensive wiring diagram in the next chapter are as follows.

| CODE | WIRE COLOR  |
|------|-------------|
| RE   | RED         |
| BL   | BLUE        |
| YE   | YELLOW      |
| GR   | GREEN       |
| WH   | WHITE       |
| OR   | ORANGE      |
| BK   | BLACK       |
| GY   | GRAY        |
| PK   | PINK        |
| SB   | SKYBLUE     |
| BR   | BROWN       |
| PU   | PURPLE      |
| LG   | LIGHT GREEN |

Note 1. The characters after WIRE COLOR CODE indicate the thickness of WIRE.

(16) or [16]: AWG16  
(18) or [18]: AWG18  
(20) or [20]: AWG20  
None : AWG22  
(24) or [24]: AWG24

## 13 Comprehensive Wiring Diagram





For general inquiries:

## **DARTSLIVE Support Desk**

<https://www.dartslive.com>

\* Please note that this support desk is not accepting inquiries regarding the machine and the parts.

Please contact the retailer for such inquiries.

For basic troubleshooting, go to the following "Product Support Page".



<http://www.dartslive.jp/info/support/eng/index.html>

For remarks for the radio equipment directive in each country or region, go to "Product R.E.D. Remark Page".



<https://dartslive-product-support.helpscoutdocs.com/article/100-product-r-e-d-remark-page>

## **DARTSLIVE Co.,Ltd.**

Sumitomo Fudosan Osaki Garden Tower, 1-1-1 Nishi-Shinagawa, Shinagawa-ku,  
Tokyo 141-0033, Japan

<http://www.dartslive.com/corp/jp/contact/>

facsimile +81-50-3153-7982

The information herein contained is as of November 2022.

**4th edition**

November 2022