

16044 Koozie Speaker

Instruction Manual (Read before proceeding)

Power:

Works on internal rechargeable Lithium battery. Please charge your speaker fully before first use.

To charge the battery use the micro USB cable into the USB port on a computer for charging.

A red light will indicate the charging situation. When battery is full, the red light will turn off automatically.

Disconnect the USB cable when it is fully charged

Playing Music via Bluetooth:

Turn your Bluetooth speaker on by sliding the power switch located on the side of the speaker to "ON" position.

The blue indicator light will flash quickly. This indicates that the speaker is in pairing mode and searching for your Bluetooth device.

Turn on the Bluetooth function on your device, search the speaker named "KoozieSpeaker" and select it, your device will pair without a password. The Blue light will begin to flash slowly after pair is complete.

Start playing music on your device. Keep your device within 33ft (10 meters) of your speaker.

Adjust the volume of your device to a comfortable level. Turn off the unit when not in use.

Caution:

This is not a toy. Please keep away from small children.

Please keep away from water / heat.

Low power may cause poor connection even no working of Bluetooth.

Do not over-charge the battery.

Battery pack shall not be exposed to excessive heat such as sunshine, fire or the like.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

The device must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body