


WIRELESS SPEAKER INSTRUCTION MANUAL



PRODUCT SPECIFICATIONS

Wireless version: 5.3
Distance: 10m
Speaker battery: 1200mAh
Charging time: 2~3h
Playing time: 2~4h
Speaker power: 5W*2
Product size: 84 x 84 x 173mm
Function: Bluetooth, TWS, TF Card, USB, FM, LED



1. ON/OFF
(Long press to ON/OFF;
Short press to change LED Light mode)
2. Play / Pause
3. Previous track (short press) /
Volume down (long press)
4. FM Mode
5. Next track (short press) /
Volume up (long press)



6. Type-C charging port
7. USB port
8. TF Card slot

WIRELESS SPEAKER

Long press Power button to turn ON/OFF the speaker. Open your device (phone, pad etc) and search for “BS-09” to connect, an alert will sound indicating speaker is connected, then you can start to playing music through the speaker.

TWS FUNCTION

Long press power button to turn ON two speakers, then long press 2 seconds on one of speaker button **M**, they will automatic connect after few seconds and prompt (ding ding) the device connected. Open your device and search for “BS-09” to connect, then you can play music through the speakers.


TF CARD

Insert TF-Card into TF-Card slot, any supported audio files found on the TF Card will begin to play automatically through the speaker. (TF-Card not included)

USB MODE

Insert USB Flash Drive into USB-A port, any supported audio files found on the USB Flash Drive will begin to play automatically through the speaker. (USB Flash Drive not included)

FM MODE

Long press power button to turn ON the speaker, insert charging cable (included) into the charging port as FM antenna, and press the **M** key to switch modes and enter FM radio reception mode. Press and hold  button to automatically search for and save stations. After receiving stations, fix them to the first station. To switch stations, click the **+** and **-** keys.

CHARGING

To charge your speaker, connect one end of the provided charging cable to a USB power source. When the speaker is charging, the LED charging indicator will glow red. When it is fully charged, the indicator will turn off.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.