

**SURVIVOR™**

**GRIFFIN™**

## **Sport True Wireless Earphones**

with Digital Display Case



**\*18 Hours Total Playtime**



**Charging Case 3.5x Charges**



**4 Hours Playtime Per Charge**



**Digital Display**

**Bluetooth®**

**Item: SRVRA1000**

**User's Manual**

# SAFETY PRECAUTIONS

When using your earphones, basic safety precautions should always be followed including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR EARPHONES AND CHARGING CASE.
2. Do not use the product near water. Do not put on wet surfaces.
3. Only clean using a clean, soft cloth.
4. Do not allow children to play with this product. This product contains small pieces that can be a choking hazard. Parental supervision is advised.
5. Do not expose this product to excessive heat or fire.
6. Do not expose this product to temperatures above 100°F. Keep out of direct sunlight.
7. Do not attempt to repair this product yourself. Contact a qualified service center if the product is in need of service.
8. Do not drop, crush, or expose this product to excessive physical force.
9. This product is not intended for commercial use.
10. When charging, keep all charging cables well ventilated. Do not keep your charging cable in contact with flammable materials such as bedding, linens or synthetic fabrics.
11. Please recycle or dispose of your earphones properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your earphones for further information.




## CAUTION

## BATTERY WARNING

-The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.

- Do not dispose of in fire or expose to excessive heat.
- Do not crush, puncture, incinerate, or short circuit external contacts.
- Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

# WHAT'S INCLUDED



SRVA1000 Earphones and Charging Case




User's Manual




USB-C Cable

# A CLOSER LOOK



# CHARGING




## Charging the Earphones

Place the earphones in the charging case in order to charge.

## Charging the Case

Insert the included charging cable's USB-C end into the USB-C charging port on the case. Insert the other end into a USB port on a computer or a suitable wall adapter. Leave to charge.




## Charging Status

The digits on the case's digital display screen will increase from 0-100 as the case charges and will display a solid '100%' once the case is fully charged.

The earphone battery icons on the digital display screen will show each earphone's charging status as they are charging inside the charging case. The right earphone battery icon will flash while the right earphone charges, and the left earphone battery icon will flash while the left earphone charges.

In addition, an LED light on each earphone will turn red as the earphone charges and turn off once the earphone is fully charged.




# POWERING ON/OFF

When first using your earphones place them into the case. Remove them from the case and they will automatically turn ON. Place them back into the case and they will automatically turn off.



Notes:

1. If the earphones are out of the charging case, put them into the case and take out again to turn ON.
2. You can also manually power your earphones on or off by pressing and holding the touch control area on each earphone for three to five seconds.




# BLUETOOTH PAIRING

Remove your earphones from the case and they will power ON. After a few moments they will pair with each other and then go into Bluetooth pairing mode. When your earphones are in Bluetooth pairing mode, an LED indicator light on one earphone will flash red and blue and the indicator of other earphone will turn off.



Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "SRVRA1000."


The LED indicator light on both earphones will turn off once paired to your phone.



After setting up Bluetooth, the earphones will automatically re-connect to the device every time you take them out of the charging case.

If your earphones remain unpaired with a Bluetooth device, they will automatically power off after approximately five minutes.

# USING YOUR EARPHONES



## LEFT EARPHONE

Play/Pause: Press  
Next Track: Double Press  
Increase Volume: Triple Press  
Voice Assistant: Press and hold for ~2 seconds  
Answer Call: Press  
End Call: Press  
Decline Call: Press and hold for ~2 seconds  
Power ON/OFF: Press and hold for 3-5 seconds



## RIGHT EARPHONE

Play/Pause: Press  
Previous Track: Double Press  
Decrease Volume: Triple Press  
Voice Assistant: Press and hold for ~2 seconds  
Answer Call: Press  
End Call: Press  
Decline Call: Press and hold for ~2 seconds  
Power ON/OFF: Press and hold for 3-5 seconds

# SPECIFICATIONS

Bluetooth Version: V5.3

Driver: 10mm

Earphone Battery Capacity: 25mAh

Charging Case Battery Capacity: 300mAh

Bluetooth Range: ~10M

Working Time: ~4 Hours at 50% Volume

Earphone Charging Time: ~1-2 hours

Case Charging Time: ~2-3 hours

## RESETTING YOUR EARPHONES

If you are experiencing issues that cannot be resolved by simply turning the earphones on and off or by placing them back into the case you may have success by doing a manual reset.

1. Power off your Bluetooth device, and power off your earphones by placing them in the charging case.
2. Take one earphone from the charging case. The indicator light flashes red and blue alternately. Press the touch control four times quickly to turn off the earbud. Then, do the same with the other earbud.

## Maintenance and Care

-Use a soft cloth or paper towel to clean your earphones. Never use any harsh chemicals or detergents for cleaning. Make sure your earphones are dry before charging.

-When your earphones are not in use, they should be stored in a cool, dry place.

-Never tug or yank on a cable while it is connected to your charging case. Connect and disconnect cables as carefully as possible.

-Never expose your earphones to high temperatures, extreme cold.

# FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. The device shall be operated and installed without restriction.

FCCID: 2AS3I-SRVRA-TWS

# **WARRANTY**

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

## **What Is Not Covered By Warranty**

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

## **To Obtain Warranty Service and Troubleshooting Information:**

Call 1-800-592-9541 or visit our website at [www.getsurvivor.com](http://www.getsurvivor.com).

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address of the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepairs.



©2025 GSICS  
195 Carter Drive  
Edison, NJ 08817  
Support: 800 592 9541  
[www.getsurvivor.com](http://www.getsurvivor.com)

\* All brand, product names and logos are trademarks or registered trademarks of their respective companies.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International. is under license. Other trademarks and trade names are those of their respective owners.