



QUICK START GUIDE

WIRELESS EARPHONES




ITEM: TWSWM

A Quick Look



CHARGING CASE

USB-C CABLE



LEFT EAR

RIGHT EAR

LEFT EARPHONE

RIGHT EARPHONE

SAFETY PRECAUTIONS

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.


WE'RE HERE TO HELP

Call us 24/7 at 1-877-397-8200
E-mail us at support@sakar.com or
visit us at www.sakar.com

Sakar International
195 Carter Drive
Edison, NJ 08817
1-877-397-8200


FCCID: 2AS3I-TWSWM

Charging



1. CONNECT USB-C END TO CASE
Connect other end to a USB smartphone charger




Pairing



2. REMOVE CHARGING PIN COVERS
Discard stickers and return earphones to case


3. REMOVE FROM CASE
Select "True Wireless EB" from Bluetooth® settings

Controls

LEFT EARPHONE	LEFT OR RIGHT EARPHONE	RIGHT EARPHONE
		
		
Press & Hold*	Tap x 2	Press & Hold*

1. AUDIO TOUCH CONTROLS
Navigating music and other audio
*Not available when using only one earphone

LEFT OR RIGHT EARPHONE




2. PHONE TOUCH CONTROLS
Answering/declining calls and smart assistant


Tap


Press & Hold


Tap x 3


Tap & Hold

— Cut line
- - - Fold line
— Copy safe area
— Outside Bleed
— Glue area