

## **“Baby Shoot” Children WiFi Camera**

### **Instructions for Use**

**Model No.: PI-01**

**Scan via WeChat to browse E-instructions**

**To see the world in children's eyes!**

#### **1. Camera Appearance and Structure**

Microphone      Speaker      Camera

    Shutter Button WiFi/Delete Button      Up/Down Button      Album Button      On/Off Button

#### **2. Download of Mobile APP**

IOS Users                      Android Users

Children's photography works can be viewed by directly connecting mobile phone with the downloaded APP.

#### **3. Operations Guide**

##### **3.1 Power on**

Long press the power switch and enter the viewfinder interface.

##### **3.2 Viewfinder Interface**

Press the shutter button once to complete the photo shooting.

Long press the shutter button to wake up the video function.

Press the Up/Down button to switch between colorful cartoon photo frames.

Press the WiFi/Delete button to enter the WiFi connection interface, and display the information of WiFi account and password.

Press the album button to enter the album interface.

##### **3.3 Album Interface**

Press the shutter button to play/pause videos in the album.

Press the Up/Down button to view the previous/next photo.

Press the WiFi/Delete button to delete the photo and press again to confirm the deletion.

Press the album button to cancel the deletion and return to the album interface.

Press the album button to return to the viewfinder interface.

##### **3.4 Power off**

Press the key once to turn off the screen; press and hold the key to turn off the camera.

#### **4.APP Operations Guide**

##### **4.1 Connection to APP**

Press the WiFi/Delete button to open the camera's WiFi interface and obtain the WiFi information.

Start the mobile APP: Android users can follow the APP tips and connect to the camera; IOS users can click “Connect to WiFi” to enter the system WiFi interface, input the password in the camera WiFi interface, and then return to the APP to complete the connection.

## 4.2 Video/Photo Download

Download Button

[Click here to view downloaded photos](#)

Photo download: click the download arrow below specific photo in the APP to download the photo.

Video download: click on the video to enter the video download interface and click the white download button on the left.

The downloaded photos and videos will be displayed in the “Album” column.

## 4.3 Photo Sharing

Share the photos to various social media

Enter the “Album” interface, click the “Select” button in the upper right corner, check the photos you want to share, click “Share” below to share the photos. (Some Android phones need to disconnect WiFi when operating).

### 1. Notice for use

- 1.1 Applicable people: This product is suitable for children over 3 years old.
- 1.2 Operating environment: The operating temperature of the product is 0°C-45°C; the operating humidity is 10%-80%, and the product does not have waterproof function.
- 1.3 The blue indicator light will flash during recording. The red indicator light will be on when charging, and the red indicator will be off to indicate that the battery is full.
- 1.4 In the WiFi connection state, the power consumption increases and the product will slightly heat up, which is a normal phenomenon. Please feel free to use.
- 1.5 The product is a precision electronic product. Do not subject the product to destructive operations such as strong impact or vibration.
- 1.6 The product uses food grade safety materials and is non-toxic and harmless. Please feel free to use.

## 6. Product detailed parameters

Display Size	1.5 Inch
Cameral Pixel	5 Mega Pixel
Battery Capacity	800 mAh
Charging Time	About 100 Minutes
Extended Memory	32GB(at most)
Product Weight	65g
Camera Dimensions	82*58*31mm

The user can enjoy the warranty service within one year after the date of purchase, as long as this product is used normally, and has not been disassembled, repaired nor demolished. The warranty service will be offered after the technician confirms that it is a product quality problem, and is available under any normal conditions.

Customer Name	Date of Purchase	Seller
Warranty record		

Please fill in the above content when you purchase.

**FCC ID: 2AS52N7N8F**

**FCC WARNING:**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter