


Model:Y-SKR18-7



User's Manual

Button and interface description



- ① Short press for volume +/long press for next song
- ② ON/OFF
- ③ Play/Pause
- ④ Switch model
- ⑤ Indicator light
- ⑥ Short press for volume -/long press for previous song
- ⑦ Microphone hole
- ⑧ USB
- ⑨ TF card
- ⑩ Charging port
- ⑪ Charging indicator light
- ⑫ 3.5mm audio input line/Auxiliary

Connection method

① Turn on the speaker

Turn on the speaker, the speaker will automatically enter into the wireless mode.

② Connect to mobile devices

Turn on wireless option in mobile device,select (Y-SKR18) in the mobile device,the speaker will make a sound after successful connection.

For future uses, just keep the mobile device's wireless turned on, it can automatically connect.

Connect to new mobile device

If the current device with the speaker is connected, you need to disconnect the current device's wireless, then use the new mobile device to connect the speaker.

Warning

1. Do not expose the product to high temperatures, corrosive or high-pressure environment.
2. Do not attempt to disassemble the Speaker, or to replace any electronic components in it.
3. If the internal devices have fluid leakage, please stop use.

Technical parameter

Loudspeaker output	20W(40hm)
Speaker	φ58mm
Version	V5.4
Frequency response range	120Hz-20KHz
Battery capacity/Voltage	1800mAh
Battery charge time	About 2-6 hours
Working time	About 7.5 hours
USB power input	5V 1A
Speaker size	99x97x220mm

Instructions for use



Next/Volume+ Button

Short press for volume +,
Long press for next song.



ON/OFF

Long press for 3 seconds to turn on/off;
Short press to switch/on/off the light



Play/Pause

Short press to play/pause;
Short press to answer/end phone call; when incoming call,
long press to reject;
Under BT mode, long press to activate voice assistant;
Under BT mode, press 2 times to redial last number



Light switch/on/off

Short press to switch BT/AUX/USB/BT mode;
Double press to enter/exit TWS mode
Under BT mode, please disconnect speaker first, then long press the
button for 5 seconds to clear Bluetooth pairing information;
Under BT mode, long press for 2 seconds to disconnect bluetooth.



Previous Volume-

Short press for volume -,
Long press for previous song.



Indicator light

1. Charging status: the red light will be constant on;
2. Charging finished: the red light will be off.

Size:65*85mm折页