



- UWB Module




- SPECIFICATION

Standards	UWB(Ultra Wide Band) - CCC Digital Key Phase3 Specification - IEEE 802.15.4-2015 - IEEE 802.15.4z
UWB Ranging Distance	Max. 10m(LOS/Line of Sight conditions, between Devices)
Power voltage	12V
Dimension(mm)	92.70 x 50.83 x 18.15

- Dimension



- PIN MAP



No.	PIN NAME
1	CAN_L
2	CAN_H
3	SUB_ID2
4	SUB_ID1
5	GND
6	GND
7	SUB_ID0
8	B+_POWER

- Electrical Characteristic

	Min	Typ.	Max	UNTI
Supply Voltage	9	12	16	V
Operating Temperature	-40	-	85	°C
Storage Temperature	-40	-	95	°C

- Product Specification

Name of company	AMOSENSE CO.,LTD.
Equipment / Model Name	UNIT ASSY-ULTRA WIDEBAND / ASUWBM00
Identification Code	Amo
Year of manufacture	Separate mark
Manufacturer / Country	AMOSENSE CO.,LTD. / KOREA
Operation Frequency	6.4896GHz / 7.9872GHz

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device should be installed and operated with minimum 20 cm between the radiator and your body.

This device contains licence-exempt transmitter(s)/receiver that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:(1) This device may not cause interference.(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs / récepteurs exempts de licence qui sont conformes aux RSS exempts de licence d'Innovation, Sciences et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes:(1) Cet appareil ne doit pas provoquer d'interférences.(2) Cet appareil doit accepter toute interférence, y compris les interférences qui peuvent provoquer un fonctionnement indésirable de l'appareil.

This equipment should be installed and operated with minimum 20 cm between the radiator and your body.

Cet appareil doit être installé et utilisé avec un minimum de 20 cm entre le radiateur et votre corps.