

1. 多功能键 Multi-function key
2. 辅助功能键 Auxiliary function key
3. Type-C 充电口 Type-C charging port
4. 微型扬声器 Micro speakers
5. 麦克风 Microphone

开/关机 On/off

按住多功能键 3 秒后开机, 开机后蓝牙进入配对模式,
按住多功能键 3 秒后关机

Press and hold the Multi-function key for 2 seconds and then turn it on. After turning on the Bluetooth, it will enter the pairing mode. Press and hold the Multi-function key for 3 seconds and then turn it off.

蓝牙配对 Bluetooth pairing

首次配对: 首次对设备连接, 长按 5 秒多功能键红蓝交替闪烁, 耳机进入配对状态。打开设备蓝牙, 找到可用设备 Mu6 Ring Surreal , 配对连接成功, 耳机蓝灯 3 秒闪烁一次。

Pairing for the first time: Pairing a connected device for the first time, press and hold the 5S Multi-function key alternately flashing red and blue to enter the pairing

state. Turn on the device's Bluetooth, find the available device Mu6 Ring Surreal, if pairing connection is successful, the headset blue light will flash 3s once.

自动回连：长按 3 秒开机自动回连最后一次连接的蓝牙设备（自动回连失败，进入蓝牙配对状态）。

Automatic connection back: Long press 3S to start automatic connection back to the last connected Bluetooth device (automatic connection failure, enter Bluetooth pairing).

超距自动回连：耳机超距设备后，耳机提示 Disconnected，并且进入超距回连状态等待回到能连接的距离范围，如果超过 10 分钟没连接上，耳机自动关机。

Over distance automatic connection: After the headset over distance from the device, the headset prompts Disconnected, and enters the over distance back to connect the state waiting to return to the distance range can be connected, if more than 10 minutes did not connect, the headset automatically shut down.

断开连接：主动关闭设备蓝牙断开连接，断开之后耳机自动进入配对状态。

Cancelling Connection: Actively close the device's

Bluetooth plug-in connection, and then the headset automatically enters the pairing mode.

使用耳机 Use headphones

多功能按键:放音时轻按一次音乐暂停,再次轻按恢复播放, 双击则上一曲;

Multi-function key: When playing, tap once to pause the music, tap again to resume playback, double click on the previous song.

当手机来电时,轻按一次接听,再轻按一次挂断:

手机来电时,双击拒接来电。

When the phone comes in, tap once to answer, then tap again to hang up; when the phone comes in, double click to reject the call;

辅助功能按键:单击可进入语音助手;

放音时双击下一曲。

Auxiliary function key: tap once to enter the voice assistant. When playing, double-click on the next song.

注意事项

Mu6 Ring Surreal 开机后未配对,无任何操作,10 分钟耳机后自动关机。

Mu6 Ring Surreal 连接手机后,断开蓝牙连接, 10 分钟后耳机自动关机。

Precautions:

After the Mu6 Ring Surreal is turned on, it is not paired and has no operation. The headset will automatically turn off after 10 minutes.

After Mu6 Ring Surreal is connected to the mobile phone, the Bluetooth connection is disconnected and the headset will automatically turn off after 10 minutes.

充电 Recharge

打开 Mu6 Ring Surreal 的 Type-C 端口盖,使用提供的 Type-C 充电线

将其连接到标准的(5V-1A)充电器,或者将其连接到 PC 上的标准 USB 端口。

当充电时, Mu6 Ring Surreal 连接手机后的 LED 指示灯红灯常亮。

充电完成时, LED 指示灯蓝灯常亮。

Open the Type-C port cover of Mu6 Ring Surreal and use the provided Type-C charging cable to connect it to a standard (5V-1A) charger, or connect it to a standard USB port on the PC.

When charging, the Red LED indicator of Mu6 Ring Surreal is always on.

When charging is complete, the blue LED indicator light

is always on.

操作方法 Operation overview

行动 Action	控制 Control	LED 指示灯 Led Indicator	声 音 提 示 Voice Notification
开机 Turn on	按住多功能键 按钮 3 秒 Hold the Multi-function key 3S	蓝灯闪烁 3 次 Blue light flashes 3 times	有 Exist
关机 Turn off	按住多功能键 按钮 3 秒 Hold the Multi-function key 3S	红灯闪烁 3 次 Red light flashes 3 times	有 Exist
搜索蓝牙设 备 Searching the bluetooth device		红 蓝 交 替 闪 烁 Red and blue flashing alternately	有 Exist
蓝 牙 连 接 Blue tooth		蓝 灯 每 3 秒 闪 一 次	有 Exist

connection device 状态		The blue light flashes every 3 seconds	
播放音乐状 态 Play music status		蓝灯每 5 秒闪一次 The blue light flashes every 5 seconds	无 N/A
上一曲 Previous playing	6. 双击多功能 键 按钮 double-click Multi-function key	无 N/A	无 N/A
下一曲 Next playing	7. 双击辅助功 能 键 按钮 double-click	无 N/A	无 N/A

	Auxiliary function key		
接 电 话 Answer the phone	8.来电时轻按 多功能键按钮 Tap the Multi-function key	红 蓝 灯 3 秒 闪 2 次 Red and blue lights flash 2 times in 3 seconds	有 Exist
挂电话 Hang up the phone	9.通话时轻按 多功能键按钮 Tap the Multi-function key	无 N/A	无 N/A
拒 接 电 话 Reject the call	10. 来电时双 击多功能键按 钮 double-click Multi-function key when calling	无 N/A	无 N/A

唤醒语音助手 Connect to voice assistant	11. 轻按辅助功能键按钮 Tap the Multi-function key	无 N/A	无 N/A
低电量提示 Low power	当电池电压 \leq 3.2v, 出提示音 (battery low) 后自动关机 When the battery voltage is less than equal to 3.2v, it will automatically shut down after a beep (battery low)	无 N/A	有 Exist
蓝牙配对超时 Bluetooth pairing	无任何操作, 10 分钟耳机自动关机	无 N/A	有 Exist

timeout	Without any operation, Bluetooth will automatically shut down in 10 minutes		
蓝牙耳机断开连接 Bluetooth headset disconnected	无任何操作，10 分钟耳机自动关机 Without any operation, Bluetooth will automatically shut down in 10 minutes	无 N/A	有 Exist
恢复出厂设置 Hard reset	12. 连接 Type-C 上电，长按辅助功能键按钮 6 秒 Connect Type-C and long press the Auxiliary	红蓝灯同时闪三次 Red and blue lights flash three times at the same	无 N/A

	function key	time	
进入配对状态 Enter the pairing state	开机时长按多功能键按钮 5 秒 Power on Long press the Multi-function key for 5S	红 蓝 交 替 闪 烁 Red and blue flashing alternately	有 Exist

参数 Parameter

产品型号 Product model: Mu6 Ring Surreal

电压输入 Power input: 5V-150mAH

驱动 Drive: 16mm

电池容量 Battery capacity: 180mAH

阻抗 Impedance: 18 Ω

通话时间 Talk time: 9 小时 9hours

灵敏度 Sensitivity: 118 \pm 3db

音频播放 Audio playback: 9 小时 9hours

频 率 响 应 范 围 Frequency response range :
20Hz-20000Hz

待机时间 Standby time: 200 小时 200 hours

蓝牙版本 Bluetooth version: Bluetooth 5.0

充电端口 Charging port: Type-C

蓝牙工作频率 Bluetooth operating frequency :
2400-2483MHZ

耳机大小 Headphone size:

蓝牙范围 Bluetooth range: $\geq 10\text{m}$

耳机重量 Headphone weight: 约 23 g About 23g

蓝牙协议 Bluetooth protocol: A2DP;HFP;HSP;AVRCP

包装清单 Packaging list

耳机 Headphone

说明书 Manual

充电线 Charging cable

存放和维修 Storage and Maintenance

1.将 Mu6 Ring Surreal 存放在阴凉干燥的地方，不要将其暴露在极端温度（ -20°C 一下或 55°C 以上）。只在 -3°C 到 40°C 温度之间操作产品。

Store Mu6 Ring Surreal in a cool and dry place, and do not expose it to extreme temperatures (below -20°C or above 55°C). Only operate the product between -3°C and 40°C .

2. 请勿使用超过 5V 的电源适配器充电.

Do not charge with a power adapter exceeding 5V.

3. 在冷/热或湿/潮环境工作会减少产品的寿命，不要将产品暴露在灰尘，油或烟。不要扔，击打或者锋利物品刮蹭产品。

Working in a cold/hot or humid/moist environment will reduce the life of the product. Do not expose the product to dust, oil or smoke. Do not throw, hit or scratch the product with sharp objects.

4. 长时间不使用，请再次使用前给 Mu6 Ring Surreal 充电。

After not using it for a long time, please charge Mu6 Ring Surreal before using it again.

5. 请使用干软布而不用砂布或者洗涤剂，酒精或基于化学品的清洁产品仔细擦拭清洁耳机

Carefully wipe clean the earphones by using a dry soft cloth instead of emery cloth or detergent, alcohol or chemical-based cleaning products.

Mu6 Ring Surreal 耳机保修说明

Mu6 Ring Surreal Earphone Warranty Description

一年有限保修

One-year limited warranty

由购买日起计一年保用期内,耳机如有损坏或发生故障,经本公司

技术人员证实乃在正常使用之情况下发生者,本公司将提供免费维

修及更换零件。经更换后之任何损坏零件,将归属本公司。

如产品曾经被非本公司人员改换或修理;或曾因错误操作、疏忽使

用、意外事件、天然灾害而引致损坏,或因电压不正常而导致机件操

作失灵,或已转换用户或用户搬迁地址而未能及时通知本公司服务

中心者,本保用证将自动失效。**Mu6** 将继续为顾客进行产品修理,但

是维修费用由顾客承担。

本保修单之免费更换零件并不包括耳机在不正确电源供给下或者

其他人为因素。

除此保修单外,任何商号及人士所发出之有关保修单,均不为本公

司认可。

请妥存此证及正式购货收据,于修理时一并出示予技术人员查阅方可

有效。

如需要回厂检修,客户需负责将机件邮寄本公司之各地维修服务中

心,服务中心于机件修妥后,将产品邮回给顾客。

During the one-year warranty period starting from the date of purchase, if the headset is damaged or malfunctions, the company's technicians have confirmed that it occurred under normal use, and the company will provide free repairs and replacement parts. Any damaged parts after replacement will belong to our company.

If the product has been changed or repaired by non-company personnel; or has been damaged due to incorrect operation, negligent use, accidents, natural disasters, or malfunction of the machine due to abnormal voltage, or the user has been changed or the user's relocation address has been changed If you fail to notify the company's service center in time, this warranty will automatically become invalid. Mu6 will

continue to repair products for customers, but the maintenance costs are borne by customers.

The free replacement parts in this warranty does not cover the earphone under incorrect power supply or other human factors.

In addition to this warranty, any related warranty issued by any firm or person is not recognized by the company.

Please keep this certificate and the official purchase receipt, and present it to the technician for inspection when repairing.

If the parts requiring service need to be returned to the factory for repair, the customer is responsible for mailing the parts to the repair service centers of our company. After the parts are repaired, the service center will mail the products back to the customer.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.