




FAST WIRELESS CHARGING, ANYWHERE.



For setup videos and updated device compatibility lists:



amperetech.co/setup
amperetech.co/compatibility

To register your product, go to,
Amperetech.co/register

Welcome Message from Ampere

Thank you for purchasing Unravel. Unravel's unique three panel design allows you to wirelessly charge three Qi-enabled devices simultaneously OR two Qi devices plus an Apple watch.

The wireless charging pads charge automatically and on contact. So simply plug in Unravel then set any Qi-enabled wireless charging device on the panel to begin charging. There are no buttons to press to activate Unravel and, because it has a low standby current, feel free to leave it plugged in day and night.



Features

Fast charge automatically - All three Unravel panels have a fast 10W wireless charging coil. The side panel without the Type-C PD input can also charge an Apple Watch.

Type-C PD input - Unravel should be used with an Ampere charger or certified Type-C PD adapter from a reputable brand. For optimum performance, adapters should have a minimum wattage of 60W.

Foldable design - multiple charging positions and easy to transport.

Low standby current - When there are no devices on the wireless charging panel or the device(s) are fully charged then the power output will be less than .3 W.

Non-slip rings and runners - Silicon grips designed to keep your devices in place.

Pogo pins - For use in conjunction with the Ampere Power Bank for fast truly wireless charging.

Overcharging protection -

Foreign object detection -


Low heat and overheating detection -

LED Indicator Lights The LED lights on each panel indicates the status of each individual pad.


- If the LED light is illuminated then the device is charging properly
- If the LED light is flashing then the device is not charging (because a metallic foreign object was detected)

Using Unravel

1. Connect the Unravel 60W Type-C PD adapter to Unravel and a wall outlet.



2. Set up Unravel in your favorite orientation.



3. Place your wireless charging device on the center of the Unravel charging panel. Charging will begin automatically on contact.



Taking care of your Unravel

- Keep your Unravel dry and away from moisture.
- Clean Unravel with a soft cloth and only enough water to make it damp. Do not use any harsh chemical cleaners or soaps.
- Fold into “stack” form when transporting. We recommend using with the Ampere Travel Case for extra protection

Warnings

Read all instructions and warnings prior to using this product. Improper use of this product may result in product damage, excess heat, toxic fumes, fire or explosion, for which damages you (“Purchaser”), and not Ampere (“Manufacturer”) are responsible.

Do not store/use the device in high-temperature environment, including heat caused by intense sunlight or other forms of heat.

Do not use device in small, confined or sealed spaces (e.g. under blankets, in boxes, etc.).

Do not disassemble this device or attempt to re-purpose or modify it in any manner.

Use with only certified Type-C PD adapters.

Unravel is designed for personal use only. It is not suitable for commercial applications.

Do not place the backside pogo pin receivers on any protruding metallic material that could complete the circuit (except for recommended Ampere products).

Remove all foreign metal objects from your device before using on Unravel.

Do not attempt to replace any part of this device.

If this device is accessible to or may be used by a minor, purchasing adult agrees to be solely responsible for providing supervision, instruction, and warnings. Purchaser agrees to defend, indemnify, and hold Manufacturer harmless for any claims or damages arising from unintended use or misuse by a minor.

All products have gone through a thorough quality assurance inspection. If you find that your device is excessively hot, is emitting odor, is deformed, or is experiencing or demonstrating an abnormal phenomenon, immediately stop all product use and contact Manufacturer.

Legal

This product is meant for use only in conjunction with the appropriate device. Please consult your device packaging to determine whether this product is compatible with your particular device. Manufacturer is not responsible for any damages to any device incurred through the use of this product. Manufacturer shall not in any way be liable to you or to any third party for any damages you or any third party may suffer as a result of use, intended or unintended, or misuse of this product in conjunction with any device or accessory other than the appropriate device for which this product is designed.

Manufacturer will not be responsible for any damages you or any third party may suffer as a result of misuse of this product as outlined above. Purchaser agrees to defend, indemnify, and hold Manufacturer harmless for any claims or damages arising from unintended use or misuse, including use with an unintended device.

FCC warning:

This device complies with part 15 of the FCC Rules. Operations is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for a uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body

FCC ID: 2ASPB-UNWBK03