



Quick Start Guide

A02 Mini Printer




1. Product Introduction

1.1 Packing List



① The quantity and specifications of the paper roll(s) are tailored to the package you've chosen

1.2 Printer Parts Instruction



2. Getting Started

2.1 Downloading the App

Method 1: Search for the "Phomemo" app on App Store® or Google Play™ for download and installation.



Method 2: Scan the QR code to download the app.


You can scan the code using your cell phone's camera, the built-in QR code scanning feature of your browser, or a dedicated QR code scanning app.



① As the Safari browser on Apple devices does not support direct QR code scanning, please use your device's built-in QR code scanner instead.

2.2 User Guide


01 To turn on the printer, long press the Power Button for three seconds until the Indicator Light is on.



02 Open the "Phomemo" app.




03 Grant permissions



05 Tap [Connect Now].




06 Connection successful, click on [Print Image].




① This is an example of printing an image. You can select other texts for printing based on your actual needs.

09 Tap [Print].




13 Stick the label onto a dry, flat surface.




① The software interface is for reference only. Please refer to the actual operating page for accurate information.

3. Replacing the Paper Roll




01 Insert your fingers into the finger recess and lift upwards.

① Remove any paper rolls or tubes from the printer.



01 Take out a brand new paper roll and remove the roll protector.



01 Place the paper roll in the printer and pull the paper head out above the paper outlet.

4. Information to User

4.1 FCC INFORMATION (U.S.A.)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure statement.

The device can be used in portable exposure condition without restriction

WARNING

Please pay attention to electrical safety. Do not disassemble, crush or puncture the battery. This product is not a toy. Bitte achten Sie auf elektrische Sicherheit. Zerlegen, zerquetschen oder durchstechen Sie die Batterie nicht. Dieses Produkt ist kein Spielzeug. Veuillez noter la sécurité électrique. Ne pas démonter, écraser ou piquer la batterie. Ce produit n'est pas un jouet. Si prega di prestare attenzione alla sicurezza elettrica. Non smontare, schiacciare o perforare la batteria. Questo prodotto non è un giocattolo. Preste atención a la seguridad del consumo de electricidad. No retire, triture o pinche la batería. Este producto no es un juguete. Lütfen elektrik güvenliğine dikkat edin. Bateriyi dağıtmaya, yokma veya yumruklama. Bu ürün oyuncak değil. Var uppåräksam på elässäkerheten. Ta inte isär, krossa eller punktera batteriet. Den här produkten är ingen leksak. Let op elektrische veiligheid. Demonteer, verpletter of prik de batterij niet. Dit product is geen speelgoed. Proszę zwrócić uwagę na bezpieczeństwo elektryczne. Nie demontuj, nie miażdż ani nie przebijaj akumulatora. Ten produkt nie jest zabawką.

Special Notes

The company assumes full responsibility for the revision and explanation of this manual, exercising utmost diligence to guarantee its accuracy. Nevertheless, please note that any technical improvements to the product may not be separately notified, and that the images of the product, accessories, software interfaces, etc. in this manual serve solely as illustrations and references. Due to product updates and upgrades, the actual product may vary slightly from the images. Please refer to the physical product for accurate representations.