


专利及保密协议

这份图纸的所有信息，包括版权、设计及其他知识产权均属珠海趣印科技有限公司所有。此文件的条款不赋予你使用及复制产品，或拥有产品所有权的权利。上述权利均属珠海趣印科技有限公司所有。未经珠海趣印科技有限公司书面同意，严禁在任何情况下复制、披露、转载产品信息。

Quick Start Guide

Portable Printer A881U



HVIN:A881U

English

1. Product Introduction

1.1 Packing List

- Printer x1
- Quick Start Guide x1
- Type-C Cable x1

1.2 Adapter Pack Introduction

Power Button
Status Indicator Light
Charging Indicator Light
Connecter Indicator Light
Paper Output Slot

Power Entry Slot
Type-C Charge Port
Reset Hole

① This device contains lithium-ion battery, which may catch fire or overheat if not used properly. Please use this device in a safe and proper way.

2. Getting Started

2.1 Downloading the App

Method 1: Search for the "Printer" app on App Store or Google Play for download and installation.

Method 2: Scan the QR code. You can scan the code using your cell phone's camera, the built-in QR code scanning feature of your smartphone, or a dedicated scanning app.

① If you have a QR scanner on your phone, please use your device to scan the QR code within 30 seconds.

2.2 Tintex Transfer Paper Introduction

White Tracing Sheet
Removable Protective Sheet
Blue Carbon Sheet
Yellow Backing Sheet

① This area is the adhesive area at the top of the paper, please do not tear it.

2.3 Preparation Before Use

① Take out a piece of tintex transfer paper, and remove its Protective Sheet.

② Tear the Yellow Backing Sheet along the top adhesive area with a line of scissors.

Method 1
Method 2

③ Please always tear along the top adhesive area (see the yellow line).

2.4 Paper Installation Guide

① Plug in the Power Button for 3 seconds until the Indicator Light is green to power up the printer.

② Double-click the power button to remove the printer's protective paper.

③ Tear off the White Tracing Sheet.

④ Place the white tracing paper facing up and insert it flat into the paper slot until the printer automatically feeds the paper. The status indicator light will blink slowly in green, indicating that the paper is loaded.

⑤ Status Indicator Light: Paper Entry Slot

2.5 User Guide: Printing via Mobile App

① Scan QR code to download the app.

② Open the "Printer" app.

③ Grant permissions.

④ For more information about app permissions, see the "Permissions" page in the User Guide.

⑤ Tap the printer to be searched.

⑥ Tap Connect Now.

⑦ Connection successful, click on Print Image.

⑧ Select the image to be printed.

⑨ Light your first image, and tap.

⑩ Confirm the preview of this image, and tap Print.

⑪ Tear off the White Tracing Sheet for use.

⑫ The software interface is for reference only. Please refer to the actual software interface for accurate information.

3. Additional Instructions

3.1 Button Instructions

Button Type	Description	Function
Long press for 5s	Power on/off	
Double press when printer is on	Print a selected page	

3.2 Indicator Light Instructions

Status/Indicator Light	Meaning	Advised Action
● Solid Green Light	Power on	
● Slow Flashing red light	Top Cover open	Close Top Cover
● Green overheat	Printer overheat	Pause printing for 5-10 min
● Fast Flashing red light	Critical battery level, shutting down soon	Charge battery for 1h or at least 30 min for quick re-charge
● No light indication	Battery depleted	Charge for 4h

3.3 Charge/Indicator Light

Charge/Indicator Light	Meaning	Advised Action
● Slow Flashing Green Light	Charging	/
● Solid Green Light	Fully charged	/
● Red light Flashing slowly	Low battery	Charge battery for 1h or at least 30 min for quick re-charge

3.4 Wireless/Indicator Light

Wireless/Indicator Light	Meaning	Advised Action
● Steady blue light	Bluetooth connection completed	/
● Blue light Flashing	Bluetooth receiving data	/

4. Accessing Detailed Online Guide

Visit QR code to access the detailed online guide, video tutorials, and answers to FAQs.

5. Information to User

5.1 FCC INFORMATION (U.S.A.)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure statement. The device can be used in portable exposure condition without restriction.

5.2 ICED NOTICE (Canada)

English
This device contains radio-frequency transmitter(s)/receiver(s) that comply with ICES Class B. Operation is subject to the following two conditions:
(1) This device must not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
IC: Radiocommunications
The device has been evaluated to meet general IC RF exposure requirements. The device can be used in portable exposure condition without restriction.
French
Cet appareil contient un émetteur de radiofréquences (s) / récepteur(s) qui est conforme à la classe B.
L'exploitation est soumise aux deux conditions suivantes:
(1) L'appareil ne doit pas produire de brouillage.
(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
IC: Radiocommunication par RF
L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF.
L'appareil peut être utilisé dans des conditions d'exposition portables sans restriction.

Special Notes

The company assumes full responsibility for the revision and explanation of this manual, ensuring correct alignment to guarantee its accuracy. Nevertheless, please note that any technical improvements to the product may not be accurately reflected, and that the design of the product, accessories, software and hardware, may change without notice. The actual product may vary slightly from the images. Please refer to the physical product for accurate representations.

5