




# E10


## 4K Time Lapse Camera

# Quick User Guide




For the electronic version of the guide, scan the QR code to access it on your computer or mobile.

# The Camera Body



|   |                 |
|---|-----------------|
| 1 | Power Button    |
| 2 | Lens            |
| 3 | 52mm UV Filter  |
| 4 | Filter Mount    |
| 5 | Focus Ring      |
| 6 | Microphone      |
| 7 | Silicone Cover  |
| 8 | USB-C Connector |
| 9 | 2.5mm Connector |




|    |                                |
|----|--------------------------------|
| 10 | Charging Indicator             |
| 11 | Battery Indicator              |
| 12 | Operation Indicator            |
| 13 | 1/4"-20 Tripod Mount           |
| 14 | Camera QR Code                 |
| 15 | Battery/Memory Card Door       |
| 16 | Battery/Memory Card Door Latch |
| 17 | Battery Clip                   |
| 18 | MicroSD Card Slot              |
| 19 | Battery Compartment            |

# Battery


## Inserting Battery

**1** Pull the door latch down till the door pops open.




**3** Use the battery to push the yellow latch back until the battery can be inserted.

**4** Slide in the battery until the yellow latch click in to lock the battery in place.



## Removing the Battery


**1** To remove the battery, turn the camera off, pull down the door latch to open the Battery/Card door.



**2** Press the yellow latch so that the battery can be released. Pull the battery tab to slide out the battery.

# Memory Card

## Inserting MicroSD card



### Memory Card Requirement

- Type: microSD
- Capacity: Support max.512GB
- Speed Class: U3
- Format: exFat

**1** Open the Battery/Card door.


**2** Orient the card so that the metal contacts facing toward the front side of the camera and the card cut out facing down.

**3** Slide in the memory card until it clicks.

## Removing memory card

To remove the memory card, press the card in and then release slowly. The card will then eject out a little and can be removed by hand.


# Charging



**1** Pry open the silicone cover.

**2** Connect the USB-C port to an external USB power source with a minimum rating of 5V@1A.


## Remove UV Filter



To remove the UV filter from the lens, grip the edge of the filter and turn it counterclockwise (to the left).

## Add-On Filter

This product accommodates common 52mm filters, enabling you to enhance your camera's functionality to precisely align with your artistic vision and adapt to diverse shooting conditions.



**1** Screw clockwise an add-on filter on the UV Filter or on the Focus Ring (remove the UV filter first).

**2** Add more filters on top as required.

# Status Indicators

The camera features three indicator lights for essential feedback:  
the Charging indicator displays charging status;  
the Battery indicator indicates battery status,  
the Operation indicator reflects camera running states.

| Indicator   | Color          | Status             |
|---|----------------|--------------------|
|  Charging    | Green Blinking | Charging           |
|   | Green Steady   | Fully charged      |
|   | Off            | Not charging       |
|  Battery   | Green Steady   | Battery $\geq$ 50% |
|   | Yellow Steady  | Battery 20% - 50%  |
|   | Red Steady     | Battery < 20%      |
|   | Off            | Sleeping           |
|  Operation | Red Steady     | Booting            |
|   | Green Steady   | Ready              |
|   | Green Blinking | Recording/Shooting |
|   | Red Blinking   | Sleeping           |

## ATLI Cam+ app


This app connects your mobile device to ATLI cameras for easy management and operation.

Download it from the App Store/Google Play or scan the QR code.

Follow the setup instructions to start your timelapse journey.



## Camera Registration



**1** Open ATLI Cam+ and go the camera list > [Add Camera].

**2** Long press the power button for 3 secs to turn on the camera. Wait approx. 10 secs until the operation indicator  turns green.

**3** Scan the QR code located at the bottom of the camera and complete the registration process.


## ATLI Cam+ Login

To take full advantage of your ATLI Cam+, please create an account and log in to the app. This will provide you access to advanced features, cross-device functionality, and automatic warranty registration.

# Manual Focus

This camera features a manual focus system, allowing users to adjust the focus of the camera to achieve sharp and clear images.

## Subjects beyond 1 meter




For subjects over 1 meter, rotate the focus ring to the preset position (as shown on the left). When it reaches this position, you will feel it click into place.

## Subjects within 6 cm to 1 meter

**1** Adjust the camera's focus ring slowly until the image appears clear and sharp on the live feed.

**2** To achieve precise focus, use the magnify feature by long-tapping on the screen. This will zoom in and allow you to check the details more closely.



# Specifications

## General

|                    |                     |
|--------------------|---------------------|
| Dimensions         | 860*600*675mm       |
| Weight             | 210g (with battery) |
| Weatherproof       | IP64                |
| Supported SD Cards | Max. 512GB microSD  |

## Camera

|                     |   |
|---------------------|---|
| Sensor              | 1/2.8"  |
| Pixel Size          | 1.45µm*1.45µm   |
| Lens                | 6 Elements Aspherical Lens  |
| ISO Range           | 100 - 3200  |
| Shutter Speed       | 1/20K – 15secs  |
| White Balance       | 2500 – 8000K  |
| Focus Method        | Manual focus  |
| Focus Range         | 6cm to infinity   |
| Exposure Metering   | Center-weighted   |
| Time Lapse Mode     | Resolution:<br>3840*2160@25FPS,<br>1920*1080@25FPS<br>Output: Video, JPG, Video+JPG<br>Intervals: 2second-24hours<br>Duration: Custom/Infinity<br>Schedule: Max.6 slots |
| Photo Mode          | Resolution:3840*2160,<br>1920*1080  |
| Support File System | exFAT   |
| Photo Format        | JPEG  |

|                |       |
|----------------|-------|
| Video Format   | MP4   |
| Video Encoding | H.264 |

## Battery

|                       |                            |
|-----------------------|----------------------------|
| Type                  | Rechargeable Li-ion        |
| Capacity              | 4400 mAh                   |
| Energy                | 16.7Wh                     |
| Voltage               | 3.8V                       |
| Limited Voltage       | 4.35V                      |
| Charging Temperature  | 5° to 45° (32° to 113°F)   |
| Operating Temperature | -10° to 50° (14° to 122°F) |

## Connection

|                |   |
|----------------|---|
| Wi-Fi Protocol | Dual-band Wi-Fi 5 (IEEE 802.11 a/b/g/n/ac 2x2 MIMO) |
|----------------|---|

## Interface / Control

|                  |                                   |
|------------------|-----------------------------------|
| Language         | 简体中文/繁体中文/English/日本語             |
| App Control      | iOS/Android                       |
| Firmware Updates | Over-The-Air (OTA) / MicroSD card |

# Warranty

Under normal operation, the product is covered by a one-year limited warranty from ATLI World Limited.

To qualify for this warranty, customers must provide the original purchase invoice or register the product online.

To access warranty service, please contact us via email to report any issues and obtain authorization beforehand.

Email us: [service@atliview.com](mailto:service@atliview.com)



Scan this code to view the user manual for in-app controls.

## FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction