

You are almost there. To be able to proceed further, connect ESP32-S3 board to PC, check under what serial port the board is visible and verify if serial communication works.



After connecting USB to power on. The screen can directly display the electronic label for two seconds.