






Band71-5MHz-16QAM-133297-1RB#0-Range6:12000~26500MHz




Band71-5MHz-16QAM-133447-1RB#0-Range1:0.009~0.15MHz




Band71-5MHz-16QAM-133447-1RB#0-Range2:0.15~30MHz




Band71-5MHz-16QAM-133447-1RB#0-Range3:30~1000MHz




Band71-5MHz-16QAM-133447-1RB#0-Range4:1000~5000MHz




Band71-5MHz-16QAM-133447-1RB#0-Range5:5000~12000MHz




Band71-5MHz-16QAM-133447-1RB#0-Range6:12000~26500MHz




Band71-10MHz-QPSK-133172-1RB#0-Range1:0.009~0.15MHz




Band71-10MHz-QPSK-133172-1RB#0-Range2:0.15~30MHz




Band71-10MHz-QPSK-133172-1RB#0-Range3:30~1000MHz



Band71-10MHz-QPSK-133172-1RB#0-Range4:1000~5000MHz




Band71-10MHz-QPSK-133172-1RB#0-Range5:5000~12000MHz




Band71-10MHz-QPSK-133172-1RB#0-Range6:12000~26500MHz




Band71-10MHz-QPSK-133297-1RB#0-Range1:0.009~0.15MHz




Band71-10MHz-QPSK-133297-1RB#0-Range2:0.15~30MHz




Band71-10MHz-QPSK-133297-1RB#0-Range3:30~1000MHz



Band71-10MHz-QPSK-133297-1RB#0-Range4:1000~5000MHz




Band71-10MHz-QPSK-133297-1RB#0-Range5:5000~12000MHz




Band71-10MHz-QPSK-133297-1RB#0-Range6:12000~26500MHz




Band71-10MHz-QPSK-133422-1RB#0-Range1:0.009~0.15MHz




Band71-10MHz-QPSK-133422-1RB#0-Range2:0.15~30MHz




Band71-10MHz-QPSK-133422-1RB#0-Range3:30~1000MHz



Band71-10MHz-QPSK-133422-1RB#0-Range4:1000~5000MHz




Band71-10MHz-QPSK-133422-1RB#0-Range5:5000~12000MHz




Band71-10MHz-QPSK-133422-1RB#0-Range6:12000~26500MHz




Band71-10MHz-16QAM-133172-1RB#0-Range1:0.009~0.15MHz




Band71-10MHz-16QAM-133172-1RB#0-Range2:0.15~30MHz




Band71-10MHz-16QAM-133172-1RB#0-Range3:30~1000MHz



Band71-10MHz-16QAM-133172-1RB#0-Range4:1000~5000MHz




Band71-10MHz-16QAM-133172-1RB#0-Range5:5000~12000MHz




Band71-10MHz-16QAM-133172-1RB#0-Range6:12000~26500MHz




Band71-10MHz-16QAM-133297-1RB#0-Range1:0.009~0.15MHz




Band71-10MHz-16QAM-133297-1RB#0-Range2:0.15~30MHz




Band71-10MHz-16QAM-133297-1RB#0-Range3:30~1000MHz



Band71-10MHz-16QAM-133297-1RB#0-Range4:1000~5000MHz




Band71-10MHz-16QAM-133297-1RB#0-Range5:5000~12000MHz




Band71-10MHz-16QAM-133297-1RB#0-Range6:12000~26500MHz




Band71-10MHz-16QAM-133422-1RB#0-Range1:0.009~0.15MHz




Band71-10MHz-16QAM-133422-1RB#0-Range2:0.15~30MHz




Band71-10MHz-16QAM-133422-1RB#0-Range3:30~1000MHz



Band71-10MHz-16QAM-133422-1RB#0-Range4:1000~5000MHz




Band71-10MHz-16QAM-133422-1RB#0-Range5:5000~12000MHz




Band71-10MHz-16QAM-133422-1RB#0-Range6:12000~26500MHz




Band71-15MHz-QPSK-133197-1RB#0-Range1:0.009~0.15MHz




Band71-15MHz-QPSK-133197-1RB#0-Range2:0.15~30MHz




Band71-15MHz-QPSK-133197-1RB#0-Range3:30~1000MHz



Band71-15MHz-QPSK-133197-1RB#0-Range4:1000~5000MHz




Band71-15MHz-QPSK-133197-1RB#0-Range5:5000~12000MHz



Band71-15MHz-QPSK-133197-1RB#0-Range6:12000~26500MHz



Band71-15MHz-QPSK-133297-1RB#0-Range1:0.009~0.15MHz



Band71-15MHz-QPSK-133297-1RB#0-Range2:0.15~30MHz