User's manual

Serial number	function	Operation	Use Punction Results
		Bluetooth headset is not in charge state	
1 Smart boot The headset is taken out of the charging box and Plus light Closboc with a personnel tank			
2	Smart shutdown	automatically turned on. The headset is automatically turned off by putting it	Blue light flashes
3	Shut down	into the charging box. Headphones long press for 5 seconds to shut down	Blue light goes off
4	Boot on	Headphones long press for 5 seconds to shut down	Blue light flashes with a power-on tone
5	Entering the interconnect mode	After the headset is removed from the charging box, it automatically enters the blue light flashing state and has a voice prompt.	Blue light flashes with ready to pairing tone
6	Paired left and right headsets successfully	The right earphone blue light flashes quickly, the left earphone blue flashes slowly, and there is a voice prompt.	Voice prompts
7	Mobile phone pairing success	The headset is successfully paired with the phone, the blue light flashes slowly, and there is a voice prompt.	Voice prompts
8	Bluetooth disconnect	The headset is disconnected from the mobile phone Bluetooth, the blue light flashes quickly, and there is a voice prompt; after 5 minutes of disconnection, the headset will automatically shut down and have a voice prompt.	There is a tone and there is a disconnect tone
9	Play, pause music	Connection status, click the touch button	Start playing/pausing music
10	Song switching up and down	When entering the music play mode, double-click the left earphone touch button area to switch to the previous track; double-click the right earphone touch button area to switch to the next track;	
11	Volume addition and subtraction	When entering the music playback mode, press and hold the left earphone to touch the button area to decrease the volume: long press the right earphone to touch the button area to increase the volume:	
12	Answer the call	Connection status Click the R headset or L headset touch button	Have a tone and answer the call
13	hang up the phone	Click the R headset or the L headset touch button during the call.	Have a tone and hang up
14	Reject	Press and hold the R headset or L headset touch button in the incoming call state.	There is a tone and reject the call
15	Low electric tone	Report low power when the voltage is low (reported every 30 seconds)	Voice prompts
16	IPHONE power display	Bluetooth is connected to Bluetooth, and the iPhone has a power indicator.	
17	IPHONE volume synchronization	The Bluetooth connection is successful and the machine volume is synchronized with the phone volume.	
18	Automatic connection	After the connection is successfully restarted, the Bluetooth headset automatically connects back to the Bluetooth device.	"Beep" and have a successful pairing voice prompt
19	Remote disconnection	After disconnecting from a long distance, the headset will automatically return to the headset within 5 meters within 3 minutes.	"Beep" and have a successful pairing voice prompt
20	Charging automatic shutdown	Play status, sleep, standby, charging will be turned off	Voice prompt
21	Wake up Siri	Double-click the touch button area of the right earphone or the left earphone	
22	Breathing light	Connect the mobile phone Bluetooth music to play the full circle light effect for the breathing light effect; long press the earphone touch button area for about 3 seconds and the prompt tone 'beep' will turn off the breathing light, if you need to re-open the breathing light effect, then press and hold for about 3 seconds And there is a 'beep' sound.	"Beep"
22	FCC Statement	This device complex with part 15 of the PCC raise. Operation is subject to the following two conditions: (3) this device may not cause benefit identification, and (2) this device must accept any interference and the conditions of the conditions and the conditions of the conditions	