




User's manual

How to paly?




User's manual

How to Replace Battery?



**REQUIRES 2 x "AA" SIZE BATTERIES
(NOT INCLUDED)**



**REQUIRES 3 x "AA" SIZE BATTERIES
(NOT INCLUDED)**

User's manual

information

| | |
|---------------------------|---|
| Frequency: | 27mhz |
| Battery parameters | Remote control:2 x 1.5 V AA Car:3*1.5V AA |
| Type: | 6601 |
| FCC ID: | 2AT6J6601 |
| Manufacturer: | JIA MING TOYS FACTORY |
| Address: | CHENGHAI DISTRICT,SHANTOU CITY, GUANGDONG PROVINCE,CHINA |

Warning

- non-rechargeable batteries are not to be recharged
- rechargeable batteries are to be removed from the toy before being charged
- rechargeable batteries are only to be charged under adult supervision
- different types of batteries or new and used batteries are not to be mixed
- batteries are to be inserted with the correct polarity
- exhausted batteries are to be removed from the toy
- the supply terminals are not to be short-circuited

The packaging has to be kept since it contains important information.

Quadrotor

1. Remove the battery compartment cover.
2. Place three grain of 1.5V AA battery in the correct position when using .
3. Replace battery compartment cover .

Remote Control

1. Remove the screw.
2. Remove the battery compartment cover.
3. Place two grain of 1.5V AA battery in the correct position when using .
4. Replace battery compartment cover and screw.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.