

UF1002 Tab A10 Pro 说明书

成品尺寸：70*113mm


材质：128g铜版纸双面印过哑胶



Follow us on Facebook

Tab A10 Pro

USER MANUAL



Instruction for Card Installation

1. Nano-SIM + Nano-SIM 2. Nano-SIM + Micro SD

Network Bands


GSM: B2/3/5/8

WCDMA: B1/2/4/5/6/8

LTE-TDD: B34/38/39/40/41

LTE-FDD: B1/2/3/4/5/7/8/12/13/17/20/26/28A/28B/66/71

1. Device Layout



- 1-Power Button
- 2-Volume Button
- 3-Front Camera

- 4-Light Sensor
- 5-3.5mm Headphone Jack
- 6-Nano-SIM/micro SD Slot

- 7-Type-C Charging Port
- 8-Speaker
- 9-Rear Camera

- 10-Flash
- 11-Microphone

[1]

2.GETTING STARTED

2.1Charging the battery

Connect the supplied USB cable to the Type-C connector of the tablet. Connect the cable to the adapter and the adapter to the mains.

The tablet begins to charge and the battery indicator is shown on the screen.


2.2 Long press the ON / OFF button to start.



WARNING:

Charge the battery fully during the first charge and prior to first use.

3.Contained in the box




Charger

Type C

Quick Start Guide

[2]

1. BESCHREIBUNG DES GERÄTES



- | | |
|--------------------------------|------------------------|
| 1-Power-Taste | 7- Typ-C-Ladeanschluss |
| 2-Lautstärketaste | 8-Lautsprecher |
| 3-Frontkamera | 9-Rückkamera |
| 4-Lichtsensor | 10-Blitz |
| 5-3,5-mm-Kopfhöreranschluss | 11-Mikrofon |
| 6-Nano-SIM/Micro-SD-Steckplatz | |

2. ERSTE SCHRITTE

2.1 Aufladen des Akkus

Schließen Sie das mitgelieferte USB-Kabel an den Typ-C-Anschluss des Tablets an. Verbinden Sie das Kabel mit dem Adapter und den Adapter mit dem Stromnetz.

Das Tablet beginnt zu laden und die Akkuanzeige wird auf dem Bildschirm angezeigt.


2.2 Drücken Sie zum Starten lang die Taste EIN / AUS.




WARNUNG:

Laden Sie den Akku beim ersten Aufladen und vor der ersten Verwendung vollständig auf.


3. Enthalten in der Box



Tablette



Ladegerät




Type-C



Schnellstartanleitung

1. DESCRIPTION DE L'UNITÉ



- | | |
|---------------------------|-----------------------------|
| 1-Bouton d'alimentation | 7- Port de charge de type C |
| 2-Bouton de volume | 8-Haut-parleur |
| 3-Caméra frontale | 9-Caméra arrière |
| 4-Capteur de lumière | 10-Flash |
| 5-Prise casque 3.5mm | 11-Microphone |
| 6-Fente nano-SIM/Micro SD | |

2. COMMENCER

2.1 Charger la batterie

Connectez le câble USB fourni au connecteur Type-C de la tablette. Connectez le câble à l'adaptateur et l'adaptateur au secteur. La tablette commence à se charger et l'indicateur de batterie s'affiche à l'écran.


2.2 Appuyez longuement sur le bouton Allumez / Éteignez pour démarrer




ATTENTION:

Chargez complètement la batterie lors de la première charge et avant la première utilisation.

3. L'emballage du produit



1. DESCRIPCIÓN DE LAS PIEZAS



1-Botón de encendido

2-Botón de volumen

3-Cámara frontal

4-Sensor de luz

5-Enchufe para auriculares de 3,5 mm

6-Ranura Nano-SIM/Micro SD

7- Puerto de carga tipo C

8-Altavoz

9-Cámara trasera

10-Flash

11-Micrófono

2. CÓMO EMPEZAR

2.1 Cargar la batería

Conecte el cable USB suministrado al conector tipo C de la tableta.

Conecte el cable al adaptador y el adaptador a la red.

La tableta comienza a cargarse y el indicador de batería se muestra en la pantalla.


2.2 Mantenga presionado el botón de reposo/activación para comenzar.




ADVERTENCIA:

Cargue la batería completamente durante la primera carga y antes del primer uso.


3. Contenido en la caja



Tableta



Cargador




Tipo-C



Guía de inicio rápido

1. DESCRIZIONE DELLE PARTI



1-Tasto di accensione

2-Tasto del volume

3-Camera frontale

4-Sensore di luce

5-Presa per cuffie da 3,5 mm

6-Nano-SIM/Micro SD Slot

7-Tipo-C porta di ricarica

8-Altoparlante

9-Camera posteriore

10-Flash

11-Microfono

2. COME INIZIARE

2.1 Caricare la batteria

Collegare il cavo USB in dotazione al connettore Type-C sul tablet. Collegare il cavo all'adattatore e l'adattatore alla rete.

Il tablet inizia a caricarsi e l'indicatore della batteria viene visualizzato sullo schermo.


2.2 Tenere premuto il pulsante Sleep / Wake per iniziare.



AVVERTIMENTO:

Caricare completamente la batteria durante la prima carica e prima del primo utilizzo.


3. Cosa c'è nella scatola



Tavoletta



Caricabatterie




Type-C



Guida Rapida

1. ОСНОВНЫЕ ЭЛЕМЕНТЫ УСТРОЙСТВА



- | | |
|--------------------------------|---------------------------|
| 1-Кнопка питания | 7-Порт для зарядки Type-C |
| 2-Кнопка регулировки громкости | 8-Динамик |
| 3-Фронтальная камера | 9-Задняя камера |
| 4-Датчик освещения | 10-Вспышка |
| 5-3,5-мм разъем для наушников | 11-Микрофон |
| 6-Nano-SIM/Micro SD слот | |

2. ПЕРВОЕ ВКЛЮЧЕНИЕ

2.1 Зарядите батарею

Подключите идущий в комплекте USB-кабель к Type-C разъему планшета. Подключите кабель к зарядному устройству, а зарядное устройство в розетку. Планшет начнет процесс зарядки, вы увидите индикацию на дисплее.

2.2 На несколько секунд зажмите кнопку питания для включения.




ВАЖНО:

Полностью зарядите батарею перед первым использованием планшета.

3. Комплектация



1. ОСНОВНІ ЕЛЕМЕНТИ ПРИСТРОЮ



1-Кнопка енергії

2-Кнопка гучності

3-Перша фотоапарата

4-Датчик освітлення

5-Джек для слухових телефонів 3, 5 мм

6-Нано- SIM/ Мікро- SD Slot

7-Порт завантаження типу C

8-Говорець

9-Задня камера

10-Спалах

11-Мікрофон

2. ПЕРШЕ ВКЛЮЧЕННЯ

2.1 Зарядіть батарею

Підключіть USB кабель з комплекту до Type-C роз'єму планшета. Підключіть кабель до зарядного пристрою, а зарядний пристрій в розетку. Планшет почне процес зарядки, ви побачите індикацію на дисплеї.


2.2 На кілька секунд затисніть кнопку живлення для вклучення.



ВАЖЛИВО:

Повністю зарядіть батарею перед першим використанням планшета.


3. Комплектація



Планшет



Зарядний пристрій




Type-C



Короткий посібник користувача

1.各部の紹介



- | | |
|-----------------------|---------------|
| 1-電源ボタン | 7-Type-C充電ポート |
| 2-音量ボタン | 8-スピーカー |
| 3-前面カメラ | 9-リアカメラ |
| 4-光センサー | 10-フラッシュ |
| 5-3.5mmヘッドフォンジャック | 11-マイク |
| 6-Nano-SIM/マイクロSDスロット | |

2.初めにお読みください。

2.1 充電について

USBケーブルをタブレットのType-Cポートに接続します。
ケーブルを充電アダプターに接続し、アダプターを電源コンセントに接続します。
タブレットの充電が始まり、通知LEDライトが点灯します。


2.2 ON/OFFボタンを長押しすると、起動/OFFします。



警告：

最初の充電中および最初の使用前に、バッテリーを完全に充電してください。

3.梱包内容：



充電器

Type-Cケーブル

クイックスタートガイド

2-بدء التشغيل

2.1 شحن البطارية قم بإيصال كبل USB بمدخل الشحن نوع C من الجهاز اللوحي

قم بإيصال الكبل بمحول الطاقة ومحول الطاقة بالمأخذ الرئيسي..


يبدأ الجهاز اللوحي بالشحن ويظهر مؤشر البطارية على الشاشة.

2.2 الضغط مطولا على زر التشغيل/ إيقاف التشغيل للبدء.


تحذير: قم بشحن البطارية بالكامل خلال الشحن الأول وقيل الاستخدام الأول




3- الموجود في الصندوق



الجهاز اللوحي



الشاحن




النوع C



دليل التشغيل السريع

1- تصميم الجهاز



7- Type-C نغليلا نغليلا

8- مكبر صوت

9- الكاميرا الخلفية

10- ش.الف

11- مذياع

1- زر التشغيل

2- زر حجم الصوت

3- الكاميرا الأمامية

4- مؤشر زغشيتسم

5- ملم 3,5 شاعليس مليم

6- فتحة نايمو- SIM/ بطاقة SD صغيرة

CE Warning

1. Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss.
2. CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.
3. The product shall only be connected to a USB interface of version USB2.0.
4. Adapter shall be installed near the equipment and shall be easily accessible.
5. Operation temperature: -10~40C
6. The plug considered as disconnect device of adapter.
7. SAR: The device complies with RF specifications when the device used at 5mm from your body (SAR limit 2.0W/Kg), The device is in compliance with the requirements.



This information has to be presented in such a way that the user can readily understand it. Typically, this will necessitate translation into every local language (required by national consumer laws) of the markets where the equipment is intended to be sold. Illustrations, pictograms and using international abbreviations for country names may help reduce the need for translation.

Restrictions in the 5 GHz band:

According to Article 10 (10) of Directive 2014/53/EU, the packaging shows that this radio equipment will be subject to some restrictions when placed on the market in Belgium (BE), Bulgaria (BG), the Czech Republic (CZ), Denmark (DK), Germany (DE), Estonia (EE), Ireland (IE), Greece (EL), Spain (ES), France (FR), Croatia (HR), Italy (IT), Cyprus (CY), Latvia (LV), Lithuania (LT), Luxembourg (LU), Hungary (HU), Malta (MT), Netherlands (NL), Austria (AT), Poland (PL), Portugal (PT), Romania (RO), Slovenia (SI), Slovakia (SK), Finland (FI), Sweden (SE), the United Kingdom (UK), Turkey (TR), Norway (NO), Switzerland (CH), Iceland (IS), and Liechtenstein (LI).

The WLAN function for this device is restricted to indoor use only when operating in the 5150 to 5250 MHz frequency range.



FCC Caution

[19]

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This Product meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of this Device UF1002(FCC ID: 2AT9T-1002) has been tested against this SAR limit. SAR information on this can be viewed on-line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search. This device was tested for typical operations 10mm from the body. To maintain compliance with FCC RF exposure requirements, 10mm separation distance should be maintained to the user's bodies

[21]

NOTE:

[20]

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

[22]

The information contained herein is subject to change without notice. The only warranties for Connect and services are set forth in the express warranty statements accompanying such products and services.

Nothing herein should be construed as constituting an additional warranty. Connect shall not be liable for technical or editorial errors omissions contained herein.

Shenzhen Gotron Electronic CO., LTD

Address: 7B01, Building A, Block 1, Anhongji Tianyao Plaza,
Longhua District, Shenzhen City, Guangdong
Province, China

Service Center

Email: service@ulefone.com



RF Specification:

Function	Operation Frequency	Max RF output power:
BLE	2402MHz~2480MHz	-1.42 dBm
BT(BR+EDR)	2402MHz~2480MHz	5.26 dBm
WIFI 802.11b/g/n/(HT20/40)	802.11b/g/n (20MHz): 2412~2472MHz; 802.11n (40MHz):2422~2462MHz	15.43 dBm
Wi-Fi 5.2G(802.11a/n20/n40/ac 20/ac40/ac80)	802.11a/ n20/ac 20:5180MHz~5240MHz 802.11 n40/ac 40:5190MHz~5230MHz 802.11 ac 80:5210MHz	12.38 dBm
Wi-Fi 5.8G(802.11a/n20/n40/ac 20/ac40/ac80)	802.11a/ n20/ac 20:5745MHz~5825MHz 802.11 n40/ac 40:5755MHz~5795MHz 802.11 ac 80:57750MHz	12.67 dBm
GSM/GPRS/EGPRS 900	TX(Uplink):880M-915MHZ; RX(Downlink):925M-960MHZ	32.63 dBm
GSM/GPRS/EGPRS 1800	TX(Uplink):1710M-1785MHZ; RX(Downlink):1805M-1880MHZ	30.28 dBm
WCDMA B1	TX(Uplink):1920-1980MHz; RX(Downlink):2110-2170MHz	23.55 dBm
WCDMA B8	TX(Uplink): 880-915MHz; RX(Downlink):925-960MHz	23.01 dBm
LTE FDD B1	TX(Uplink):1920-1980MHz; RX(Downlink):2110-2170MHz	22.81 dBm
LTE FDD B3	TX(Uplink) :1710-1785MHz; RX(Downlink):1805-1880MHz	23.90 dBm
LTE FDD B7	TX(Uplink) :2500-2570MHz; RX(Downlink):2620-2690MHz	23.96 dBm
LTE FDD B8	TX(Uplink): 880MHz to 915 MHz RX(Downlink): 925 MHz to 960 MHz	23.81 dBm
LTE FDD B20	TX(Uplink): 832MHz~862MHz; RX(Downlink):791MHz~821MHz	23.60 dBm
LTE FDD B28a	TX(Uplink): 703 MHz to 733MHz RX(Downlink): 758 MHz to 788 MHz	23.49 dBm
LTE FDD B28b	TX(Uplink): 718 MHz to 748MHz RX(Downlink): 773 MHz to 803 MHz	23.35dBm
LTE TDD B38	Uplink & Downlink:2570 MHz to 2620 MHz	24.06 dBm
LTE TDD B40	Uplink & Downlink: 2300 MHz to 2400 MHz	24.00 dBm
FM	Rx(Downlink): 87.5MHz~108MHz	--
GPS	Rx(Downlink): 1.57542GHz	--