



TRANSMITTER & TRIMMER




HOW TO USE THE SMOKE FEATURE



Open the lid and pour clean water.

Note: water should be filled at least half of reservoir.

Connect the included rechargeable battery pack



To recharge the battery you must use the provided USB charging cable.

USB charger

27Mhz FREQUENCY

Connect USB cable to only 5V charger



INSTRUCTIONS

1. Recharge the Ni-Cd battery before use for at least 8hrs for the first 2 times
Normal charge after for 5-6 hours. Do not overcharge more than 8hrs.
2. Install batteries.
3. Turn the power switch to the "ON" position on the car.
4. Turn the power switch to the "ON" position on the remote control.
5. If it does not pair successfully repeat step 2 and 3.
6. Remote control and car pairing needs to be done only once.
7. To reset the control frequency, you need to remove the batteries wait or 30 seconds and re-install the batteries. The control light indicator will flash and then go into a constant light.

Caution

1. Do not throw batteries into fire. Otherwise, batteries may explode or leak.
2. Do not mix new and old batteries.
3. Do not mix different types of batteries such as carbon-zinc, alkaline or rechargeable.
4. It's suggested to use batteries of the same brand or the same type.
5. As small parts may cause choking danger, battery replacement should be done by an adult.
6. Note polarity when installing the batteries to avoid short circuit.
7. Do not leave exhausted batteries in the product. When necessary replace the batteries with new ones.
8. Do not charge batteries that are not rechargeable.
9. If rechargeable battery is used, remove it from the product before charging.
10. Please keep this packaging box as they contain important information about the product.

caution

WARNINGS:

1. Use the same type of batteries, do not mix old and new batteries.
2. Insert the batteries properly, do not misplace +/- electrode.
3. Non-rechargeable batteries can not be charging, rechargeable batteries are only to be charged under adult supervision.
4. Please take out the batteries when not in use for a long time.

FCCID:2ATH8202007210123

this device complies with part 15 of the FCC Rules, operation is subject to the following two conditions;(1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However there is no guarantee that interference will not occur in a particular installation.

if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures;

--reorient or relocate the receiving antenna.

--increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.