



说明书尺寸: 80x120mm  
材质: 105g铜版纸  
印刷: 单黑  
装订方式: 骑马钉

Thank you for purchasing the AUKEY EP-M6 True Wireless Earbuds. Please read the user manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your purchase receipt.

**Package Contents**

True Wireless Earbuds  
Charging Case  
User Manual

**Product Diagram**

LED Status Indicator  
Touch-Sensitive Panel

Charging Case

LED Status Indicator  
USB-C Charging Port

English

**Specifications**

Model	EP-M6
Technology	Bluetooth 5.2
Bluetooth Version	5.2
Bluetooth	BT5.2
Microphone Type	MEMS Microphone
Speaker Sensitivity	90dB±1dB
Microphone Sensitivity	24dB
Battery Type	Li polymer 2 x 30mAh
Battery Life	12h (typical) / 24h (max)
Charging Time	1h
Speaker Frequency Range	20K-20KHz
Microphone Frequency Range	50Hz-10KHz
Transmission Range	10m
Weight	53g (each earbud)

**Charging Case**

Charging Time	1h
Charging Time	1h
Battery Type	Li polymer (300mAh)
Number of Contacts Technology	100% waterproof

**Getting Started**

Fully charge the charging case before the first use. Connect the charging case to power source with the included USB-C cable. The LED indicator will turn on when the case is fully charged and turn off when charging process is completed.

**Note**

1. Remove the protective film from the earbuds when using for the first time.  
2. Using an adapter with an output voltage higher than 5V may not charge the battery or damage the device.  
3. Turn off the earbuds when not in use to save power.

**Turning On / Off**

Turn On: Press and hold the touch-sensitive panel for 3 seconds until the LED indicator flashes for 3 seconds and the case indicator also flashes.  
Turn Off: Press and hold the touch-sensitive panel for 3 seconds until the LED indicator flashes for 3 seconds and the case indicator also flashes.

**Pairing**

1. Turn on the earbuds.  
2. Press and hold the touch-sensitive panel for 3 seconds until the LED indicator flashes for 3 seconds and the case indicator also flashes.  
3. Turn on the pairing function on the device you want to pair with the earbuds.

**Regular Use After Pairing**

Once the earbuds are successfully paired with your device, they will automatically turn on. The indicator on the earbuds will stay white while the indicator on the other earbud will stay white. Pressing the touch-sensitive panel will enter into pairing mode.

**Note**

• When you turn on the earbuds, they will be automatically reconnected to the previously paired device in pairing mode if it is paired.  
• If you are using the earbuds for the first time, they will be automatically reconnected to the previously paired device in pairing mode if it is paired.  
• If one of the earbuds does not work during use, put both earbuds back in the charging case and wait for 10 seconds before using them out. They will be automatically reconnected to each other.

**Reset the Earbuds**

1. Put the earbuds into the charging case, and then take out the left and right earbuds. Press and hold the touch-sensitive panel for 10 seconds until the LED indicator flashes for 10 seconds and the case indicator also flashes.  
2. Press and hold the touch-sensitive panel for 10 seconds until the LED indicator flashes for 10 seconds and the case indicator also flashes.  
3. Turn on the earbuds and they will be automatically reconnected to each other.

**Controls & LED Indicators**

**Steering Audio**

Press and hold the touch-sensitive panel for 3 seconds until the LED indicator flashes for 3 seconds and the case indicator also flashes.

**Play or pause track**

Press and hold the touch-sensitive panel for 3 seconds until the LED indicator flashes for 3 seconds and the case indicator also flashes.

**Stop to next track**

Press and hold the touch-sensitive panel for 3 seconds until the LED indicator flashes for 3 seconds and the case indicator also flashes.

**Take Calls**

Answer call: Press and hold the touch-sensitive panel for 3 seconds until the LED indicator flashes for 3 seconds and the case indicator also flashes.  
Reject call: Press and hold the touch-sensitive panel for 3 seconds until the LED indicator flashes for 3 seconds and the case indicator also flashes.  
End a call: Press and hold the touch-sensitive panel for 3 seconds until the LED indicator flashes for 3 seconds and the case indicator also flashes.

**LED Indicators for Earbuds**

Turn on / Off	LED on / Off
Pairing mode	LED on / Off
Charging	LED on / Off
Full charged	LED on / Off

**LED Indicators for Case**

Charging	Flashing orange light
Full charged	Flashing orange light
Charging	Flashing orange light
Full charged	Flashing orange light

**Mobile App**

To use the app, please download the app from the Google Play Store or the Apple App Store. The app is available for both iOS and Android devices.

**App Installation**

1. Open the App Store for iOS or Google Play Store for Android on your mobile device.  
2. Search for "AUKEY EP-M6" in the search bar.  
3. Tap the "Install" or "Get" button to download and install the app on your device.

Alternatively, you can scan the QR code provided below to directly access the app download page.

**App Pairing**

1. Connect your earbuds to your mobile device.  
2. Open the app and tap the "Pair" button.  
3. The app will search for the earbuds and display the pairing code.  
4. Enter the pairing code on the app to complete the pairing process.

**FAQ**

**The earbuds are not working properly.**  
1. Check if the earbuds are fully charged.  
2. Check if the earbuds are in pairing mode.  
3. Check if the earbuds are connected to the correct device.  
4. Check if the earbuds are not blocked by any obstacles.

**The earbuds are not working properly.**  
1. Check if the earbuds are fully charged.  
2. Check if the earbuds are in pairing mode.  
3. Check if the earbuds are connected to the correct device.  
4. Check if the earbuds are not blocked by any obstacles.

**The earbuds won't turn on.**  
1. Check if the earbuds are fully charged.  
2. Check if the earbuds are in pairing mode.  
3. Check if the earbuds are connected to the correct device.  
4. Check if the earbuds are not blocked by any obstacles.

**The earbuds won't turn on.**  
1. Check if the earbuds are fully charged.  
2. Check if the earbuds are in pairing mode.  
3. Check if the earbuds are connected to the correct device.  
4. Check if the earbuds are not blocked by any obstacles.

**Product Care & Use**

• Keep away from liquids and extreme heat.  
• Do not use the earbuds for extended periods of time, as this may cause permanent hearing damage or loss.  
• Regular cleaning is recommended to prevent issues with charging and earbuds.

**Warranty & Customer Support**

For warranty support or inquiry claims, please contact your seller directly.

**FCC Statement**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Notes:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment does not use radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installations. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**FCC Radiation Exposure Statement:**  
This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This statement must not be concealed or operating in conjunction with any other statement or literature.