

2018BP4

BandPhones User Manual

www.bandphonesellc.com

(CE, FCC, Rec. symbol, etc.)

Thank you for choosing our BandPhones device. This user manual teaches users how to successfully operate Bandphones functions and features.

Description of Main Function:

1. BT 5.0 Wireless Technology

- 1.1 BT version: V5.0
- 1.2 Built in microphone to answer phone calls.
- 1.3 Wireless range approximately 10m (32 feet) (depending on environmental conditions).
- 1.4 Wireless music streaming from smartphone or tablet, compatible with all wireless BT devices.

2. Power Supply

- 2.1 Integrated with built in Li-ion rechargeable battery 3.7V. 300mAh.
- 2.2 Listen to your favorite music when and where you want -Up to 15 hours

3. Washable headband

The headband portion of the Bandphones, after frequent use, will get dirty. It will need to be washed. Before washing the Bandphones headband the speakers (electronics) must be removed.

DO NOT EMERSE THE SPEAKER PORTION OF THE BANDPHONES INTO LIQUID.


- 3.1 Take out the headphones from the headband hole by pushing (or squeezing) from the two sides each speaker, with care, not pull on the wiring connecting the two speakers.
- 3.2 Wash the headband portion by hand or machine wash and if possible use biodegradable soap. Do not use bleach.
- 3.3 If the speaker (electronic portion) gets wet then let dry for 48 hours before turning ON or recharging.
- 3.4 Air-dry the headband by natural air. **Do not use a dryer and/or iron.**
- 3.5 Ensure headband is fully dry, then put the speakers (electronics) back into the headband and ensure the USB port/power button speaker is in the right side.

4. Specifications:

- 4.1 Frequency: 20Hz-20KHz
- 4.2 Sensatory: 96dB/mW
- 4.3 Impedance: 32 Ω
- 4.4 Battery: 300mAh/3.7V
- 4.5 Charging time: 3H
- 4.6 Playing time: ≥15H

Instructions:

Fashion design BandPhones (2018BP4)



How to connect your BT wireless device:

1. Turn your Bandphones speaker on by pressing and holding the power button on the speaker middle until you heard the audible beeps and/or the indicator LED will start fast blinking with blue and red alternately.
2. Turn on BT on your device (smartphone or tablet) and search for new BT device.
3. Choose the name "Bandphones" and connect when it appear on your search list.
4. When successfully connected the indicator blue LED will slowly blink.
(Bandphones will auto reconnect to a paired BT device when powered on)

Using Your BandPhones:

1. Long press the power button to turn the speaker on or off.
2. Short press the power button to pause/or resume music.
3. Short press the power button to answer/or hang up a phone call.
4. Long press the power button to reject a phone call.

Charging the Battery:

When the battery is running low, the speakers will make a beeping sound the red LED indicator will start to blink. Charge your Bandphones by plugging in your USB charger to the Bandphones speaker input port on the side of the speaker. When charging the battery the LED indicator will turn red. When the battery is fully charged the red indicator LED will stop illuminating.

NOTICE: Fully charge the battery before first time use.

Warranty: This product is quality tested and has the legal warranty period of 18 months from date of purchase. Please keep the invoice document as proof of purchase.

Copying and reproduction only with permission of the publisher Bandphones LLC
www.bandphonesllc.com

FCC Warning Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.