SETUP YOUR HYPERSONIC

1. Place headphones in the charging case Insert the Left and Right headphones into the charging case

iminutes to recharge,

Fin This will wake up the HyperSonic earbuds from sleep mode.

Nedice the publish ble light on the headphones when properly docked.

You may occasionally need to push or clean (with cotton swall) the
charging pins in the charging case to disladge any dust or debris that
inhibits tham from charging your earbuds.

1000

2. Put headphones in your ear Remove the Left and Right HyperSonin headphones from the charging case, Right headphone will flash blue and white. Place them in your ears.

You will hear:
"HyperSonic is Connected"
"I oft Channel/Right Channel 'HyperSonic in Pairing Mode'

3. Pair HyperSonic to your phone (or other Bluetooth device) nce you hear "HyperSonic in Pairing Mode" it is ready to be iscovered by your Bluetooth enabled phone or device.

Turn on Bluetooth on your device. Select "LinearFlux HyperSonic" in your Bluetooth devices list. Left head prompt "HyperSonic Pairing Successful".

TIP: If pairing is unsuccessful, repeat steps 1 – 3.

"Congratulations! You are now ready to use your HyperSonic headphones."

HYPERSONIC RECHARGING

Place HyperSonic into the Charging case.
As long as your case is charged, the headphones will
display a pulsing blue light wills charging is in progress.
The blue light will turn off after the headphones are fully
charged. You may need to push or clean (with totton swab)
the charging pins in the charging case to dislodge any dust
or debris.

Verifying HyperSonic earbuds battery level 1, On your phone's status bar when paired, 2, 2 voice prompts will indicate "Low Battery" when headphones have less than 10% charge left.

Recharging the case by connecting to a USB

power source Use the provided USB-A to micro-USB recharging cable, We do not recommend using USB wall chargers above 5V

Check charging case battery level ate battery level:

Check Charging Case battery IC Charging case charger meter will indi 0-25% - 1 Blue Light 25-50% - 2 Blue Lights 50-75% - 3 Blue Lights 75-100% - 4 Blue Lights

Four solid blue lights indicate that the charging case has been fully charged.

BUTTON FUNCTIONS



Play / Pauses 1 Top | Play / Pauses 1 Top | Track Backs 2 Top | Track Backs 3 Top | Track Paul 2 Top | And 2 Top |

VOICE PROMPTS

HyperSonic Powering On": Power ON HyperSonic is Connected": Headphones synced to each othe HyperSonic in Pairing Mode": HyperSonic is ready to connec o Bluetooth device HyperSonic Pairing Successful": HyperSonic is paired to

evice Left Channel": Left headphone

Lett Channel: Lett neapphone Right Channel: Right headphone Incoming Call*: Incoming Call* Call Ended: Gall ended 'Call Righected': Call rejected 'Disconnected': Letf and Right headphones are disco Low Battery': Headphones battery level is low 'HyperSonic Powered Off': Power OFF

smitter Charging Case

On/Off - Press and hold 5 seconds
Pairing mode - Double click button
*Light will flash to indicate pairing mode and turn
reliid ners paired.

EARBUD FIT eartips

HyperSonic headphones are preinstalled with a large ear tip PRO TIP: have the largest ear-tip you can fit inside your ear canal for optimum HD sound quality. Hold the headphone vertical to the ear. Twist in the ear canal to lock in

If the HyperSonic does not feel secure enough, please try going up or down an ear-tip size for the best fit and proper seal to optimize your sound experience.

QUICK TIPS

he ear tip.

c headphones feature an IPX6 water resistant hypersonic readplinines feature air iPAN water resistant rating and are designed to handle rain, sweat, and outdoor activities. However, they are NOT intended for water immersion, swimming, showering or exposure to pool or ocean water. In case of exposure to safted or chlorinated water, rinse the headphones gently with fresh water and air r/th yeffor uso. fresh water and air dry before use.

Please take care of your headphone/case. Do not disassemble, burn, nuncture, crush or bend your headphone/case. Improper operation o

e headphone/case may produce smoke. In such an event, ventilate

use resulptionercase may produce smoke. In such an event, ventitate the area. Extinguish any flames with cland nidoxide, or pooder fire extinguisher, or cover with sand or mud. Take care to avoid conditions of excessive makture for prolonged periods and do not immerse. Do not expose to temperature above 50°C172F. Charge headphonercase fully before storage or if stored for longer than three months.

(a)

Fully dry off the HyperSonic before placing in the charging case to avoid any damage to the case electronics.

TROUBLE SHOOTING

For more troubleshooting tips, please visit www.LINEARFLUX.com and visit our LINEARFLUX YouTube page (www.youtube.com/LinearFlux).

Can you hear music from one headphone but not the other? Reset and ReSync the Left and Right headphones: A better proviously assed HyperSnier from your blactooth menu. Place both headphone into the charging case, Males sure BOTH headphones have a publing blac light.

2. Tap gently on each headphones for 5 time while they are docked in the BOTH flash blue and white.

3. Take both headphones out of the charging Take both headphones out of the charging case at the SAME time and hold them directly fourthing each other to initiate Left and Right headphone connection. ALERT if the earbuild of not touch each other they will ROT say repoylely Deck out our 'fourtible channel for more info, www.YouTube.com/LinearHux

Note: To avoid having to reconnect the headphones. Return the headphones is the case properly and make sure the LED on each headphone pulses blue upo docking. See "Charging Headphones".

SONICLINK BACK MEMORY: The HyperSonic can remember up to 2 of your previously paired Bluetooth devices. Insert your HyperSonic earbuds into the case re-pair your HyperSonic to a previously paired device, then turn OFF the bluetooth from the most recently paired device, Now, turn-ON the Bluetooth of you paired device, Now, turn-ON the Bluetooth of your previously paired device, Take off the HyperSonic earbuds from the case, The earbuds will search for all the previously paired devices and will automatically pair your device. Please note that this feature will not work whenever the HyperSonic earbuds are ReSync as previously described.

SAFETY

- The product contains small, detachable parts, which may cause choking, personal injury, or death, especially in children. Please exercise care in the use and handling of small parts, and keep them away from children under 4 years of age.

 Do not use your headphones in any environment where a
- failure to hear surrounding sounds may be dangerous.

 Do not use your headphones while driving or operating

- Do not use your headphones where ownig to sup-aurus, matchinery.
 Do not modify the product, Do not disassemble or attempt to service this product.
 This is not a Children's Product and is not intended for use
 This is not a Children's Product and is not intended for use
 This product is seed under normal and reasonably foreseeable operating conditions. If product is operating improperly, contact LinearFlux suport. Product must be returned to LinearFlux for any service or repair.

Keep HyperSonic headphones away from devices and object that could be damaged or impacted by magnetic fields. HyperSonic magnets may interfere with certain medical

WARRANTY

PARTICLE VI. In the process of the p

Read all Instructions and warnings prior to using this product. Improper use of this product may result in product damage, excess heat, toxic fumes, fire or explosion, for which damages you (Purchaser!) and not LinearFix USA Incorporated ("Manufacturer") are responsible.

LEGAL.

This headphone is meant for use only in conjunction with the appropriate mobile device. Please consult your device packaging to determine whether this headphone is compatible with your particular mobile device. Manufacture is not responsible for any damages to any mobile device incurred through the use of this

Manufacturer shall not in any way be liable to you or to any third Manufacture shall not in any way be liable to you or to any third party for any damages, you or any thried party may suffer as a result of two intended or unrinstended, or misuse of this hadphiene in copiation with any deliver or excessory other than the appropriate mobile effect for which this hadphine is only one of the copiation of the copia

0000

US COMPLIANCE

FC Liferantian.

This explaines the base tested and found to comply with the limits for a Class B digital device, pursant to Bart 15 of the FC Life.

This for a Class B digital device, pursant to Bart 15 of the FC Life.

Also, Thread Internal seeding of the profit explained in the limit of the limit of

- Recrient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that

his device complies with Part 15 of the FCC Rules. Operation is ubject to the following two conditions: (1) this device may not use harmful interference, and (2) this device must accept any terference received, including interference that may cause indesired operation.

ELL COMBITANCE CE

LINEARFLUX hereby declares that this device is in compliance with the requirements.

The symbol above indicates that this product and/or battery should not be disposed of with household waste. When you decide to dispose of this product and/or its battery, do so in accordance with local environmental law and guidelines.

LICENSED UNDER FREEBIT PATENTS EP2434777, US8976995 AND CORRESPONDING INTERNATIONAL PATENTS

Charging Box FCC ID: 2ATO6-HYPERSONC

R-Earphone FCC ID: 2ATO6-HYPERSONNC L -Earphone FCC ID: 2ATO6-HYPERSONCC

At the end of its life, please take care to dispose of this product isponsibly. Electronic products and headphones contain materials hat can be harmful to the environment. Please do not dispose to rted waste. Take your electronic waste to a designated collection recycling facility to be recycled property. Your local council authority will be able to tell you where your nearest facilities are. here may be one at your local supermarket.

eadobone and headobone case Information

CONTACT US

We want you to be satisfied with your HyperSonic headphones, please contact us if you have any questions/concerns and we'll take care of you! You can contact our California based customer support team:

Website: www.LINEARFLUX.com Email: info@linearflux.com
Visit LINEARFLUX.COM to return or exchange.

All rights reserved 2021, www.LinearFlux.com Designed by LinearFlux in California. Assembled in China.



1111

LIDEARFLUX

EDITION X